


Series MB□Q

∅32, ∅40, ∅50
∅63, ∅80, ∅100

Replacement
Procedure is
P.284

Construction



* The numbers are the same as the "Construction" of the Best Pneumatics No.2 Series MB□Q.

Seal Kit List

No.	Description	Material	Note
13	Back-up O-ring	NBR	16 is a non-replaceable part, so it is not included in the seal kit.
14	Rod seal		
15	Piston seal		
16	Cushion valve seal		
17	Cylinder tube gasket		

Replacement Parts: Seal Kit

Bore size (mm)	Kit no.	Contents
32	MBQ32-PS	Set of left nos. 13, 14, 15, 17.
40	MBQ40-PS	
50	MBQ50-PS	
63	MBQ63-PS	
80	MBQ80-PS	
100	MBQ100-PS	

* Seal kits consist of items 13, 14, 15 and 17, and can be ordered by using the seal kit number corresponding to each bore size.

* Trunnion type should not be disassembled.

* Since the seal kit does not include a grease pack, order it separately.

Grease pack part no.: GR-L-005 (5 g), GR-L-010 (10 g), GR-L-150 (150 g)