
Series CUJ 04, 06, 08, 010




Construction

Double acting



Single acting, spring return



* The numbers are the same as the "Construction" of the Best Pneumatics No.2 Series CUJ.

Seal Kit List

No.	Description	Material	Note
11)	Piston seal		
12	Rod seal	NBR	
13	Tube gasket		

Replacement Parts: Seal Kit

riepiacement i arts. Ocai ttit		
Bore size (mm)	Kit no.	Contents
Double acting		
4	CUJB4-PS	Cat of left nee
6	CUJB6-PS	Set of left nos.
8	CUJB8-PS	and grease pack.
10	CUJB10-PS	and grease pack.

* Seal kit 11 to 13 comes as a set. Use the kit number for each bore size.

Single acting, spring return

4	CUJB4-S-PS	
6	CUJB6-S-PS	Set of left nos. 11
8	CUJB8-S-PS	and grease pack.
10	CUJB10-S-PS	

^{*} Use the following part number for ordering a grease pack only. Grease pack part no.: GR-L-005 (5 g)

Modular F.R.L. Pressure Control Equipment

Air Preparation Equipment

Industrial Filters

Actuators


Mini Free Mount Cylinder

Series CUJ 012, 016, 020




Construction

Double acting



Single acting, spring return



* The numbers are the same as the "Construction" of the Best Pneumatics No.2 Series CUJ.

Seal Kit List

No.	Description	Material	Note
13	Piston seal		
14)	Rod seal	NBR	
15	O-ring		

Replacement Parts: Seal Kit

riepiacement i arts. Ocai Kit			
Bore size (mm)	Kit no.	Contents	
Double acting			
12	CUJB12-PS	Set of left nos.	
16	CUJB16-PS	13, 14, 15	
20	CUJB20-PS	and grease pack.	

^{*} Seal kit (3) to (15) comes as a set. Use the kit number for each bore size.

Single acting, spring return

12	CUJB12-S-PS	Set of left nos. (13)
16	CUJB16-S-PS	and grease pack.
20	CUJB20-S-PS	

^{*} Use the following part number for ordering a grease pack only. Grease pack part no.: GR-L-005 (5 g)