





SMC

265





Self Diagnosis Function

In combination with the Handheld Terminal, the following two functions are available.

Short/Open circuit detection function

It is possible to detect short or open circuit of input device such as an electronic 2-wire switch and 3-wire switch and output device such as a solenoid valve. The location of the error can be identified by the indicator light and the network.



Counter function

It is possible to ascertain the maintenance period and identify the parts that require maintenance by an input and output signal ON/OFF counter function. When the counter function is enabled and a certain number of contact operations is reached, the display of counter will flash in red.

Note) The counter function is not provided with the Analog Unit.





⊘SMC

Fieldbus System(€ c AL usSeries EX600RoHS



∕⊘SMC

Note 2) Cannot be connected with the EX600-SPR1, EX600-SPR2, EX600-SDN1, or EX600-SDN2. Refer to page 285 for a table of mountable units.

Fieldbus System Series EX600



Series EX600

SI Unit Specifications

All Units Common Specifications

lice	Operating temperature range	-10 to 50°C
esist	Storage temperature range	-20 to 60°C
쿝	Operating humidity range	35 to 85% RH (No dew condensation)
auo	Withstand voltage Note)	500 VAC for 1 minute between external terminals and FE
E	Insulation resistance Note)	500 VDC, 10 MΩ or more between external terminals and FE
No	te) Except Handheld Terminals	

ept Handheld Termina

SI Unit (EX600-SPR□A)

Model		EX600-SPR1A	EX600-SPR2A				
c	Protocol	PROFIBUS	DP (DP-V0)				
l₽	Device type	PROFIBUS	S DP Slave				
unica	Communication speed	9.6/19.2/45.45/93. 1.5/3/6/	75/187.5/500 kbps 12 Mbps				
Ē	Configuration file	GSD file					
Cor	Occupation area (Number of inputs/outputs)	Max. (512 inputs/512 outputs)					
Te	erminating resistor	Internally implemented					
Internal current consumption (Power supply for Control/Input)		80 mA or less					
	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)				
+	Number of outputs	32 outputs (8/16/24/32 outputs selectable)					
	Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC)					
Ξ	Power supply	24 VDC, 2 A					
10	Fail safe	HOLD/CLEAR/F	orced power ON				
	Protection	Short-circui	t protection				
Er	nclosure	IP67 (Manifold assembly)					
St	andards	CE Marking, UL (CS	SA), RoHS compliant				
W	eight	300 g					

SI Unit (EX600-SDNDA)

	Model	EX600-SDN1A EX600-SDN2A			
	Protocol	DeviceNet [™] : Volume 1 (Edition	on 2.1), Volume 3 (Edition 1.1)		
	Device type	Group 2 O	nly Server		
Communication	Communication speed	125/250/	500 kbps		
	Configuration file	EDS	S file		
	Occupation area (Number of inputs/outputs)	Max. (512 inputs/512 outputs)			
		Duplicate MAC ID	Check Message		
	Applicable messages	Group 2 Only Unconne	ected Explicit Message		
		Explicit Message (Group 2)			
		Poll I/O Message (Predefined M/S Connect			
DeviceNet [™] power supply		11 to 25 VDC (Current consumption 50 mA or less)			
Internal current consumption (Power supply for Control/Input)		55 mA or less			
Output type		Source/PNP (Negative common)	Sink/NPN (Positive common)		
+-	Number of outputs	32 outputs (8/16/24/32 outputs selectable)			
B	Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC)			
Ξ	Power supply	24 VD	C, 2 A		
	Fail safe	HOLD/CLEAR/F	orced power ON		
	Protection	Short-circuit protection			
En	closure	IP67 (Manifold assembly)			
Sta	andards	CE Marking, UL (CS	A), RoHS compliant		
We	eight	300 g			

SI Unit (EX600-SMJD)

Model		EX600-SMJ1	EX600-SMJ2				
Б	Protocol	CC-Link (Ver.	1.10, Ver. 2.00)				
cati	Station type	Remote De	vice Station				
Ē	Communication speed	156/625 kbps 2.5/5/10 Mbps					
Comm	Occupation area (Number of inputs/outputs)	Max. (512 inputs/512 outputs) 1/2/3/4 stations occupied					
Int (Po	ernal current consumption ower supply for Control/Input)	75 mA or less					
	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)				
+	Number of outputs	32 outputs (8/16/24/32 outputs selectable)					
D D	Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC)					
E	Power supply	24 VDC, 2 A					
0	Fail safe	HOLD/CLEAR/Forced power ON					
	Protection	Short-circuit protection					
Er	nclosure	IP67 (Manifold assembly)					
St	andards	CE Marking, UL (CSA), RoHS compliant					
W	eight	300 g					

EX600-SPR

EX600-SDN

EX600-SMJ

Fieldbus System Series EX600

EX600-SEN

Unit (EX600-SEN□)				
Model	EX600-SEN1	EX600-SEN2		
Protocol	EtherNet/IP™ (Conformar	nce version: Composite 6)		
Media	100 BA	SE-TX		
Communication speed	10/100 Mbps (Au	itomatic/Manual)		
Communication method	Full duplex/Half duple	x (Automatic/Manual)		
Configuration file	EDS	file		
Occupation area (Number of inputs/outputs)	Max. (512 input	ts/512 outputs)		
IP address setting range	SI Unit switch settings: Through DHCP serve	192.168.0 or 1.1 to 254 er: Optional address		
Device information	Vendor ID: 7 (SMC Corporation) Product type: 12 (Communication Adapter) Product code: 126			
ernal current consumption wer supply for Control/Input)	120 mA or less			
Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)		
Number of outputs	32 outputs (8/16/24/32 outputs selectable)			
Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC)			
Power supply	24 VDC, 2 A			
Fail safe	HOLD/CLEAR/Forced power ON			
Protection	Short-circuit protection			
closure	IP67 (Manifold assembly)			
andards	CE Marking, UL (CS	A), RoHS compliant		
eight	300) g		
	Unit (EX600-SEN) Model Protocol Media Communication speed Communication method Configuration file Occupation area (Number of inputs/outputs) IP address setting range Device information ernal current consumption wer supply for Control/Input) Output type Number of outputs Load Power supply Fail safe Protection telosure andards eight	Model EX600-SEN□) Model EX600-SEN1 Protocol EtherNet/IP™ (Conformat 100 BA Communication speed 10/100 Mbps (AL Communication method Full duplex/Half duple Configuration file EDS Occupation area (Number of inputs/outputs) Max. (512 input IP address setting range SI Unit switch settings: Through DHCP serv. Device information Yendor ID: 7 (Sh Product type Device information 120 mA Output type Source/PNP (Negative common) Number of outputs 32 outputs (8/16/24/3 Load Power supply 24 VD Fail safe HOLD/CLEAR/F. Protection Protosure IP67 (Manifo andards Geight 300		

SI Unit (EX600-SEC

Model	EX600-SEC1	EX600-SEC2				
Protocol	EtherCAT (Conforman	ce Test Record V.1.2)				
Communication speed	100 N	Mbps				
Configuration file	XML file					
Occupation area (Number of inputs/outputs)	Max. (512 inputs/512 outputs)					
ernal current consumption wer supply for Control/Input)	100 mA or less					
Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)				
Number of outputs	32 outputs (8/16/24/32 outputs selectable)					
Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC)					
Power supply	24 VDC, 2 A					
Fail safe	HOLD/CLEAR/Forced power ON					
Protection	Short-circuit protection					
closure	IP67 (Manifold assembly)					
andards	CE Marking, UL (CSA), RoHS compliant					
eight	300	D g				
	Model Protocol Communication speed Configuration file Occupation area (Number of inputs/outputs) ernal current consumption wer supply for Control/Input) Output type Number of outputs Load Power supply Fail safe Protection closure andards sight	Model EX600-SEC1 Protocol EtherCAT (Conforman Communication speed 100 f Configuration file XMI Occupation area (Number of inputs/outputs) Max. (512 inputs/outputs) erral current consumption wer supply for Control/Inputs 100 mA Output type Source/PNP (Negative common) Number of outputs 32 outputs (8/16/24/3) Load Solenoid valve with surge voltage sup Power supply Pail safe HOLD/CLEAR/F Protection Short-circui andards CE Marking, UL (CS sight 30				

SI Unit (EX600-SPN□)

Model		EX600-SPN1 EX600-SPN2						
5	Protocol	PROFINET IO (PROFINET RT)					
cati	Communication speed	100 1	100 Mbps					
in	Configuration file	GSDML file						
Comm	Occupation area (Number of inputs/outputs)	Max. (512 inputs/512 outputs)						
Int (Po	ernal current consumption ower supply for Control/Input)	120 mA or less						
_	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)					
	Number of outputs	32 outputs						
D	Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.0 W or less (SMC)						
E	Power supply	24 VDC, 2 A						
0	Fail safe	HOLD/CLEAR/Forced power ON						
	Protection	Short-circuit protection						
Enclosure		IP67 (Manifold assembly)						
St	andards	CE Marking, UL (CSA), RoHS compliant						
W	eight	300 g						

EX600-SEC

EX600-SPN

Series EX600

Digital Unit Specifications

EX600-DXDE

EX600-DXDD

Digital Input Unit

g.u								
Model			EX600-DXPB	EX600-DXNB	EX600-DXPC	EX600-DXNC	EX600-DXPD	EX600-DXND
	Input type		PNP	NPN	PNP	NPN	PNP	NPN
	Input connector		M12 (5-pin)	socket Note 1)	M8 (3-pin) s	socket Note 3)	M12 (5-pin)	socket Note 1)
	Number of inputs		8 inputs (2 inp	8 inputs (2 inputs/connector) 8 inputs (1 input/connector)		16 inputs (2 inp	16 inputs (2 inputs/connector)	
	Supplied voltage				24 \	/DC		
Input	Max. supplied current		0.5 A/co 2 A/	onnector 'unit	0.25 A/connector 2 A/unit		0.5 A/connector 2 A/unit	
	Protection		Short-circuit protection					
	Input current (at 24 VDC)		9 mA or less					
	ON voltage	17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)						
	OFF voltage		5 V or less (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)					
	Open circuit	2 wires	_		0.5 mA/in	put Note 2)	-	-
	detection current	3 wires	-	-	0.5 mA/con	nector Note 2)	-	-
Си	irrent consumpt	ion	50 mA	or less	55 mA	or less	70 mA	or less
En	closure				IP67 (Manifo	ld assembly)		
Sta	andards		CE Marking, UL (CSA), RoHS compliant					
We	eight		30	0 g	27	5 g	34	0 g
-								

 Note 1) M12 (4-pin) connector can be connected.

 Note 2) Function only applies to the EX600-DX□C1.

 Note 3) When connecting the M8 plug connector, the tightening torque must be 0.2 N·m ±10%. If tightened with an excessive tightening torque, this may cause the connector thread of the unit to break.

Model		EX600-DXPE	EX600-DXNE	EX600-DXPF	EX600-DXNF	
	Input type	PNP	NPN	PNP	NPN	
	Input connector	D-sub socket (25 pins) Lock screw: No.4-40 UNC		Spring type terminal block (32 pins)		
Input	Number of inputs	16 ir	puts	16 inputs (2 inp	outs x 8 blocks)	
	Supplied voltage		24 \	/DC		
	Max. supplied current	2 A	′unit	0.5 A/block 2 A/unit		
	Protection	Short-circuit protection				
	Input current (at 24 VDC)	5 mA or less				
	ON voltage	17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)				
	OFF voltage	5 V or less (At NPN input, between the pin for input terminal and supplied voltage of +24 (At PNP input, between the pin for input terminal and supplied voltage of 0 V)				
Ap	plicable wire	-	-	0.08 to 1.5 mm ² (AWG16 to 28)		
Сι	irrent consumption	50 mA	or less	55 mA	or less	
Enclosure		IP40 (Manifold assembly)				
Standards		CE Marking, UL (CSA), RoHS compliant				
W	eight		30	0 g		

Fieldbus System Series EX600

Directional Directional **XS** Control Valves

EX600-DY□E EX600-DM□E

EX600-DY□F EX600-DM□F

Digital Output Unit	Digital	Output	Unit
---------------------	---------	--------	------

		EVC00 DVDD	EVCOD DVND	EVCOD DVDE	EVCOD DVNE	EVCOD DVDE	EVCOD DVNE
	IVIOdel	EX000-DIPD	EXOUD-DIND	EX000-DTPE	EXOUD-DTINE	EXOUD-DIPF	EXOUD-DINF
	Output type	PNP	NPN	PNP	NPN	PNP	NPN
	Output connector	M12 (5-pin)	socket Note)	D-sub sock Lock screw:	et (25 pins) No.4-40 UNC	Spring type t (32)	erminal block pins)
Number of outputs Supplied voltage Max. load current		8 outputs (2 out	puts/connector)	16 oi	utputs	16 outputs (2 ou	tputs x 8 blocks)
				24 \	/DC		
		0.5 A/output 2 A/unit					
	Protection	Short-circuit protection					
Applicable wire		-	_	-	_	0.08 to (AWG1	1.5 mm ² 6 to 28)
Сι	rrent consumption	50 mA or less					
Enclosure		IP67 IP40 (Manifold assembly) (Manifold assembly)					
St	andards	CE Marking, UL (CSA), RoHS compliant					
w	eight			30	0 g		

Note) M12 (4-pin) connector can be connected.

Digital Input/Output Unit

	Juan mpaa o aipai o.						
Model		EX600-DMPE	EX600-DMNE	EX600-DMPF	EX600-DMNF		
Input/Output type		PNP	NPN	PNP	NPN		
Connector		D-sub sock Lock screw: I	et (25 pins) No.4-40 UNC	Spring type termin	nal block (32 pins)		
	Number of inputs	8 inputs		8 inputs (2 inputs x 4 blocks)			
	Supplied voltage		24 \	VDC			
Input	Max. supplied current	2 A/	'unit	0.5 A 2 A	/block /unit		
	Protection		Short-circuit protection				
	Input current (at 24 VDC)	5 mA or less					
	ON voltage	17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)					
	OFF voltage	5 V or less (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)					
	Number of outputs	8 out	puts	8 outputs (2 out	puts x 4 blocks)		
Ħ	Supplied voltage	24 VDC					
Outp	Max. load current	0.5 A/output 2 A/unit					
	Protection		Short-circui	t protection			
Ap	plicable wire	-	-	0.08 to 1.5 mm ² (AWG16 to 28)			
Cu	irrent consumption	50 mA	or less	60 mA	or less		
En	closure	IP40 (Manifold assembly)					
Sta	andards		CE Marking, UL (CS	A), RoHS compliant			
We	eight	300 g					

Series EX600

Analog Unit Specifications

EX600-AXA

Analog Input Unit

Model			EX600-AXA	
	Input type		Voltage input	Current input
	Input connector		M12 (5-pin) socket Note 1)	
	Input chan	nel	2 channels (1 channel/connector)	
	Supplied v	oltage	24 \	/DC
	Max. suppl	ied current	0.5 A/cc	onnector
- L	Protection		Short-circui	it protection
ğ	Input signal range	12 bit resolution	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA
=		16 bit resolution	-10 to 10 V, -5 to 5 V	-20 to 20 mA
	Max. rated input signal		±15 V	±22 mA Note 2)
	Input impedance		100 kΩ	50 Ω
	Linearity (25°C)		±0.05% F.S.	
	Repeatability (25°C)		±0.15% F.S.	
	Absolute accuracy (25°C)		±0.5% F.S.	±0.6% F.S.
Current consumption		Imption	70 mA or less	
Enclosure			IP67 (Manifold assembly)	
St	Standards		CE Marking, UL (CSA), RoHS compliant	
W	eight		29	0 g

Note 1) M12 (4-pin) connector can be connected. Note 2) When input signal exceeds 22 mA, the protection function activates and the input signal is interrupted.

Analog Output Unit

Model		del	EX600-AYA		
	Output type		Voltage output	Current output	
	Output connector		M12 (5-pin)	socket Note)	
	Output ch	annel	2 channels (1 channel/connector)		
	Supplied v	/oltage	24 \	/DC	
	Max. load current		0.5 A/cc	onnector	
put	Protection		Short-circuit protection		
out	Output signal range	12 bit resolution	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA	
	Load impedance		1 kΩ or more	600 Ω or less	
	Linearity (25°C)		±0.05% F.S.		
	Repeatability (25°C)		±0.15% F.S.		
	Absolute accuracy (25°C)		±0.5% F.S.	±0.6% F.S.	
Current consumption		umption	70 mA or less		
Enclosure			IP67 (Manifold assembly)		
Standards			CE Marking, UL (CSA), RoHS compliant		
W	Weight		290 g		

Note) M12 (4-pin) connector can be connected.

SMC

Fieldbus System Series EX600

EX600-AMB

An	Analog Input/Output Unit				
Model			EX600-	EX600-AMB	
	Input type		Voltage input	Current input	
	Input connector		M12 (5-pin) socket Note 1)		
	Input channe		2 channels (1 cha	nnel/connector)	
	Supplied volt	age	24 V	DC	
	Max. supplied	d current	0.5 A/connector		
÷	Protection		Short-circuit	Short-circuit protection	
ndu	Input signal range	12 bit resolution	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA	
	Max. rated inp	ut signal	15 V	22 mA Note 2)	
	Input impeda	nce	100 kΩ	250 Ω	
	Linearity (25°	C)	±0.05%	±0.05% F.S.	
	Repeatability (25°C)		±0.15%	±0.15% F.S.	
	Absolute accur	acy (25°C)	±0.5% F.S.	±0.6% F.S.	
	Output type		Voltage output	Current output	
	Output connector		M12 (5-pin) s	ocket Note 1)	
	Output channel		2 channels (1 cha	nnel/connector)	
	Supplied voltage		24 V	DC	
	Max. load cur	rent	0.5 A/connector		
D.	Protection		Short-circuit	circuit protection	
ō	Output signal range	12 bit resolution	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA	
	Load impeda	nce	1 kΩ or more	600 Ω or less	
	Linearity (25°	C)	±0.05% F.S.		
	Repeatability	(25°C)	±0.15%	- F.S.	
	Absolute accuracy (25°C)		±0.5% F.S.	±0.6% F.S.	
Cu	Current consumption		100 mA or less		
Er	nclosure		IP67 (Manifold assembly)		
St	tandards		CE Marking, UL (CSA	CE Marking, UL (CSA), RoHS compliant	
Weight			300 g		

Note 1) M12 (4-pin) connector can be connected. Note 2) When input signal exceeds 22 mA, the protection function activates and the input signal is interrupted.

End Plate

Model		EX600-ED2-	EX600-ED3-		
specification	Power connector	M12 (5-pin) plug	7/8 inch (5-pin) plug		
	Power supply (for Control/Input)	24 VDC ±10%, Class 2, 2 A	24 VDC ±10%, 8 A		
	Power supply (for Output)	24 VDC +10/-5%, Class 2, 2 A	24 VDC +10/-5%, 8 A		
Er	Enclosure IP67 (Manifold assembly)		ld assembly)		
Standards		CE Marking, UL (CSA), RoHS compliant			
Weight		170 g	175 g		

EX600-ED2-□

EX600-HT1A-

ŀ	lan	dh	eld	Те	rmi	na
•	-uii		ciu.			- iu

Model	EX600-HT1A-□
Power supply	Power supplied from SI Unit connector (24 VDC)
Current consumption	50 mA or less
Display	LCD with backlight
Connection cable	Handheld Terminal cable (1 m ··· EX600-AC010-1, 3 m ··· EX600-AC030-1)
Enclosure	IP20
Standards	CE Marking, RoHS compliant
Weight	160 g

Series EX600

Parts Description

No.	Name	Use
1	Status indication LED	Displays unit status.
2	Indication cover	Open for setting the switch.
3	Indication cover set screw	Loosen for opening the indication cover.
4	Connector (BUS OUT)	Connects to the fieldbus output cable.
5	Marker groove	Can be used to mount a marker.
6	Connector (PCI)	Connects to the Handheld Terminal cable.
7	Valve Plate mounting holes	Fixes Valve Plate in place.
8	Valve Plate mounting groove	Inserts Valve Plate.
9	Joint bracket	Links units to one another.
10	Connector for unit (Plug)	Transmits signals to the neighboring unit and supplies power.
11	Connector (BUS IN)	Connects to the cable for fieldbus input.
12	MAC address name plate Note)	Displays a unique 12-digit MAC address for each SI Unit.
13	Seal cap	Mounted on the connectors (BUS OUT and PCI) at the time of shipment.

Note) MAC address name plate is not provided on the EX600-SEC.

Handheld Terminal

No.	Name	Use
1	LCD	Displays operation and unit information.
2	Connector	Connects to the Handheld Terminal cable.
3	Handheld Terminal cable	Connects the SI Unit to the Handheld Terminal.
4	Enter button (())	From the selection screen, goes to the screen for the item selected. On the settings screen, registers the settings that have been made so far.
5	Cursor button	Moves the cursor on the LCD up, down, left or right. Moves the cursor on the selection screen up, down, left or right to make selections. On the settings screen, increases or decreases the value of settings or turns settings on and off.
6	F2 button (Functions in accordance with on-screen display or instructions.
7	F1 button (Functions in accordance with on-screen display or instructions.
8	Escape button (📼))	On the selection screen, goes back to the previous screen. On the settings screen, cancels the settings that have been made so far and goes back to the previous screen.
9	ERROR LED	Lights up red when the EX600 diagnosis errors occur.
10	POWER LED	Connects to the EX600 SI Unit, and lights up green when control/input power supply is on.

277

Fieldbus System Series EX600

Control Valves MA

No.	Name	Use	SY
1	Status indication LED	Displays unit status.	
2	Connector	Connects with input or output devices.	EX(6)
3	Marker groove	Can be used to mount a marker.	
4	Lock screw	Fixes the D-sub connector in place. (No.4-40 UNC)	VM
5	Joint bracket	Links units to one another.	XT3
6	Connector for unit (Plug)	Transmits signals to the neighboring unit and supplies power.	

Analog Unit

No.	Name	Use
1	Status indication LED	Displays unit status.
2	Connector	Connects with input or output devices.
3	Marker groove	Can be used to mount a marker.
4	Joint bracket	Links units to one another.
5	Connector for unit (Plug)	Transmits signals to the neighboring unit and supplies power.

End Plate

No.	Name	Use
1	Power connector	Supplies power to the unit and/or input/output devices.
2	Fixing hole for direct mounting	Connects directly to equipment.
3	Fixing hole for DIN rail	Converts to manifold or for DIN rail mounting.
4	FE terminal	Used for grounding. Ground this terminal securely to improve the noise immunity.
5	Connector (Unused)	This connector has not yet been used. Do not remove the seal cap.

Series EX600

Dimensions

Handheld Terminal

280

Series EX600 **Accessories**

End Plate bracket

This bracket is used for the End Plate of DIN rail mounting.

EX600-ZMA2

Enclosed parts Round head screw (M4 x 20) 1 pc. P-tight screw (4 x 14) 2 pcs. EX600-ZMA3 (Specialized for Series SY)

Enclosed parts Round head screw with washer (M4 x 20) 1 pc. P-tight screw (4 x 14) 2 pcs.

2 Valve Plate EX600-ZMV1 EX600-ZMV2 (Specialized for Series SY Enclosed parts Enclosed parts Round head screw (M4 x 6) 2 pcs. Round head screw (M4 x 6) 2 pcs. Round head screw (M3 x 8) 4 pcs. Round head screw (M3 x 8) 4 pcs.

Accessories Series EX600

Geal cap (10 pcs.)

Be sure to mount a seal cap on any unused I/O connectors. Otherwise, the specified enclosure cannot be maintained.

Marker (1 sheet, 88 pcs.)

The signal name of I/O device and each unit address can be entered and mounted on each unit.

6 7/8 inch connector and its related parts

· Power supply cable with 7/8 inch connector

- PCA-1558810 Straight 2 m PCA-1558823 Straight 6 m PCA-1558836 Right angle 2 m PCA-1558849
 - Right angle 6 m

• Fieldwireable 7/8 inch connector [compatible to AWG22-16] PCA-1578078 Plug PCA-1578081 Socket

Power supply cable with M12 connector (5-pin B-coded)

PCA-1564927	St
PCA-1564930	St
PCA-1564943	Ri
PCA-1564969	Ri

raight 2 m raight 6 m ght angle 2 m ght angle 6 m

Note) For M12 connector, description of B-coded for a reverse type is used as a connector shape.

SPEEDCON

Series EX600

Ocommunication cable with connector/Communication connector

For SI Unit compatible with CC-Link, DeviceNet[™] and PROFIBUS DP

For details, refer to the M8/M12 connector catalog available on SMC website.

Name	Use	Part no.	Description
	For Fieldbus communication	PCA-1567720	Communication cable for CC-Link (Socket)
		PCA-1567717	Communication cable for CC-Link (Plug)
Cable with connector		PCA-1557633	Communication cable for DeviceNet [™] (Socket)
SPEEDCON	OF THE REAL PROPERTY OF THE RO	PCA-1557646	Communication cable for DeviceNet [™] (Plug)
		PCA-1557688	Communication cable for PROFIBUS DP (Socket/B-coded)
		PCA-1557691	Communication cable for PROFIBUS DP (Plug/B-coded)
	For Fieldbus communication	PCA-1557617	Fieldwireable connector for CC-Link (Plug/Spring-caged)
		PCA-1557620	Fieldwireable connector for CC-Link (Socket/Spring-caged)
Fieldwireable		PCA-1557659	Fieldwireable connector for DeviceNet [™] (Plug/Spring-caged)
connector		PCA-1557662	Fieldwireable connector for DeviceNet [™] (Socket/Spring-caged)
		PCA-1557701	Fieldwireable connector for PROFIBUS DP (Plug/B-coded/Spring-caged)
		PCA-1557714	Fieldwireable connector for PROFIBUS DP (Socket/B-coded/Spring-caged)

Accessories Series EX600

birectional Introl Valves

I/O cable with connector/I/O connector

For details, refer to	For details, refer to the M8/M12 connector catalog available on SMC website.				
Name	Use	Part no.	Description		
Cable with connector	For sensor	PCA-1557769	Cable with M12 connector (4 pins/3 m)	SY	
		PCA-1557772	Cable with M8 connector (3 pins/3 m)	EX60	
	For sensor	PCA-1557730	Fieldwireable connector (M8/3 pins/Plug/Piercecon® connection)	VM	
Fieldwireable connector		For sensor	PCA-1557743	Fieldwireable connector	VTO
connector		PCA-1557756	(M12/4 pins/Plug/QUICKON-ONE connection/SPEEDCON)	X13	
Y connector	For sensor	PCA-1557785	Y connector (2 x M12 (3 pins)-M12 (5 pins)/SPEEDCON)		
		PCA-1557798	Y connector (2 x M8 (3 pins)-M12 (4 pins)/SPEEDCON)]	

Note) When using the Y connector, connect it to the connector on the I/O Unit through the sensor cable (PCA-1557769) with the M12 connector.

M8/M12 connector

Series EX600

Table of Mountable Units

The units that can be connected differ depending on the product number. Before mounting, please be sure to confirm the types of units that can be connected. ○: Acceptable ×: Not acceptable

		Product number				
			SI Unit			
			EX600-SPR⊡ (PROFIBUS DP) EX600-SDN⊡ (DeviceNet™)	EX600-SPR⊡A (PROFIBUS DP) EX600-SDN⊡A (DeviceNet™)	EX600-SMJ⊟ (CC-Link)	EX600-SEN⊡ (EtherNet/IP™) EX600-SEC□ (EtherCAT) EX600-SPN□ (PROFINET)
Tab	ole of compatible unit	S	Version	Version	Version	Version
mo	untable with each SI	Unit	Nil	Α	Nil	Nil
		EX600-DXDB	0	0	0	0
	Digital Input Unit	EX600-DXCC	0	0	0	0
		EX600-DXDD	0	0	0	0
		EX600-DXDE	×	0	0	0
		EX600-DX□F	×	0	0	0
pe		EX600-DYDB	0	0	0	0
E E	Digital Output Unit	EX600-DYDE	×	0	0	0
L H		EX600-DYDF	×	0	0	0
qu	Digital Input/Output Lipit	EX600-DMDE	×	0	0	0
2	Digital Input/Output Offic	EX600-DM□F	×	0	0	0
	Analog Input Unit	EX600-AXA	0	0	0	0
[Analog Output Unit	EX600-AYA	×	0	0	0
[Analog Input/Output Unit	EX600-AMB	×	0	0	0
	Handbeld Terminal	EX600-HT1-	Ó	Ó	Ó	×
	nanuneu reminal	EX600-HT1A-	0	0	Ó	Ó

			Product number		
		Handheld Terminal			
			EX600-HT1-	EX600-HT1A-	
Iat	ble of compatible unit	s capable of	Version	Version	
100	nmunication with Har	hdheld Terminals	Nil	Α	
		EX600-SPR (PROFIBUS DP)	0	0	
		EX600-SPR□A (PROFIBUS DP)	0	0	
		EX600-SDN□ (DeviceNet™)	0	0	
	SI Lloit	EX600-SDN⊡A (DeviceNet™)	0	0	
	SION	EX600-SMJ⊟ (CC-Link)	0	0	
duct number		EX600-SEN⊡ (EtherNet/IP™)	×	0	
		EX600-SEC□ (EtherCAT)	×	0	
		EX600-SPN□ (PROFINET)	×	0	
2		EX600-DXDB	0	0	
_		EX600-DXCC	0	0	
	Digital Input Unit	EX600-DXD	0	0	
		EX600-DXDE	×	0	
		EX600-DX	×	0	
		EX600-DYDB	0	0	
	Digital Output Unit	EX600-DYDE	×	0	
		EX600-DYUF	×	0	
	Digital Input/Output Unit	EX600-DMUE	X	0	
		EX600-DMDF	×	0	
	Analog Input Unit	EX600-AXA	0		
	Analog Output Unit	EX600-AYA	×	0	
	Analog Input/Output Unit	EX600-AMB	X	0	

Manifold Solenoid Valves for Series EX600

Type 10 Side Ported Type 11 Bottom Ported

For Series EX600 (E RoHS Plug-in Connector Connecting Base Series SY3000/5000

How to Order Manifold

Refer to the SY3000/5000 series catalog (CAT.ES11-103) for Type 11/Bottom ported dimensions.

Series

3	SY3000
5	SY5000
~	

2 Туре

10	Side ported
11	Bottom ported *
* The S	75000 manifold base is used for bottor

ported of the SY3000. When ordering, refer to "How to Order Manifold" (for plug-in mixed mounting) in the SY series catalog.

SI Unit

0	Without SI Unit	
Q	For DeviceNet [™]	
N	For PROFIBUS DP	
V	For CC-Link	
ZE	For EtherNet/IP™	
D	For EtherCAT	
F	For PROFINET	

Note 1) I/O Unit cannot be mounted without SI Unit. Note 2) Valve Plate which connects manifold and

SI Unit is not mounted to a valve without SI Unit. Refer to page 321 for mounting method.

How to Order Manifold Assembly

 Ine vaive arrangement is numeered as the 1st station from the U side.
 Under the manifold part number, state the valves to be mounted, then the I/O Units in order from the 1st station as shown in the figure above.
 If the arrangement becomes complicated, specify on a manifold specification sheet.

Note 1) Do not enter the SI Unit part number and the End Plate part number together.

Note 2) When mounting a top ported valve, select it from page 294.

In this case, use caution as there is also output on the A and B ports on base side. Specify on a manifold specification sheet if plugs are required on the A and B ports on base side.

4 SI Unit output polarity, End Plate type

SI Unit output polarity	Power supply with M12 connector	Power supply with 7/8 inch connector
Without SI Unit	N	il
SI Unit Positive common	2	3
SLUnit Negative common	4	5

Note 1) Ensure a match with the common

specifications of the value to be used. Note 2) Without SI Unit, the symbol is nil.

5 I/O Unit stations

Nil	None
1	1 station
:	:
9	9 stations

Note 1) Without SI Unit, the symbol is nil.

Note 2) SI Unit is not included in I/O Unit stations.

Note 3) When I/O Unit is selected, it is shipped separately, and assembled by customer. Refer to the attached operation manual for mounting method.

operation manual for mounting method.

6 Valve stations

Symbol	Stations	Note	
02	2 stations		
:		Double wiring Note 1)	
16	16 stations		
02	2 stations	Que e sifi e el les seu e Note 2)	
:		(Available up to 22 colonoida)	
24	24 stations	(Available up to 32 soleholds)	

Note 1) Double wiring: 2-position single, double, 3-position and 4-position valves can be used on all manifold stations.

Use of a 2-position single solenoid will result in an unused control signal. If this is not desired, order with a specified layout.

- Note 2) Specified layout: Indicate the wiring specifications on the manifold specification sheet. (Note that 2-position double, 3-position and 4-position valves cannot be used where single wiring has been specified.)
- Note 3) This also includes the number of blanking plate assembly.

P, E port entry, SUP/EXH block assembly

	Internal	Internal pilot,	External
	pilot	Built-in silencer	pilot
P, E port entry U side (2 to 10 stations)	U	С	G
P, E port entry D side (2 to 10 stations)	D	E	Н
P, E port entry both sides (2 to 24 stations)	В	F	J

* 3/5 (E) port is plugged for the built-in silencer type.

* When the built-in silencer type is used, keep the exhaust port from coming in direct contact with water or other liquids.

Refer to the page on the right for (8).

9 Mounting and Option

Symbol	Mounting	Option	
Nil	Direct mounting	None	
AA		Name plate (With station number)	
BA		Name plate (Without station number)	
D	DIN rail mounting	Without name plate	
A		Name plate (With station number)	
B		Name plate (Without station number)	

Note 1) Enter the number of valve stations into □ when being longer than the length of valve stations. (Refer to "DIN Rail Option" below.) Note 2) Only direct mounting is available for Type 11 (Bottom ported).

DIN Rail Option

@SMC

-		
Nil		Standard length
0		With bracket (without DIN rail)
3	For 3 stations	
:		Specify a longer rail than the standard length.
24	For 24 stations	

* When it is necessary to mount a DIN rail without an SI Unit, select D0 and order the DIN rail with required length separately by referring to L3 in the dimensions. (Refer to the SY3000/5000 series catalog (CAT.ES11-103) for the DIN rail part number.)

For Series EX600 Plug-in Connector Connecting Base Series SY3000/5000

Note) To avoid interference with the body or piping, select downward elbow when mounting the optional spacer assembly (SY3000/5000 series catalog (CAT.ES11-103)). * Indicate the sizes on the manifold specification sheet in the case of "CM" and "LM"

* The direction of P, E port fittings is the same as for A, B port. If selecting "LM", indicate it on the manifold specification sheet for the P, E port fitting direction.

Refer to the SY3000/5000 series catalog (CAT.ES11-103) for valve specifications. How to Order Valves (With two mounting screws)

SY 31	00		- <u>5</u>	1 -[₫
Series	Base mounted	6 Pilot	valve option	

6	Pil	ot	va	lve
---	-----	----	----	-----

3	SY3000
5	SY5000

2 Type of actuation

1	2-position single
2	2-position double
3	3-position closed center
4	3-position exhaust center
5	3-position pressure center
A *	4-position dual 3-port valve (N.C./N.C.)
B *	4-position dual 3-port valve (N.O./N.O.)
C *	4-position dual 3-port valve (N.C./N.O.)

* Only rubber seal type is available for 4-position dual 3-port valves.

Seal type

-	<i></i>
0	Rubber seal
1	Metal seal
	Ivietal seal

4 Pilot type

Nil	Internal pilot
R	External pilot

5 Bacl	c pressure check valve (Built-in valve type)
Nil	None
н	Built-in

- * Only rubber seal type. Manifold installed type is available if the back pressure check valve is required for a valve with metal seal, Refer to the SY3000/5000 series catalog (CAT.ES11-103) for details. However, it is not recommended to use the built-in valve type and the manifold installed type at the same time because it will reduce the flow
- * The built-in valve type back pressure check valve is not available for the 3-position type.

option

- Standard (0.7 MPa) Nil в Quick response type (0.7 MPa)
- K^{*} High pressure type (1.0 MPa)
- * Only metal seal type is available for the high pressure type.

Coil type

- Nil Standard With power saving circuit (Continuous duty type)
- * Be sure to select the power saving circuit type when the valve is continuously energized for long periods of time.
- * Note the specified energizing time when power saving circuit is selected. Refer to the SY3000/5000 series catalog (CAT.ES11-103) for details.

8 Rated voltage

24 VDC

9 Light/surge voltage suppressor and common specification

	-
R	With surge voltage suppressor (Non-polar)
U	With light/surge voltage suppressor (Non-polar)
S	With surge voltage suppressor (Positive common)
Z	With light/surge voltage suppressor (Positive common)
NS	With surge voltage suppressor (Negative common)
NZ	With light/surge voltage suppressor (Negative common)

- Select a valve from R, U, S or Z when the SI Unit output polarity is positive common. Select a valve from R, U, NS or NZ when the SI Unit output
- polarity is negative common. Only "Z" and "NZ" types are available for the product with power saving circuit.

Manual override

Type of mounting screw

Nil	Round head combination screw
в	Hexagon socket head cap screw
к	Round head combination screw (Falling-out-prevention type)
н	Hexagon socket head cap screw (Falling-out-prevention type)

- * For "K" and "H", the valve body cover has a drop prevention construction to stop the mounting screws from falling out when the valve is removed for maintenance etc.
- * When ordering a valve individually, the base gasket is not included. Since the base gasket is attached to the manifold, please order the base gasket separately if it is needed for maintenance service. Refer to the SY3000/5000 series catalog (CAT.ES11-103) for details.
- "B" and "H" cannot be selected for the individual SUP/EXH spacer assembly or double check spacer assembly with residual pressure release valve.

Series SY3000/5000

Dimensions: Type 10/For EX600 (M12 Connector)/Series SY3000

n1: Valve stations n2: I/O Unit stations

L3: DIN Rail Overall Length

Valve I/O stations Unit (n1) stations (n2)	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
0	185.5	198	210.5	223	223	235.5	248	260.5	273	285.5	285.5	298	310.5	323	335.5	348	348	360.5	373	385.5	398	410.5	423
1	235.5	248	248	260.5	273	285.5	298	310.5	323	323	335.5	348	360.5	373	385.5	385.5	398	410.5	423	435.5	448	448	460.5
2	285.5	285.5	298	310.5	323	335.5	348	348	360.5	373	385.5	398	410.5	410.5	423	435.5	448	460.5	473	485.5	485.5	498	510.5
3	323	335.5	348	360.5	373	385.5	385.5	398	410.5	423	435.5	448	448	460.5	473	485.5	498	510.5	510.5	523	535.5	548	560.5
4	373	385.5	398	410.5	410.5	423	435.5	448	460.5	473	473	485.5	498	510.5	523	535.5	548	548	560.5	573	585.5	598	610.5
5	423	435.5	448	448	460.5	473	485.5	498	510.5	510.5	523	535.5	548	560.5	573	573	585.5	598	610.5	623	635.5	635.5	648
6	473	473	485.5	498	510.5	523	535.5	535.5	548	560.5	573	585.5	598	610.5	610.5	623	635.5	648	660.5	673	673	685.5	698
7	510.5	523	535.5	548	560.5	573	573	585.5	598	610.5	623	635.5	635.5	648	660.5	673	685.5	698	698	710.5	723	735.5	748
8	560.5	573	585.5	598	598	610.5	623	635.5	648	660.5	673	673	685.5	698	710.5	723	735.5	735.5	748	760.5	773	785.5	798
9	610.5	623	635.5	635.5	648	660.5	673	685.5	698	698	710.5	723	735.5	748	760.5	760.5	773	785.5	798	810.5	823	835.5	835.5

SMC

For Series EX600 Plug-in Connector Connecting Base Series SY3000/5000

Valve I/O stations Unit (n1) stations (n2)	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
0	198	210.5	223	235.5	248	260.5	260.5	273	285.5	298	310.5	323	323	335.5	348	360.5	373	385.5	385.5	398	410.5	423	435.5
1	248	260.5	273	285.5	285.5	298	310.5	323	335.5	348	360.5	360.5	373	385.5	398	410.5	423	423	435.5	448	460.5	473	485.5
2	298	310.5	323	323	335.5	348	360.5	373	385.5	385.5	398	410.5	423	435.5	448	448	460.5	473	485.5	498	510.5	523	523
3	348	348	360.5	373	385.5	398	410.5	423	423	435.5	448	460.5	473	485.5	485.5	498	510.5	523	535.5	548	548	560.5	573
4	385.5	398	410.5	423	435.5	448	448	460.5	473	485.5	498	510.5	510.5	523	535.5	548	560.5	573	585.5	585.5	598	610.5	623
5	435.5	448	460.5	473	485.5	485.5	498	510.5	523	535.5	548	548	560.5	573	585.5	598	610.5	610.5	623	635.5	648	660.5	673
6	485.5	498	510.5	510.5	523	535.5	548	560.5	573	573	585.5	598	610.5	623	635.5	648	648	660.5	673	685.5	698	710.5	710.5
7	535.5	548	548	560.5	573	585.5	598	610.5	610.5	623	635.5	648	660.5	673	673	685.5	698	710.5	723	735.5	735.5	748	760.5
8	573	585.5	598	610.5	623	635.5	635.5	648	660.5	673	685.5	698	710.5	710.5	723	735.5	748	760.5	773	773	785.5	798	810.5
9	623	635.5	648	660.5	673	673	685.5	698	710.5	723	735.5	735.5	748	760.5	773	785.5	798	798	810.5	823	835.5	848	860.5

290

Series SY3000/5000

610.5 635.5

710.5

760.5 773 785.5 798 823 835.5 848 873 885.5 898 910.5 935.5

735.5

SMC

660.5 673

735.5 760.5 773 785.5 798 823 835.5 848 873 885.5

6

7

R

9

485.5 498 523 535.5 548 560.5 585.5 598 610.5 623 648 660.5 673 698 710.5 723 735.5 760.5 773 785.5 810.5 823 835.5

535.5

573 598 610.5 623 648 660.5 673 685.5 710.5

623 648 660.5 673 685.5 710.5 723 735.5 748 773 785.5 798 823 835.5 848 860.5 885.5 898 910.5 935.5 948 960.5 973

548

560.5 585.5 598 610.5 623 648 660.5 673 698

523

For Series EX600

 $L2 = 16 \times n1 + 48$ L4 = L3 - 10.5L5 = (L3 - L1)/2

Note 2) Refer to the SY3000/5000 series catalog (CAT.ES11-103) for dimensions of external pilot, silencer, elbow fittings and slide locking manual override. Note 3) Refer to the SY3000/5000 series catalog (CAT.ES11-103) for dimensions of A or B port top-ported type.

- L6 = 47 x n2 + 81.5
- n1: Valve stations
- n2: I/O Unit stations

1.2. DIN Bail Overall Length

		••••••																					
Valve I/O stations Unit (n1) stations (n2)	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
0	223	235.5	248	273	285.5	298	310.5	335.5	348	360.5	385.5	398	410.5	423	448	460.5	473	485.5	510.5	523	535.5	560.5	573
1	260.5	285.5	298	310.5	335.5	348	360.5	373	398	410.5	423	448	460.5	473	485.5	510.5	523	535.5	560.5	573	585.5	598	623
2	310.5	335.5	348	360.5	373	398	410.5	423	435.5	460.5	473	485.5	510.5	523	535.5	548	573	585.5	598	623	635.5	648	660.5
3	360.5	373	398	410.5	423	435.5	460.5	473	485.5	510.5	523	535.5	548	573	585.5	598	610.5	635.5	648	660.5	685.5	698	710.5
4	410.5	423	435.5	460.5	473	485.5	498	523	535.5	548	573	585.5	598	610.5	635.5	648	660.5	685.5	698	710.5	723	748	760.5
5	460.5	473	485.5	498	523	535.5	548	560.5	585.5	598	610.5	635.5	648	660.5	673	698	710.5	723	748	760.5	773	785.5	810.5
6	498	523	535.5	548	560.5	585.5	598	610.5	635.5	648	660.5	673	698	710.5	723	735.5	760.5	773	785.5	810.5	823	835.5	848
7	548	560.5	585.5	598	610.5	623	648	660.5	673	698	710.5	723	735.5	760.5	773	785.5	810.5	823	835.5	848	873	885.5	898
8	598	610.5	623	648	660.5	673	685.5	710.5	723	735.5	760.5	773	785.5	798	823	835.5	848	873	885.5	898	910.5	935.5	948
9	648	660.5	673	685.5	710.5	723	735.5	760.5	773	785.5	798	823	835.5	848	860.5	885.5	898	910.5	935.5	948	960.5	973	_

SMC

Type 12 Top Ported

RoHS For Series EX600 **Plug-in Connector Connecting Base** Series SY3000/5000

2

05

How to Order Manifold

Refer to the SY3000/5000 series catalog (CAT.ES11-103) for Type 12/Top ported dimensions.

Series

3	SY3000
5	SY5000

* For mixed mounting of the SY3000/5000 series, refer to "How to Order Manifold" (for plug-in mixed mounting) in the SY series catalog.

🛛 SI Unit

-	
0	Without SI Unit
Q	For DeviceNet [™]
N	For PROFIBUS DP
v	For CC-Link
ZE	For EtherNet/IP™
D	For EtherCAT
F	For PBOFINET

- Note 1) I/O Unit cannot be mounted without SI Unit
- Note 2) Valve Plate which connects manifold and SI Unit is not mounted to a valve without SI Unit, Refer to page 321 for mounting method.

How to Order Manifold Assembly

5 Valve stations SI Unit output polarity, End Plate type Power supply with M12 connector 7/8 inch connector SI Unit output polarity Without SI Unit Nil SI Unit Positive common 2 3

2

Note 2) Ensure a match with the common specifications of the value to be used.

SS5Y 3 - 12S6 Q

4 I/O Unit stations

Nil	None
1	1 station
:	
9	9 stations

Note 1) Without SI Unit, the symbol is nil.

Note 2) SI Unit is not included in I/O Unit stations. Note 3) When I/O Unit is selected, it is shipped

separately, and assembled by customer. Refer to the attached operation manual for mounting method.

Symbol	Stations	Note
02	2 stations	
:		Double wiring Note 1)
16	16 stations	
02	2 stations	Constituent Note 2)
:		(Available up to 22 colonaide)
24	24 stations	(Available up to 52 soleriolds)

Note 1) Double wiring: 2-position single, double, 3-position and 4-position valves can be used on all manifold stations

- Use of a 2-position single solenoid will result in an unused control signal. If this is not desired, order with a specified layout.
- Note 2) Specified layout: Indicate the wiring specifications on the manifold specification sheet. (Note that 2-position double, 3-position and 4-position valves cannot be used where single wiring has been specified.)
- Note 3) This also includes the number of blanking plate assembly.

6 P, E port entry, SUP/EXH block assembly

	Internal	Internal pilot,	External
	pilot	Built-in silencer	pilot
P, E port entry U side (2 to 10 stations)	U	C Note)	G
P, E port entry D side (2 to 10 stations)	D	E Note)	н
P, E port entry both sides (2 to 24 stations)	В		J

- For built-in silencer type, P and E ports are available on the U and D sides. 3/5(E) port is plugged. The silencer discharge port is located on the opposite side of P, E port entry. (Example: When the P, E port entry is D side, the silencer discharge port is U side.)
- * When the built-in silencer type is used, keep the exhaust port from coming in direct contact with water or other liquids.
- Note) For SUP/EXH block assembly specifications, built-in silencer types will have P port entry stipulated.

P, E port size touch fittings)

(One-touch hittings)						
Symbol	SY3000	SY5000				
Nil	ø8	ø10				
N	ø5/16"	ø3/8"				

* For N, sizes are in inches.

8 Mounting

Nil	Direct m	Direct mounting					
D	DIN rail	DIN rail mounting (With DIN rail)					
D0	DIN rail	mounting (Without DIN rail)					
D3	For 3 stations	Specify a longer rail than					
:		the standard length					
D24	For 24 stations	the standard length.					

* When it is necessary to mount a DIN rail without an SI unit, select D0 and order the DIN rail with required length separately by referring to L3 in the dimensions. (Refer to the SY3000/5000 series catalog (CAT.ES11-103) for the DIN rail part number.)

Refer to the catalog of each series for details on manifold solenoid valve specifications, Common Precautions and Specific Product Precautions.

Digital Output Unit Digital Input Unit 2-position single EX600-DXPD EX600-DYPB SY3130-5U1-C6 (3 sets) End Plate Note SI Unit No 2-position double EX600-ED2 EX600-SDN1A SY3230-5U1-C6 (2 sets) 00000 D side U side 1 2 3 4 5 --- Valve stations I/O Unit stations

SS5Y3-12S6Q42-05B ········ 1 set (Type 12 5-station manifold base part no.)
*SY3130-5U1-C6 3 sets (2-position single part no.)
*SY3230-5U1-C6 2 sets (2-position double part no.)
*EX600-DXPD 1 set I/O Unit part number (Station 1)
*EX600-DYPB 1 set I/O Unit part number (Station 2)
The asterisk denotes the symbol for assembly.
Prefix it to the part numbers of the solenoid valve, etc.

. The valve arrangement is numbered as the 1st station from the D side. . Under the manifold part number, state the valves to be mounted, then

the I/O Units in order from the 1st station as shown in the figure above If the arrangement becomes complicated, specify on a manifold specification sheet

Note) Do not enter the SI Unit part number and the End Plate part number together.

a)

6	s	er	ie	
	0	CI	10	- 3

	163
3	SY3000
5	SY5000

2 Type of actuation

_	
1	2-position single
2	2-position double
3	3-position closed center
4	3-position exhaust center
5	3-position pressure center
A *	4-position dual 3-port valve (N.C./N.C.)
B *	4-position dual 3-port valve (N.O./N.O.)
C*	4-position dual 3-port valve (N.C./N.O.)

* Only rubber seal type is available for 4-position dual 3-port valves.

Seal type

_	<i>,</i> ,
0	Rubber seal
1	Metal seal

Pilot type

Nil	Internal pilot
R	External pilot

Back pressure check valve

000	ok pressure eneek varve
Nil	None
н	Built-in

- * Only rubber seal type. Manifold installed type is available if the back pressure check valve is required for a valve with metal seal. Refer to the SY3000/5000 series catalog (CAT.ES11-103) for details. However, it is not recommended to use the built-in valve type and the manifold installed type at the same time because it will reduce the flow.
- * The built-in valve type back pressure check valve is not available for the 3-position type.

6 Pilot valve option

Nil	Standard (0.7 MPa)
В	Quick response type (0.7 MF

K High pressure type (1.0 MPa)

Only metal seal type is available for the high pressure type.

Coil type

Nil Standard

- With power saving circuit (Continuous duty type)
- Be sure to select the power saving circuit type when the valve is continuously energized for long periods of time.
- * Note the specified energizing time when power saving circuit is selected. Refer to the SY3000/5000 series catalog (CAT.ES11-103) for details.

24 VDC

Bated voltage

5

9 Light/surge voltage suppressor and common specification

R	With surge voltage suppressor (Non-polar)
U	With light/surge voltage suppressor (Non-polar)

- S With surge voltage suppressor (Positive common)
- NS
- NZ
- Select a valve from R. U. S or Z when the SI Unit output polarity is positive common. Select a valve from R. U. NS or NZ when the
- SI Unit output polarity is negative common. * Only "Z" and "NZ" types are available for the product with power saving circuit.

Manual override

A, B port size

Thread piping

Symbol	Port size	Applicable series
M5	M5 x 0.8	SY3000
01	1/8	SY5000

One-touch fitting (Metric)

Symbol	A, B port	SY3000	SY5000
C2	ø2 One-touch fitting	•	_
C3	ø3.2 One-touch fitting	•	_
C4	ø4 One-touch fitting	•	•
C6	ø6 One-touch fitting	•	•
C8	ø8 One-touch fitting	_	•

One-touch fitting (Inch)

Symbol	A, B port	SY3000	SY5000
N1	ø1/8" One-touch fitting	•	—
N3	ø5/32" One-touch fitting	•	
N7	ø1/4" One-touch fitting	•	•
N9	ø5/16" One-touch fitting	_	•

Thread type

_	
Nil	Rc
F	G
N	NPT
Т	NPTF

* Only Nil is available for M5.

Type of mounting screw

Nil	Round head combination screw
В	Hexagon socket head cap screw
к	Round head combination screw (Falling-out-prevention type)
н	Hexagon socket head cap screw (Falling-out-prevention type)

* For "K" and "H", the valve body cover has a drop prevention construction to stop the mounting screws from falling out when the valve is removed for maintenance etc.

- * When ordering a valve individually, the base gasket is not included. Since the base gasket is attached to the manifold, please order the base gasket separately if it is needed for maintenance service. Refer to the SY3000/5000 series catalog (CAT ES11-103) for details
- "B" and "H" cannot be selected for the individual SUP/EXH spacer assembly.

- With light/surge voltage suppressor (Positive common)
- With surge voltage suppressor (Negative common)
- With light/surge voltage suppressor (Negative common)

For Series EX600 ($\in \mathbb{R}^{1}$ is RoHS Series SV1000/2000/3000

When I/O Unit EX600-D E or EX600-D F are selected, enclosure is IP40. Refer to page 320 for details.

How to Order Manifold

In the case of mixed specifications (M), indicate separately on the manifold specification sheet

The X and PE port size of External pilot type (R), and X port size of External pilot, Built-in silencer type (RS) are ø4 (mm) or ø5/32" (inch) for the SV1000/2000 series, and ø6 (mm) or ø1/4" (inch) for the SV3000 series.

N11

М

ø3/8" One-touch fitting

A, B port mixed

C10

Μ

ø10 One-touch fitting

A, B port mixed

For Series EX600 Series SV

@SMC

L2 = L1 - 10.5
L3 = 10.5 x n1 + 53
L4 = L3 + 81 + 47 x n2
L5 = (L1 – L4)/2
L6 = 10.5 x n1 + 42
L7 = 47 x n2 + 81

n1: Valve stations n2: I/O Unit stations

L1: DIN Rail Overall Length

Valve VO stations Unit (n1) stations (n2)	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
0	185.5	198	210.5	210.5	223	235.5	248	260.5	273	273	285.5	298	310.5	323	335.5	348	348	360.5	373
1	235.5	248	248	260.5	273	285.5	298	310.5	310.5	323	335.5	348	360.5	373	373	385.5	398	410.5	423
2	273	285.5	298	310.5	323	335.5	335.5	348	360.5	373	385.5	398	410.5	410.5	423	435.5	448	460.5	473
3	323	335.5	348	360.5	373	373	385.5	398	410.5	423	435.5	435.5	448	460.5	473	485.5	498	498	510.5
4	373	385.5	398	398	410.5	423	435.5	448	460.5	473	473	485.5	498	510.5	523	535.5	535.5	548	560.5
5	423	435.5	435.5	448	460.5	473	485.5	498	498	510.5	523	535.5	548	560.5	560.5	573	585.5	598	610.5
6	460.5	473	485.5	498	510.5	523	535.5	535.5	548	560.5	573	585.5	598	598	610.5	623	635.5	648	660.5
7	510.5	523	535.5	548	560.5	560.5	573	585.5	598	610.5	623	623	635.5	648	660.5	673	685.5	698	698
8	560.5	573	585.5	598	598	610.5	623	635.5	648	660.5	660.5	673	685.5	698	710.5	723	723	735.5	748
9	610.5	623	623	635.5	648	660.5	673	685.5	685.5	698	710.5	723	735.5	748	760.5	760.5	773	785.5	798

SMC

5

6

7

8

9

435.5 448 460.5 473 473 485.5 498 510.5 523 535.5 535.5 548 560.5 573 585.5 598 598 610.5 623

485 5 498 498 510 5 523 535.5 548 560.5 573

535.5 535.5 548

573 585 5

623 635.5 648 660.5 660.5 673 685.5 698

560.5

610.5 623

598

573

585.5

635.5

598

635.5

For Series EX600 Series SV

INDEX

598 610.5 623

648 660.5 673

573

723 723 735.5 748

598

648

610.5 623 635.5 635.5 648 660.5 673 710.5

660.5

660.5

760.5

673

773

685.5 698

785.5

748 760 5

798

798

585.5

635.5

685.5 698 698 710.5 723 735.5 760.5 810.5 298

723

L2 = L1 - 10.5 L3 = 16 x n1 + 60
L4 = L3 + 81 + 47 x n2
L5 = (L1 - L4)/2
L6 = 16 x n1 + 48
L7 = 47 x n2 + 81.5
L

n1: Valve stations n2: I/O Unit stations

L1: DIN Rail Overall Length

Valve VO stations Unit (n1) stations (n2)	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
0	198	223	235.5	248	260.5	285.5	298	310.5	335.5	348	360.5	373	398	410.5	423	448	460.5	473	485.5
1	248	260.5	285.5	298	310.5	335.5	348	360.5	373	398	410.5	423	435.5	460.5	473	485.5	510.5	523	535.5
2	298	310.5	323	348	360.5	373	398	410.5	423	435.5	460.5	473	485.5	510.5	523	535.5	548	573	585.5
3	348	360.5	373	385.5	410.5	423	435.5	460.5	473	485.5	498	523	535.5	548	573	585.5	598	610.5	635.5
4	385.5	410.5	423	435.5	460.5	473	485.5	498	523	535.5	548	560.5	585.5	598	610.5	635.5	648	660.5	673
5	435.5	448	473	485.5	498	523	535.5	548	560.5	585.5	598	610.5	635.5	648	660.5	673	698	710.5	723
6	485.5	498	510.5	535.5	548	560.5	585.5	598	610.5	623	648	660.5	673	698	710.5	723	735.5	760.5	773
7	535.5	548	560.5	585.5	598	610.5	623	648	660.5	673	685.5	710.5	723	735.5	760.5	773	785.5	798	823
8	573	598	610.5	623	648	660.5	673	685.5	710.5	723	735.5	760.5	773	785.5	798	823	835.5	848	860.5
9	623	635.5	660.5	673	685.5	710.5	723	735.5	748	773	785.5	798	823	835.5	848	860.5	885.5	898	910.5

SMC

I/O stations Unit (n1) stations (n2)	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
0	223	235.5	248	273	285.5	298	310.5	335.5	348	360.5	373	398	410.5	423	448	460.5	473	485.5	510.5
1	260.5	285.5	298	310.5	335.5	348	360.5	373	398	410.5	423	448	460.5	473	485.5	510.5	523	535.5	548
2	310.5	323	348	360.5	373	398	410.5	423	435.5	460.5	473	485.5	510.5	523	535.5	548	573	585.5	598
3	360.5	373	398	410.5	423	435.5	460.5	473	485.5	498	523	535.5	548	573	585.5	598	610.5	635.5	648
4	410.5	423	435.5	460.5	473	485.5	498	523	535.5	548	573	585.5	598	610.5	635.5	648	660.5	673	698
5	448	473	485.5	498	523	535.5	548	560.5	585.5	598	610.5	635.5	648	660.5	673	698	710.5	723	748
6	498	523	535.5	548	560.5	585.5	598	610.5	623	648	660.5	673	698	710.5	723	735.5	760.5	773	785.5
7	548	560.5	585.5	598	610.5	623	648	660.5	673	698	710.5	723	735.5	760.5	773	785.5	798	823	835.5
8	598	610.5	623	648	660.5	673	685.5	710.5	723	735.5	760.5	773	785.5	798	823	835.5	848	873	885.5
9	648	660.5	673	685.5	710.5	723	735.5	748	773	785.5	798	823	835.5	848	860.5	885.5	898	910.5	935.5

INDEX

For Series EX600 Series SV

n2: I/O Unit stations

L1: DIN Rail Overall Length

Valve VO stations Unit (n1) stations (n2)	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
0	223	248	260.5	285.5	298	323	348	360.5	385.5	410.5	423	448	473	485.5	510.5	535.5	548	573	585.5
1	273	285.5	310.5	335.5	348	373	398	410.5	435.5	448	473	498	510.5	535.5	560.5	573	598	623	635.5
2	310.5	335.5	360.5	373	398	423	435.5	460.5	485.5	498	523	535.5	560.5	585.5	598	623	648	660.5	685.5
3	360.5	385.5	398	423	448	460.5	485.5	510.5	523	548	573	585.5	610.5	635.5	648	673	685.5	710.5	735.5
4	410.5	435.5	448	473	498	510.5	535.5	548	573	598	610.5	635.5	660.5	673	698	723	735.5	760.5	773
5	460.5	473	498	523	535.5	560.5	585.5	598	623	635.5	660.5	685.5	698	723	748	760.5	785.5	810.5	823
6	498	523	548	560.5	585.5	610.5	623	648	673	685.5	710.5	735.5	748	773	785.5	810.5	835.5	848	873
7	548	573	598	610.5	635.5	648	673	698	710.5	735.5	760.5	773	798	823	835.5	860.5	873	898	923
8	598	623	635.5	660.5	685.5	698	723	735.5	760.5	785.5	798	823	848	860.5	885.5	910.5	923	948	973
9	648	660.5	685.5	710.5	723	748	773	785.5	810.5	835.5	848	873	885.5	910.5	935.5	948	973	_	_

SMC

For Series EX600 Series SV

INDEX

735.5

710.5

748 773 798 810.5 835.5

848

723 748 760.5 785 5 810.5 823 848 873 885.5

860.5 885.5 910.5 923 948 973 985.5

5

6

7

8

9

473 498 510.5 535.5 560.5 573 598 623 635.5 660.5 673 698 723 735.5 760.5 785.5 798 823 848

523 535.5 560.5 585 5 598 623 648 660.5 685.5

573

610.5 635.5 660.5 673 698 723 735.5 760.5 773 798 823 835.5 860.5 885 5 898 923 948

660.5 685.5 698 723 748 760.5 785.5 810.5

585.5 610.5 648

673

623

685.5 710.5

302

898 910.5 935.5

> 960.5 985.5

860.5 873

For Series EX600 Series S0700 (E ROHS

How to Order Manifold

Kit type

S kit

specified.

How to Order Manifold Assembly

How to Order Valves

For Series EX600 Series S0700

VM XT34

Series S0700

Dimensions

L1: DIN Rail Overall Length

Valve VO stations Unit (n1) stations (n2)	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
0	173	185.5	185.5	198	210.5	210.5	223	235.5	235.5	248	260.5	260.5	273	285.5	285.5	298	310.5	310.5	323	335.5	335.5	348	360.5	373
1	223	223	235.5	248	248	260.5	273	273	285.5	298	298	310.5	323	323	335.5	348	360.5	360.5	373	385.5	385.5	398	410.5	410.5
2	260.5	273	285.5	285.5	298	310.5	310.5	323	335.5	348	348	360.5	373	373	385.5	398	398	410.5	423	423	435.5	448	448	460.5
3	310.5	323	335.5	335.5	348	360.5	360.5	373	385.5	385.5	398	410.5	410.5	423	435.5	435.5	448	460.5	460.5	473	485.5	485.5	498	510.5
4	360.5	373	373	385.5	398	398	410.5	423	423	435.5	448	448	460.5	473	473	485.5	498	498	510.5	523	535.5	535.5	548	560.5
5	410.5	410.5	423	435.5	435.5	448	460.5	460.5	473	485.5	485.5	498	510.5	523	523	535.5	548	548	560.5	573	573	585.5	598	598
6	448	460.5	473	473	485.5	498	510.5	510.5	523	535.5	535.5	548	560.5	560.5	573	585.5	585.5	598	610.5	610.5	623	635.5	635.5	648
7	498	510.5	523	523	535.5	548	548	560.5	573	573	585.5	598	598	610.5	623	623	635.5	648	648	660.5	673	673	685.5	698
8	548	560.5	560.5	573	585.5	585.5	598	610.5	610.5	623	635.5	635.5	648	660.5	660.5	673	685.5	698	698	710.5	723	723	735.5	748
9	598	598	610.5	623	623	635.5	648	648	660.5	673	685.5	685.5	698	710.5	710.5	723	735.5	735.5	748	760.5	760.5	773	785.5	785.5

SMC

L1: DIN Rail Overall Length

Dimensions

Valve VO stations Unit (n1) stations (n2)	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
0	185.5	198	210.5	210.5	223	235.5	235.5	248	260.5	260.5	273	285.5	285.5	298	310.5	310.5	323	335.5	335.5	348	360.5	360.5	373	385.5
1	235.5	248	248	260.5	273	273	285.5	298	298	310.5	323	323	335.5	348	348	360.5	373	385.5	385.5	398	410.5	410.5	423	435.5
2	285.5	285.5	298	310.5	310.5	323	335.5	335.5	348	360.5	373	373	385.5	398	398	410.5	423	423	435.5	448	448	460.5	473	473
3	323	335.5	348	360.5	360.5	373	385.5	385.5	398	410.5	410.5	423	435.5	435.5	448	460.5	460.5	473	485.5	485.5	498	510.5	510.5	523
4	373	385.5	398	398	410.5	423	423	435.5	448	448	460.5	473	473	485.5	498	498	510.5	523	523	535.5	548	560.5	560.5	573
5	423	435.5	435.5	448	460.5	460.5	473	485.5	485.5	498	510.5	510.5	523	535.5	548	548	560.5	573	573	585.5	598	598	610.5	623
6	473	473	485.5	498	498	510.5	523	535.5	535.5	548	560.5	560.5	573	585.5	585.5	598	610.5	610.5	623	635.5	635.5	648	660.5	660.5
7	523	523	535.5	548	548	560.5	573	573	585.5	598	598	610.5	623	623	635.5	648	648	660.5	673	673	685.5	698	698	710.5
8	560.5	573	585.5	585.5	598	610.5	610.5	623	635.5	635.5	648	660.5	660.5	673	685.5	685.5	698	710.5	723	723	735.5	748	748	760.5
9	610.5	623	623	635.5	648	648	660.5	673	673	685.5	698	710.5	710.5	723	735.5	735.5	748	760.5	760.5	773	785.5	785.5	798	810.5

For Series EX600 Series S0700

Directional Control Valves

SY

EX600

VM

XT34

For Series EX600 Series VQC1000

How to Order Manifold

Note) Without SI Unit, the symbol is nil.

@SMC

Precautions and Specific Product Precautions.

S kit

For Series EX600 Series VQC1000

@SMC

Series VQC1000

Dimensions

Power supply with M12 connector

L1: DIN Rail Overall Length

Valve VO stations Unit (n1) stations (n2)	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
0	198	198	210.5	223	235.5	248	260.5	260.5	273	285.5	298	310.5	323	335.5	335.5	348	360.5	373	385.5	398	398	410.5	423	435.5
1	235.5	248	260.5	273	285.5	298	298	310.5	323	335.5	348	360.5	360.5	373	385.5	398	410.5	423	423	435.5	448	460.5	473	485.5
2	285.5	298	310.5	323	323	335.5	348	360.5	373	385.5	398	398	410.5	423	435.5	448	460.5	460.5	473	485.5	498	510.5	523	523
3	335.5	348	360.5	360.5	373	385.5	398	410.5	423	423	435.5	448	460.5	473	485.5	485.5	498	510.5	523	535.5	548	560.5	560.5	573
4	385.5	385.5	398	410.5	423	435.5	448	460.5	460.5	473	485.5	498	510.5	523	523	535.5	548	560.5	573	585.5	585.5	598	610.5	623
5	423	435.5	448	460.5	473	485.5	485.5	498	510.5	523	535.5	548	548	560.5	573	585.5	598	610.5	623	623	635.5	648	660.5	673
6	473	485.5	498	510.5	523	523	535.5	548	560.5	573	585.5	585.5	598	610.5	623	635.5	648	648	660.5	673	685.5	698	710.5	710.5
7	523	535.5	548	548	560.5	573	585.5	598	610.5	610.5	623	635.5	648	660.5	673	685.5	685.5	698	710.5	723	735.5	748	748	760.5
8	573	585.5	585.5	598	610.5	623	635.5	648	648	660.5	673	685.5	698	710.5	710.5	723	735.5	748	760.5	773	773	785.5	798	810.5
9	610.5	623	635.5	648	660.5	673	673	685.5	698	710.5	723	735.5	748	748	760.5	773	785.5	798	810.5	810.5	823	835.5	848	860.5

SMC

$\begin{array}{c} L5 = (L1 - L4)/2 \\ L6 = 10.5 \times n1 + 45 \\ L7 = 47 \times n2 + 89.8 \end{array}$

n1: Valve stations n2: I/O Unit stations

L1: DIN Rail Overall Length

Valve VO stations Unit (n1) stations (n2)	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
0	210.5	223	235.5	235.5	248	260.5	273	285.5	298	298	310.5	323	335.5	348	360.5	373	373	385.5	398	410.5	423	435.5	435.5	448
1	260.5	273	273	285.5	298	310.5	323	335.5	335.5	348	360.5	373	385.5	398	398	410.5	423	435.5	448	460.5	460.5	473	485.5	498
2	298	310.5	323	335.5	348	360.5	360.5	373	385.5	398	410.5	423	435.5	435.5	448	460.5	473	485.5	498	498	510.5	523	535.5	548
3	348	360.5	373	385.5	398	398	410.5	423	435.5	448	460.5	460.5	473	485.5	498	510.5	523	523	535.5	548	560.5	573	585.5	598
4	398	410.5	423	423	435.5	448	460.5	473	485.5	498	498	510.5	523	535.5	548	560.5	560.5	573	585.5	598	610.5	623	623	635.5
5	448	460.5	460.5	473	485.5	498	510.5	523	523	535.5	548	560.5	573	585.5	585.5	598	610.5	623	635.5	648	660.5	660.5	673	685.5
6	485.5	498	510.5	523	535.5	548	560.5	560.5	573	585.5	598	610.5	623	623	635.5	648	660.5	673	685.5	685.5	698	710.5	723	735.5
7	535.5	548	560.5	573	585.5	585.5	598	610.5	623	635.5	648	648	660.5	673	685.5	698	710.5	723	723	735.5	748	760.5	773	785.5
8	585.5	598	610.5	623	623	635.5	648	660.5	673	685.5	685.5	698	710.5	723	735.5	748	748	760.5	773	785.5	798	810.5	810.5	823
9	635.5	648	648	660.5	673	685.5	698	710.5	710.5	723	735.5	748	760.5	773	785.5	785.5	798	810.5	823	835.5	848	848	860.5	873

For Series EX600 Series VQC1000

(E RoHS For Series EX600 Series VQC2000

How to Order Manifold

NII	No End Plate
2	Power supply with M12 connector (Max. supplied current 2 A)
3	Power supply with 7/8 inch connector (Max. supplied current 8 A)
te) Witl	hout SI Unit, the symbol is nil.

@SMC

Nr

Kit type

S kit

For Series EX600 Series VQC2000

Coil voltage

Refer to the catalog of each series for details on manifold solenoid valve specifications, Common Precautions and Specific Product Precautions.

Series VQC2000

Dimensions

Power supply with M12 connector

n1: Valve stations n2: I/O Unit stations

L1: DIN Rail Overall Length

Valve VO stations Unit (n1) stations (n2)	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
0	210.5	223	235.5	260.5	273	285.5	298	323	335.5	348	373	385.5	398	410.5	435.5	448	460.5	473	498	510.5	523	548	560.5	573
1	248	273	285.5	298	323	335.5	348	360.5	385.5	398	410.5	435.5	448	460.5	473	498	510.5	523	548	560.5	573	585.5	610.5	623
2	298	323	335.5	348	360.5	385.5	398	410.5	423	448	460.5	473	498	510.5	523	535.5	560.5	573	585.5	610.5	623	635.5	648	673
3	348	360.5	385.5	398	410.5	423	448	460.5	473	498	510.5	523	535.5	560.5	573	585.5	598	623	635.5	648	673	685.5	698	710.5
4	398	410.5	423	448	460.5	473	485.5	510.5	523	535.5	560.5	573	585.5	598	623	635.5	648	673	685.5	698	710.5	735.5	748	760.5
5	448	460.5	473	485.5	510.5	523	535.5	548	573	585.5	598	623	635.5	648	660.5	685.5	698	710.5	735.5	748	760.5	773	798	810.5
6	485.5	510.5	523	535.5	548	573	585.5	598	623	635.5	648	660.5	685.5	698	710.5	723	748	760.5	773	798	810.5	823	835.5	860.5
7	535.5	548	573	585.5	598	610.5	635.5	648	660.5	685.5	698	710.5	723	748	760.5	773	798	810.5	823	835.5	860.5	873	885.5	898
8	585.5	598	610.5	635.5	648	660.5	673	698	710.5	723	748	760.5	773	785.5	810.5	823	835.5	860.5	873	885.5	898	923	935.5	948
9	635.5	648	660.5	673	698	710.5	723	748	760.5	773	785.5	810.5	823	835.5	848	873	885.5	898	923	935.5	948	960.5	985.5	985.5

For Series EX600 Series VQC2000

Dimensions

n1: Valve stations n2: I/O Unit stations

L1: DIN Rail Overall Length

Valve VO stations Unit (n1) stations (n2)	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
0	223	235.5	260.5	273	285.5	298	323	335.5	348	373	385.5	398	410.5	435.5	448	460.5	485.5	498	510.5	523	548	560.5	573	585.5
1	273	285.5	298	323	335.5	348	360.5	385.5	398	410.5	435.5	448	460.5	473	498	510.5	523	548	560.5	573	585.5	610.5	623	635.5
2	323	335.5	348	360.5	385.5	398	410.5	435.5	448	460.5	473	498	510.5	523	535.5	560.5	573	585.5	610.5	623	635.5	648	673	685.5
3	360.5	385.5	398	410.5	423	448	460.5	473	498	510.5	523	535.5	560.5	573	585.5	610.5	623	635.5	648	673	685.5	698	710.5	735.5
4	410.5	423	448	460.5	473	485.5	510.5	523	535.5	560.5	573	585.5	598	623	635.5	648	673	685.5	698	710.5	735.5	748	760.5	785.5
5	460.5	473	485.5	510.5	523	535.5	560.5	573	585.5	598	623	635.5	648	660.5	685.5	698	710.5	735.5	748	760.5	773	798	810.5	823
6	510.5	523	535.5	548	573	585.5	598	623	635.5	648	660.5	685.5	698	710.5	735.5	748	760.5	773	798	810.5	823	835.5	860.5	873
7	548	573	585.5	598	610.5	635.5	648	660.5	685.5	698	710.5	723	748	760.5	773	798	810.5	823	835.5	860.5	873	885.5	910.5	923
8	598	610.5	635.5	648	660.5	685.5	698	710.5	723	748	760.5	773	785.5	810.5	823	835.5	860.5	873	885.5	898	923	935.5	948	973
9	648	660.5	673	698	710.5	723	748	760.5	773	785.5	810.5	823	835.5	860.5	873	885.5	898	923	935.5	948	960.5	985.5	985.5	—

SMC

MA Directional Control Valves

XT34

For Series EX600 Series VQC4000

How to Order Manifold

Note) Without SI Unit, the symbol is nil

Note) The maximum number of stations depends on the number of solenoids Add the option symbol "-K" when the combination of single wiring and double wiring is specified.

stations

16 stations

. When "Without SI Unit" is specified, I/O Unit cannot be mounted.

For EtherCAT

For PROFINET

SD6ZE For EtherNet/IP™

SD6D

SD6F

. When "Without SI Unit" is specified, Valve Plate to connect the manifold and SI Unit is not mounted. Refer to page 321 for mounting method.

Refer to the catalog of each series for details on manifold solenoid valve specifications, Common Precautions and Specific Product Precautions.

For Series EX600 Series VQC4000

Series VQC4000

Dimensions

Power supply with M12 connector

Formulas

L1 = 25n + 106L2 = 25n + 184

* L2 is the dimension without I/O Unit. Add 47 mm for each additional I/O Units. * "m" is number of I/O Units.

Dime	ension	s										n	: Station	s (Maxir	num 16	stations)
\sum	n 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16															16
L1	131	156	181	206	231	256	281	306	331	356	381	406	431	456	481	506
L2	209	234	259	284	309	334	359	384	409	434	459	484	509	534	559	584

For Series EX600 Series VQC4000

Dimensions

Formulas

L1 = 25n + 106

12 = 25n + 184

* L2 is the dimension without I/O Unit. Add 47 mm for each additional I/O Units. * "m" is number of I/O Units.

Dimensions n: Stations (Maximum 16 statio														stations)		
\sim	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	131	156	181	206	231	256	281	306	331	356	381	406	431	456	481	506
L2	209	234	259	284	309	334	359	384	409	434	459	484	509	534	559	584

VM

Series EX600 Specific Product Precautions 1

Be sure to read this before handling. Refer to page 1574 cover for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" for 3/4/5 Port Solenoid Valve Precautions. The Operation Manual can be downloaded from the SMC website, http://www.smcworld.com

Design/Selection

MWarning

- Use this product within the specification range. Using beyond the specifications range can cause fire, malfunction, or damage to the system. Check the specifications before operation.
- 2. When using for an interlock circuit:
 - Provide a multiple interlock system which is operated by another system (such as mechanical protection function).
 - Perform an inspection to confirm that it is working properly.

This may cause possible injury due to malfunction.

- When applicable to UL, use a Class 2 power supply unit conforming to UL1310 for direct current power supply.
- Use this product within the specified voltage range. Using beyond the specified voltage range is likely to cause the units and connecting devices to be damaged or to malfunction.
- The power supply for the unit should be 0 V as the standard for both power supply for output as well as power supply for control/input.

4. Do not install a unit in a place where it can be used as a foothold.

Applying any excessive load such as stepping on the unit by mistake or placing a foot on it, will cause it to break.

- 5. Keep the surrounding space free for maintenance. When designing a system, take into consideration the amount of free space needed for performing maintenance.
- 6. Do not remove the name plate.

Improper maintenance or incorrect use of operation manual can cause failure and malfunction. Also, there is a risk of losing conformity with safety standards.

7. Beware of inrush current when the power supply is turned on.

Some connected loads can apply an initial charge current which will trigger the over current protection function, causing the unit to malfunction.

Mounting

1. When handling and assembling units:

- Do not touch the sharp metal parts of the connector or plug.
- Do not apply excessive force to the unit when disassembling.

The connecting portions of the unit are firmly joined with seals.

 When joining units, take care not to get fingers caught between units. Injury can result. Mounting

≜Caution

2. Do not drop, bump, or apply excessive impact.

Otherwise, the unit can become damaged, malfunction, or fail to function.

3. Observe the tightening torque range.

Tightening outside of the allowable torque range will likely damage the screw.

IP67 cannot be guaranteed if the screws are not tightened to the specified torque.

 When lifting a large size manifold solenoid valve unit, take care to avoid causing stress to the valve connection joint.

The connection parts of the unit may be damaged. Because the unit may be heavy, carrying and installation should be performed by more than one operator to avoid strain or injury.

 When placing a manifold, mount it on a flat surface. Torsion in the whole manifold can lead to trouble such as air leakage or defective insulation.

Wiring

 Check the grounding to maintain the safety of the reduced wiring system and to improve the noise immunity.

Provide a specific grounding as close to the unit as possible to minimize the distance to grounding.

2. Avoid repeatedly bending or stretching the cable and applying a heavy object or force to it.

Wiring applying repeated bending and tensile stress to the cable can break the circuit.

3. Avoid miswiring.

If miswired, there is a danger of malfunction or damage to the reduced wiring system.

4. Do not wire while energizing the product.

There is a danger of malfunction or damage to the reduced wiring system or input/output device.

5. Avoid wiring the power line and high pressure line in parallel.

Noise or surge produced by signal line resulting from the power line or high pressure line could cause malfunction. Wiring of the reduced wiring system or input/output device and the power line or high pressure line should be separated from each other.

6. Check the wiring insulation.

Defective insulation (contact with other circuits, improper insulation between terminals, etc.) may cause damage to the reduced wiring system or input/output device due to excessive voltage or current.

Series EX600 Specific Product Precautions 2

Be sure to read this before handling. Refer to page 1574 cover for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" for 3/4/5 Port Solenoid Valve Precautions. The Operation Manual can be downloaded from the SMC website, http://www.smcworld.com

XT34

Wiring

ACaution

- When a reduced wiring system is installed in machinery/equipment, provide adequate protection against noise by using noise filters, etc.
 Noise in signal lines may cause malfunction.
- When connecting wires of input/output device or Handheld Terminal, prevent water, solvent or oil from entering inside from the connecter section.
 This can cause damage, equipment failure or malfunction.
- 9. Avoid wiring patterns in which excessive stress is applied to the connector.

This may cause malfunction or damage to the unit due to contact failure.

Operating Environment

MWarning

1. Do not use in an atmosphere containing an inflammable gas or explosive gas.

Use in such an atmosphere is likely to cause a fire or explosion. This system is not explosion-proof.

▲Caution

1. Select the proper type of enclosure according to the environment of operation.

IP65/67 is achieved when the following conditions are met.

- Provide appropriate wiring between all units using electrical wiring cables, communication connectors and cables with M12 connectors.
- 2) Suitable mounting of each unit and manifold valve.
- 3) Be sure to mount a seal cap on any unused connectors.

If using in an environment that is exposed to water splashes, please take measures such as using a cover.

When the enclosure is IP40, do not use in an operating environment or atmosphere where it may come in contact with corrosive gas, chemical agents, seawater, water, or water vapor. When connected to the EX600-DDDE or EX600-DDDF, manifold enclosure is IP40.

Also, the Handheld Terminal conforms to IP20, so prevent foreign matter from entering inside, and water, solvent or oil from coming in direct contact with it.

2. Provide adequate protection when operating in locations such as the following.

Failure to do so may cause damage or malfunction. The effect of countermeasures should be checked in individual equipment and machine.

- 1) Where noise is generated by static electricity, etc.
- 2) Where there is a strong electric field
- 3) Where there is a danger of exposure to radiation
- 4) When in close proximity to power supply lines

Operating Environment

▲Caution

3. Do not use in an environment where oil and chemicals are used.

Operating in environments with coolants, cleaning solvents, various oils or chemicals may cause adverse effects (damage, malfunction) to the unit even in a short period of time.

 Do not use in an environment where the product could be exposed to corrosive gas or liquid.

This may damage the unit and cause it to malfunction.

5. Do not use in locations with sources of surge generation.

Installation of the unit in an area around the equipment (electromagnetic lifters, high frequency induction furnaces, welding machine, motors, etc.), which generates the large surge voltage could cause to deteriorate an internal circuitry element of the unit or result in damage. Implement countermeasures against the surge from the generating source, and avoid touching the lines with each other.

Use the product type that has an integrated surge absorption element when directly driving a load which generates surge voltage by relay, solenoid valves or lamp.

When a surge generating load is directly driven, the unit may be damaged.

- The product is CE marked, but not immune to lightning strikes. Take measures against lightning strikes in your system.
- 8. Keep dust, wire scraps and other foreign matter from entering inside the product.

This may cause malfunction or damage.

9. Mount the unit in such locations, where no vibration or shock is affected.

This may cause malfunction or damage.

10. Do not use in places where there are cyclic temperature changes.

In case that the cyclic temperature is beyond normal temperature changes, the internal unit is likely to be adversely affected.

- Do not use in direct sunlight. Do not use in direct sunlight. It may cause malfunction or damage.
- 12. Use this product within the specified ambient temperature range.

This may cause malfunction.

13.Do not use in places where there is radiated heat around it.

Such a place is likely to cause malfunction.

Series EX600 Specific Product Precautions 3

Be sure to read this before handling. Refer to page 1574 cover for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" for 3/4/5 Port Solenoid Valve Precautions. The Operation Manual can be downloaded from the SMC website, http://www.smcworld.com

Adjustment/Operation

Warning

1. Do not perform operation or setting with wet hands. There is a risk of electrical shock.

<Handheld Terminal>

- Do not apply pressure to the LCD. There is a possibility of the crack of LCD and injuring.
- The forced input/output function is used to change the signal status forcibly. When operating this function, be sure to check the safety of the surroundings and installation.

Otherwise, injury or equipment damage could result.

 Incorrect setting of parameters can cause malfunction. Be sure to check the settings before use. This may cause injury or equipment damage.

≜Caution

 Use a watchmakers' screwdriver with thin blade for the setting of each switch of the SI Unit.
 When setting the switch, do not touch other unrelated parts.

This may cause parts damage or malfunction due to a short circuit.

2. Provide adequate setting for the operating conditions. Failure to do so could result in malfunction.

Refer to the operation manual for setting of the switches.

 For details on programming and address setting, refer to the manual from the PLC manufacturer. The content of programming related to protocol is designed by

the manufacturer of the PLC used.

<Handheld Terminal>

4. Do not press the setting buttons with a sharp pointed object.

This may cause damage or malfunction.

5. Do not apply excessive load and impact to the setting buttons.

This may cause damage, equipment failure or malfunction.

When the order does not include the SI Unit, the Valve Plate to connect the manifold and SI Unit is not mounted. Use attached valve fixing screws and mount the Valve Plate. (Tightening torque: 0.6 to 0.7 N·m)

Maintenance

≜ Warning

1. Do not disassemble, modify (including circuit board replacement) or repair this product.

Such actions are likely to cause injuries or breakage.

- 2. When an inspection is performed,
 - · Turn off the power supply.
 - Stop the air supply, exhaust the residual pressure in piping and verify that the air is released before performing maintenance work.

Unexpected malfunction of system components and injury can result.

A Caution

- 1. When handling and replacing the unit:
 - Do not touch the sharp metal parts of the connector or plug.
 - Do not apply excessive force to the unit when disassembling.

The connecting portions of the unit are firmly joined with seals.

 When joining units, take care not to get fingers caught between units. Injury can result.

2. Perform periodic inspection.

Unexpected malfunction in the system composition devices is likely to occur due to malfunction of machinery or equipment.

After maintenance, make sure to perform an appropriate functionality inspection.

In cases of abnormality such as faulty operation, stop operation. Unexpected malfunction in the system composition devices is likely to occur.

4. Do not use benzine and thinner for cleaning units.

Damage to the surface or erasure of the display can result. Wipe off any stains with a soft cloth.

If the stain is persistent, wipe off with a cloth soaked in a dilute solution of neutral detergent and wrung out tightly, and then finish with a dry cloth.

Other

▲Caution

1. Refer to the catalog of each series for Common Precautions and Specific Product Precautions on manifold solenoid valves.

Trademark

DeviceNet[™] is a trademark of ODVA.

EtherNet/IP™ is a trademark of ODVA.

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

