Sine Rodless Cylinder

Series REA/REB

(Maximum speed: 300 mm/s) (Maximum speed: 600 mm/s)



Series REA (300 mm/s)

Guide type	Model	Page
Basic type	REA	P. 931
Direct mount type	reaR	P. 939
Slider type (Slide bearing)	REAS	P. 951
Slider type (Ball bushing bearing)	REAL	P. 965
Linear guide type (Single axis)	REAH	P. 979
Linear guide type (Double axis)	REAHT	P. 979

Series REB (600 mm/s)

Guide type	Model		Page
			_
Direct mount type	REBR	_	P. 995
Linear quide type			
(Single axis)	REBH		P. 1007
Linear guide type	DEDHT		D 1007
(Double axis)	REBUI		P. 1007

REA
REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

D- □
-X □
Individual -X□

Semiconductor wafers • Liquid crystal substrates Magnetic disks • Ceramic products Glass products

Smooth acceleration & deceleration at 5

Allows rapid transfer of impact

1

Throughput dramatically increased (Maximum speed: **600** mm/s)

Series REB introduced with a maximum speed of 600 mm/s. Compared with the previous type (Series REA: 300 mm/s), the tact time can be shortened by approximately 1/2.



Cushion ring

The exterior of the cushion ring is provided with a variable throttle groove in its longitudinal direction.



Series Variations ——— Series REA (300 mm/s)

Guide type	Base cylinder	Model
Basic type	CY3B	REA
Direct mount type	CY3R	REAR
Slider type (Slide bearing)	CY1S	REAS
Slider type (Ball bushing bearing)	CY1L	REAL
Linear guide type (Single axis)	CY1H	REAH
Linear guide type (Double axis)	CY1HT	REAHT



sensitive workpieces













REA

Series REA/REAR/REBR/REAS/REAL/REAH/REBH Model Selection Criteria

Madel Coloction Oritoria		Reco	mmended Cylinder	
Model Selection Criteria	Appearance			Features
 When many different types of guides are used When a long stroke is necessary 	ated type	Series REA Size: ø25, ø32, ø40, ø50, ø63	• Wide variations from ø25 to ø63.	• Long strokes available.
 When many different types of guides are used When auto switches are added to the basic style When used without a guide for a light load When space is very limited 	Guide non-integra	Series REAR Size: 010, 015, 020, 025, 032, 040 Series REBR Size: 015, 025, 032	• Choice of the maximum speed of 300 mm/s or 600 mm/s is available.	 Cylinder can be directly mounted. Auto switch capable, with no cylinder lurching. Rotation can be stopped within an allowable range. Compact external dimensions Mounting can be performed from the top or one side.
 To ensure a permanent path When used for general transfer operations 		Series REAS Size: 010, 015, 020, 025, 032, 040	• A load can be carried	 Smooth operation is made possible by using special slide bearings.
 To ensure a permanent path When smoother operation is required, even with an offset load 	Guide integrated type	Series REAL Size: 010, 015, 020, 025, 032, 040	 The centralized piping type allows concentration of piping on one side plate. Auto switch capable. Choice of the maximum speed of 300 mm/s or 600 mm/s is available. (RE□H/Linear guide type) 	 Stable operation is possible, even with an offset load, by using ball bushings.
 To ensure a permanent path When a large load, large moment is required When used for pick-and-place operations, etc. 		Series REAH Size: 010, 015, 020, 025, 032 Series REBH Size: 015, 025, 032		 The use of a linear guide facilitates a large load, large moment. Mounting freedom is improved by providing T-slots on the mounting surfaces. A top cover mounted over the sliding parts of the cylinder prevents scratches and damage, etc.



Series REA/REB Specific Product Precautions

Be sure to read before handling. Refer to front matters 42 and 43 for Safety Instructions and pages 3 to 11 for Actuator and Auto Switch Precautions.

Disassembly and Maintenance

A Warning

1. Use caution as the attractive force of the magnets is very strong.

When removing the external slider and piston slider from the cylinder tube for maintenance, etc., handle with caution, since the magnets installed in each slider have a very strong attractive force.

ACaution

1. Use caution when removing the external slider, as the piston slider will be directly attracted to it.

When removing the external slider or piston slider from the cylinder tube, first force the sliders out of their magnetically coupled positions, and then remove them individually when there is no longer any holding force. If they are removed while still magnetically coupled, they will be directly attracted to one another and will not come apart.

2. Do not disassemble the magnetic components (piston slider, external slider).

This can cause a loss of holding force and malfunction.

- 3. When disassembling to replace the seals and wear ring, refer to the separate disassembly instructions.
- 4. Use caution to the direction of the external slider and the piston slider.

Since the external slider and piston slider are directional for size ø10, refer to the figures below when performing disassembly or maintenance. Put the external slider and piston slider together, and insert the piston slider into the cylinder tube so that they will have the correct positional relationship as shown in Fig. (1). If they align as shown in Fig. (2), reinsert the piston slider only, after turning it around 180°. If the direction is not correct, it will be impossible to obtain the specified holding force.





Fig. (1) Correct position

Fig. (2) Incorrect position

5. During disassembly, use caution in handling the cushion ring.

The cushion ring is a precision part, and any deformation, etc., can cause malfunction or poor performance.

Speed Adjustment

▲ Caution

1. SMC's "throttle" type speed controllers (Series AS) are recommended for speed adjustment. (Refer to Table (3).)

Table (3) Recommended Speed Controller

Bore size	Model		
(mm)	Elbow type	Straight type	In-line type
10	AS1201F-M5-04-X214	AS1301F-M5-04-X214	AS1001F-04-X214
15	AS1201F-M5-04-X214	AS1301F-M5-04-X214	AS1001F-04-X214
20	AS2201F-01-06-X214	AS2301F-01-06-X214	AS2001F-06-X214
25	AS2201F-01-06-X214	AS2301F-01-06-X214	AS2001F-06-X214
32	AS2201F-01-06-X214	AS2301F-01-06-X214	AS2001F-06-X214
40	AS2201F-02-06-X214	AS2301F-02-06-X214	AS2001F-06-X214
50	AS3201F-02-08-X214	AS3301F-02-08-X214	AS3001F-08-X214
63	AS3201F-02-08-X214	AS3301F-02-08-X214	AS3001F-08-X214

- **2.** Speed adjustment is possible with meter-in/meter-out type speed controllers, but it may not be possible to obtain the cushion effect (smooth start-up, soft stop).
- **3.** In the case of other than horizontal mounting, it is recommended that the system have a reduced pressure supply circuit installed at its lower side. (This is also effective as a countermeasure against start-up delay on an upward stroke, and for air conservation.)



Lower-side reduced pressure supply circuit

Adjustment of Cushion Effect (Smooth start-up, Soft stop)

▲ Caution

1. The cushion cannot be adjusted.

There is no cushion needle adjustment of the kind found on conventional cushion mechanisms.



REA



Basic Type

Series **REA**

ø25, ø32, ø40, ø50, ø63



REA
REB
REC
C Y
C 🗆 X
MQ
RHC
RZQ

D- □
-X □
Individual -X□





多SMC

Caution on Design 1

Selection Method

Selection Procedures

- 1. Find the drive resisting force Fn (N) when moving the load horizontally.
- 2. Find the distance Lo (cm) from the point of the load where driving force is applied, to the center of the cylinder shaft.
- 3. Select a bore size from Lo and Fn in Data (A).



Selection Example

Given a load drive resisting force of Fn = 100 (N) and a distance from the cylinder shaft center to the load application point of Lo = 8 cm, find the intersection point by extending upward from the horizontal axis of data (A) where the distance from the shaft center is 8 cm, and then extending to the side, find the allowable driving force on the vertical axis. Models suitable to satisfy the requirement of 100 (N) are REA32 or REA40.

* Distance from cylinder shaft center, Lo, is the moment working point between the cylinder and the load.



-oad mass W (kg)

Caution on Design 2

Cylinder Self-weight Deflection

When the cylinder is mounted horizontally, deflection appears due to its own weight as shown in the data, and the longer the stroke the greater the amount of variation in the shaft centers. A connection method as shown in the figure should be considered to allow for this deflection.



The above clearance is for reference.

Note) Referring to the self-weight deflection in the graph below, provide clearance so that the cylinder does not touch the mounting surface or the load section, and is able to operate smoothly within the minimum operating pressure range for a full stroke.



REA (Basic type) is not directly connected to the load, and is guided by another shaft (LM guide, etc.). Load connection fittings should be designed so that they do not exceed the mass given in the table below.

Maximum Connection Fitting Mass WBmax (kg)
--

Model	Maximum load (kg)	
REA25	1.2	
REA32	1.5	
REA40	2.0	
REA50	2.5	
REA63	3.0	

* When loading the mass exceeding the above values, please consult with SMC.

Vertical Operation

The load should be guided by a ball type bearing (Linear guide, etc.). If a slide bearing is used, sliding resistance increases due to the load mass and load moment, which can cause malfunction. When the cylinder is mounted vertically or sidelong, sliders may move downwards due to the self-weight or workpiece mass. If an accurate stopping position is required at the stroke end or the middle-stroke, use an external stopper to secure accurate positioning.

Intermediate Stop

The cushion effect (smooth start-up, soft stop) exists only before the stroke end in the stroke ranges indicated in the table below.

The cushion effect (smooth start-up, soft stop) cannot be obtained in an intermediate stop or a return from an intermediate stop using an external stopper, etc.

Cushion Stroke

Model	Stroke (mm)	
REA25	30	
REA32	30	
REA40	35	
REA50	40	
REA63	40	



* The above deflection data indicate values for external movement within the stroke.



Model	Allowable load mass Wv (kg)	Maximum operating pressure Pv (MPa)					
REA25	18.5	0.65					
REA32	30.0	0.65					
REA40	47.0	0.65					
REA50	75.0	0.65					
REA63	115.0	0.65					

Note) Use caution, since the magnetic coupling may be dislocated if it is used over the maximum operating pressure.

Sine Rodless Cylinder/Basic Type Series REA ø25, ø32, ø40, ø50, ø63

How to Order **REA** 25 Basic type 300 Made to Order Sine rodless cylinder Refer to the table below (Basic type) for details. Stroke (mm) Bore size Refer to "Standard Stroke" below. 25 25 mm Port thread type 32 32 mm 40 Symbol Type Bore size 40 mm Nil Rc 25, 32, 40 50 50 mm

63

63 mm

Specifications

				1				
Bore size (mm)	25	32	40	50	63			
Fluid	Air							
Proof pressure	1.05 MPa							
Maximum operating pressure	0.7 MPa							
Minimum operating pressure	0.18 MPa							
Ambient and fluid temperature		-10 to	o 60°C (No fi	reezing)				
Piston speed (Max.) Note)		5	50 to 300 mn	n/s				
Lubrication	Not required (Non-lube)							
Stroke length tolerance	0 to 250 st: ⁺¹ ₀ , 251 to 100 st: ^{+1.4} ₀ , 1001 st or longer: ^{+1.8} ₀							
Holding force	363	588	922	1,470	2,260			

NPT

G

50, 63

32, 50, 63

ΤN

TF





(For details, refer to pages 1851 to 1954.) Specifications Symbol -XB11 Long stroke type

—XC24	With magnet shielding plate
—XC57	With floating joint
—X206	Additional moving element mounting taps
—X210	Non-lubricated exterior specifications
—X324	Non-lubricated exterior specifications with dust seal
—X168	Helical insert thread specifications

Refer to "Pneumatic Clean Series" catalog for clean room specifications.

Note) Piston speed above indicates the maximum speed. It takes approximately 0.5 seconds (for one side) after the body moves from the stroke end until it goes through the cushion stroke, while it takes approximately 1 second for both sides

Standard Stroke

			- It	
Bore size (mm)	Standard stroke (mm)	Maximum manufacturable stroke (mm)		
25	200, 250, 300, 350, 400, 450, 500, 600, 700, 800	4000		
32	200, 250, 300, 350, 400, 450, 500, 600, 700, 800	4000		
40	200, 250, 300, 350, 400, 450, 500, 600, 700, 800, 900, 1000	5000		
50	200, 250, 300, 350, 400, 450, 500, 600, 700, 800, 900, 1000	c000	ľ	
63	200, 250, 300, 350, 400, 450, 500, 600, 700, 800, 900, 1000	6000	F	
Ninte d'Alerte	una eliete studio in considerate los tras de seus internal			

Note 1) Intermediate stroke is available by the 1 mm interval.

Note 2) Strokes over 2000 mm are available as made-to-order. (Refer to -XB11.)

Mass

					(kg)			
Bore size (mm)	25	32	40	50	63	ם-ע		
Basic mass	0.71	1.34	2.15	3.4	5.7	-X□		
Additional mass per each 50 mm of stroke	0.05	0.07	0.08	0.095	0.12	leuhividual		
Calculation: (Example) REA32-500 • Basic mass								

• Additional mass0.07 (kg/50 st) 1.34 + 0.07 x 500 ÷ 50 = 2.04 kg

Cylinder stroke500 (st)



Series REA

Construction



Component Parts

No.	Description	Material	Note
1	Body	Aluminum alloy	Anodized
2	Head cover	Aluminum alloy	Anodized
3	Cushion ring holder	Aluminum alloy	Chromated
4	Cylinder tube	Stainless steel	
5	Piston	Aluminum alloy	Chromated
6	Shaft	Stainless steel	
7	Lock nut B	Carbon steel	Nickel plated
8	Piston side yoke	Rolled steel plate	Zinc chromated
9	External slider side yoke	Rolled steel plate	Zinc chromated
10	Magnet A	—	

Component Parts

	=		
No.	Description	Material	Note
11	Magnet B	—	
12	Bumper	Urethane rubber	
13	Cushion seal holder	Aluminum alloy	Chromated
14	Cushion ring	Brass	Electroless nickel plated
15	Adjusting screw	Carbon steel	Nickel plated
16	Stopper bolt	Carbon steel	Nickel plated
17	Lock nut A	Carbon steel	Nickel plated
18	Retaining ring	Carbon tool steel	
19	Spring washer	Steel wire	

Working principle



Start-up/Acceleration

The driving air from the cylinder port passes through the inside of the cushion ring, and flows into the left chamber of the drive piston from the clearance between the cushion seal and the U-shaped groove in the outer surface of the cushion ring. Further, the exhaust air in the right chamber of the drive piston passes from inside the hollow cushion ring through the cylinder port and is released to the atmosphere by the drive solenoid valve.

When the differential pressure (thrust) generated on either side of the drive piston becomes larger than the starting resistance of the machinery, the drive piston begins to move to the right. As the drive piston moves to the right, the U-shaped groove in the outer surface of the cushion ring gradually becomes deeper, a flow corresponding to the drive speed of the drive piston flows into the left chamber of the drive piston, and the drive piston proceeds to accelerate. The U-shaped groove is machined into the cushion ring in such a way that this acceleration process can proceed smoothly (as a sine function).

Deceleration/Stop

SMC

In conventional cushion mechanisms, when the cushion seal installed on the drive piston is pushed into the cushion ring at the right stroke end, the drive piston's right chamber is pressurized and a sudden braking force is generated. However, in a sine rodless cylinder, due to the U-shaped groove provided on the outer surface of the cushion ring, whose depth changes as a sine function, a large quantity of the air in the cushion chamber is discharged when the cushion seal is pushed in, and a sudden braking force is not generated. With the progression of the cushion stroke, the discharge flow from the cushion chamber is restricted, and therefore, a soft stop is achieved at the stroke end.

Dimensions

REA25/32/40





Model	Port size	В	D	F	G	Н	Ι	K	L	MM x J	Ν	NT	NA	NB	NN
REA25	Rc 1/8	46	27.8	13	8	20.5	34	10	70	M5 x 0.8 x 8	15	11.5	30	13	M26 x 1.5
REA32	Rc 1/8	60	35	16	9	22	40	15	80	M6 x 1.0 x 8	17	13	36	15	M26 x 1.5
REA40	Rc 1/4	70	43	16	11	29	50	16	92	M6 x 1.0 x 10	21	13	46	19	M32 x 2.0
								_	-						
	P						_	_							

Madal		Р		c	147	v	77	Б	–	
Woder	Nil	TN	TF	Э	VV	^		п		
REA25	Rc 1/8	NPT 1/8		111	50	30	137	8	17	
REA32	Rc 1/8	NPT 1/8	G1/8	124	50	40	156	8	17	
REA40	Rc 1/4	NPT 1/4		150	60	40	182	10	19	

REA50/63



Madal	в	6	D			ĸ		ΝΑ		Р			6	TOND	w	v	77
Model	Р	C	U	E(110)		ĸ	L	INA	Nil	TN	TF	3	IUXN	vv	^	~~	
REA50	86	32	53	30 ⁰ -0.033	58.2	25	110	55	Rc 1/4	NPT 1/4	G 1/4	M8 x 1.25 x 16	176	M12 x 1.25 x 7.5	60	60	180
REA63	100	38	66	32- ⁰ .039	72.2	26	122	69	Rc 1/4	NPT 1/4	G 1/4	M10 x 1.5 x 16	188	M14 x 1.5 x 11.5	70	70	192

SMC

Mounting Nuts: 2 pcs. Packaged with Each Cylinder





Model	Applicable bore size (mm)	d	Н	В	С
SN-032B	ø 25 , ø 32	M26 x 1.5	8	32	37
SN-040B	ø 40	M32 x 2.0	11	41	47.3



REA

REB

REC

C V

C□X

MQ

RHC

RZQ



Series REA **Specific Product Precautions**

Be sure to read before handling. Refer to front matters 42 and 43 for Safety Instructions and pages 3 to 11 for Actuator and Auto Switch Precautions.

Mounting

A Caution

- 1. Take care to avoid nicks or other damage on the outside surface of the cylinder tube. This can lead to a damage of the scraper and the wear ring,
 - which in turn can cause malfunction.
- 2. Use caution to the rotation of the external slider. Rotation should be controlled by connecting it to another shaft (linear guide, etc.).
- 3. Do not operate with the magnetic coupling out of position.

If the magnetic coupling is out of position, push the external slider by hand (or the piston slider with air pressure) back to the proper position at the stroke end.

4. Be sure that both head covers are secured to the mounting surface before operating the cylinder. Avoid operation with the external slider secured to the surface.

5. Do not apply a lateral load to the external slider.

When a load is mounted directly to the cylinder, variations in the alignment of each shaft center cannot be offset, which results in the generation of a lateral load that can cause malfunction. The cylinder should be operated using a connection method which allows for shaft alignment variations and deflection due to the cylinder's own mass. A drawing of a recommended mounting is shown in Fig. (2).





Variations in the load and cylinder shaft alignment cannot be offset and may result in a malfunction.

Fig. (1) Incorrect mounting

Shaft alignment variations are offset by providing clearance between mounting bracket and cylinder Moreover, the mounting bracket is extended above the cylinder shaft center, so that the cylinder is not subjected to moment

Fig. (2) Recommended mounting

6. Use caution regarding the allowable load mass when operating in a vertical direction.

The allowable load mass when operating in a vertical direction (reference values on page 934 is determined by the model selection method. However, if a load greater than the allowable value is applied, the magnetic coupling may break and there is a possibility of dropping the load. When using this type of application, please contact SMC regarding the operating conditions (pressure, load, speed).

Disassembly and Maintenance

A Caution

1. When reattaching the head covers after disassembly, confirm that they are tightened securely.

When disassembling, hold the wrench flats of one head cover with a vise, and remove the other cover using a spanner or adjustable wrench on the wrench flats. When retightening, first coat with Loctite® (no. 542 Red), and retighten 3° to 5° past the original position prior to removal.

Stroke Adjustment

A Caution

- 1. This mechanism is not intended for adjustment of the cushion effect (smooth start-up, soft stop). This mechanism is for matching of the cylinder's stroke end position to the mechanical stopper, etc., of a machine. (adjustment range from 0 to -2 mm)
- 2. Before adjustment is performed, shut off the drive air, release any residual pressure and implement measures to prevent dropping of workpieces, etc.

Stroke End Adjustment

(To ensure safety, implement with air shut down.)

A Caution

- 1. Loosen lock nut A.
- 2. Insert a wrench into the hexagon socket of the adjusting screw, and turn it to the left or right, matching the cushion ring holder (stroke end) with the position of the external stopper by moving it backward or forward.
- 3. After the stroke end adjustment is completed, retighten lock nut A, and apply high strength Loctite[®] no. 262 or another comparable locking agent.

Adjusting Screw Hexagon Socket

Adjusting So	rew Hexagon Socket	Lock Nut A tightening Torque				
Model	Width across flats (mm)	Model	Tightening torque (N·m)			
REA25	5	REA25	1.2			
REA32	5	REA32	1.2			
REA40	6	REA40	2.1			
REA50	8	REA50	3.4			
REA63	8	REA63	3.4			



Direct Mount Type

Series **REAR**

ø10, ø15, ø20, ø25, ø32, ø40



REA
REB
REC
C 🗆 Y
C 🗆 X
MQ
RHC
RZQ

D- □
-X □
Individual -X□





SMC

940

Caution on Design 1

SMC

Selection Method

Selection Procedures

- Find the drive resisting force Fn (N) when moving the load horizontally.
- 2. Find the distance Lo (cm) from the point
 of the load where driving force is applied,
- to the center of the cylinder shaft.
- 3. Select a bore size from Lo and Fn in Data (A).



Selection Example

Given a load drive resisting force of Fn = 100 (N) and a distance from the cylinder shaft center to the load application point of Lo = 8 cm, find the intersection point by extending upward from the horizontal axis of data (A) where the distance from the shaft center is 8 cm, and then extending to the side, find the allowable driving force on the vertical axis. Models suitable to satisfy the requirement of 100 (N) are **REAR32** or **REAR40**.

 Distance from cylinder shaft center, Lo, is the moment working point between the cylinder and the load.





REA

REB

REC

CUA

C 🗆 X

MQ

RHC

RZQ

D-🗆

-X□ Individual

-X□

Cylinder Self-weight Deflection

When the cylinder is mounted horizontally, deflection appears due to its own weight as shown in the data, and the longer the stroke, the greater the amount of variation in the shaft centers. Therefore, a connection method should be considered which allows for this variation as shown in the drawing.



The above clearance is for reference.

Note) Referring to the self-weight deflection in the graph below, provide clearance so that the cylinder does not touch the mounting surface or the load section, and is able to operate smoothly within the minimum operating pressure range for a full stroke.



* The above deflection data indicate values when the external slider has moved to the middle of the stroke.

Caution on Design 2

Vertical Operation

The load should be guided by a ball type bearing (Linear guide, etc.). If a slide bearing is used, sliding resistance will increase due to the load weight and moment, and this can cause malfunction.

When the cylinder is mounted vertically or sidelong, sliders may move downwards due to the self-weight or workpiece mass. If an accurate stopping position is required at the stroke end or the middle-stroke, use an external stopper to secure accurate positioning.



Bore size (mm)	Model	Allowable load mass Wv (kg)	Maximum operating pressure Pv (MPa)
10	REAR10	2.7	0.55
15	REAR15	7.0	0.65
20	REAR20	11.0	0.65
25	REAR25	18.5	0.65
32	REAR32	30.0	0.65
40	REAR40	47.0	0.65

Note) Use caution, since the magnetic coupling may be dislocated if it is used over the maximum operating pressure.

Maximum Load Mass when Loaded Directly on Body

When the load is applied directly to the body, it should be no greater than the maximum values shown in the table below.

Model	Maximum load mass WBmax (kg)
REAR 10	0.4
REAR 15	1.0
REAR 20	1.1
REAR 25	1.2
REAR 32	1.5
REAR 40	2.0



Caution on Design 3

SMC

Intermediate Stop

The cushion effect (smooth start-up, soft stop) exists only before the stroke end in the stroke ranges indicated in the table below.

The cushion effect (smooth start-up, soft stop) cannot be obtained in an intermediate stop or return from an intermediate stop using an external stopper, etc.

Cushion Stroke

Model	Stroke (mm)
REAR10	20
REAR15	25
REAR20	30
REAR25	30
REAR32	30
REAR40	35

Body Non-rotating Accuracy and Max. Allowable Moment (With switch rail) (Reference values)

Reference values for non-rotating accuracy and maximum allowable moment at stroke end are indicated below.



Note 1) Avoid operations where rotational torque (moment) is applied. In such a case, the use of an external guide is recommended.

Note 2) The above reference values will be satisfied within the allowable stroke ranges. However, caution is necessary because as the stroke becomes longer the inclination (rotation angle) within the stroke can be expected to increase.

Note 3) When a load is applied directly to the body, the loaded mass should be no greater than the allowable load mass on page 942.

REA
REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

D- □
-X □
Individual -X□

Sine Rodless Cylinder/Direct Mount Type Series **REAR**

ø10, ø15, ø20, ø25, ø32, ø40



Cylinder stroke (mm)

Refer to "Standard Stroke" on page 945.

Applicable Auto Switch/Refer to pages 1719 to 1827 for further information on auto switches.

			L	Load voltage			Lead wire length (m)			m)	Due sulme d								
Туре	Special function	entry	Indicator	(Output)	D	C	AC Auto switch model		0.5 (Nil)	1 (M)	3 (L)	5 (Z)	connector	Applica	ble load				
ч				3-wire (NPN)		5V 10V		M9N	•			0	0	IC					
wit	—			3-wire (PNP)		50,120		M9P				0	0	circuit					
tes		Grommot	Vaa	2-wire	24V	0.414	0.417	0414	0414	12V]	M9B				0	0	—	Relay,
sta	Disgnastic indication	Giommer	ies	3-wire (NPN)		51/ 101/	_	M9NW				0	0	IC	PLC				
lid	(2-color indication)	2-color indication)	(2-color indication)	(2-color indication)		3-wire (PNP)		50,120		M9PW				0	0	circuit			
ŝ				2-wire		12V		M9BW				0	0	—					
tc q		Crommot	Yes	3-wire (NPN equivalent)	—	5V	—	A96	•	-	•	-	—	IC circuit	—				
Š.		Gronnet	L	0	1011	100V	A93	•	-		—	_	—	Relay,					
			N0	2-wire	∠4V	120	100V or less	A90		—		—	—	IC circuit	PLC				

* Lead wire length symbols: 0.5 m.....Nil (Example) M9NW

* Solid state auto switches marked with "O" are produced upon receipt of order.

1 m······M (Example) M9NWM 3 m······L (Example) M9NWL 5 m······Z (Example) M9NWZ

* Since there are other applicable auto switches than listed, refer to page 949 for details.

* For details about auto switches with pre-wired connector, refer to pages 1784 and 1785.

* Auto switches are shipped together (not assembled).

勿 SMC

Sine Rodless Cylinder Direct Mount Type Series REAR



Made to Order Specifications (For details, refer to page 1939.)

> Specifications With floating joint

Made to Order

Symbol

–XC57

Specifications

Bore size (mm)	10	15	20	25	32	40
Fluid			А	ir		
Proof pressure			1.05	MPa		
Maximum operating pressure			0.7 M	ИРа		
Minimum operating pressure			0.18	MPa		
Ambient and fluid temperature			-10 to	60°C		
Piston speed (Max.) Note)	50 to 300 mm/s					
Lubrication	Not required (Non-lube)					
Stroke length tolerance	0 to 250 st: ^{+1.0} ₀ , 251 to 1000 st: ^{+1.4} ₀ , 1001 st or longer: ^{+1.8} ₀					
Holding force	53.9	137	231	363	588	922

Note) Piston speed above indicates the maximum speed. It takes approximately 0.5 seconds (for one side) after the body moves from the stroke end until it goes through the cushion stroke, while it takes approximately 1 second for both sides.

Standard Stroke

Bore size (mm)	Standard stroke (mm)	Maximum manufacturable stroke (mm)	Maximum stroke with switch stroke (mm)
10	150, 200, 250, 300	500	500
15	150, 200, 250, 300, 350, 400 450, 500	1000	750
20		1500	1000
25 32	200, 250, 300, 350, 400, 450 500, 600, 700, 800	2000	1500
40	200, 250, 300, 350, 400, 450 500, 600, 700, 800, 900, 1000	2000	1500

Note) Intermediate stroke is available by the 1 mm interval.

Mass

							(kg)	
Item	Bore size (mm)	10	15	20	25	32	40	
Basic	REAR□ (with switch rail)	0.111	0.277	0.440	0.660	1.27	2.06	
(for 0 st)	REAR□-□N (without switch rail)	0.080	0.230	0.370	0.580	1.15	1.90	
Additional mass per each 50 mm of stroke (when equipped with switch rail)		0.034	0.045	0.071	0.083	0.113	0.133	
Additional mass per each 50 mm of stroke (when not equipped with switch rail)		0.014	0.020	0.040	0.050	0.070	0.080	

Calculation: (Example) REAR25-500 (with switch rail) • Basic mass 0.660 (kg)

Additional mass 0.083 (kg/50 st)
 Cylinder stroke 500 (st)
 0.660 + 0.083 x 500 ÷ 50 = 1.49 kg

EA EB EC ⊐Y □X MQ RHC RZQ



Series REAR

Construction: ø10, ø15



REAR10

Component Parts

No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Cylinder tube	Stainless steel	
3	Shaft	Stainless steel	Zinc chromated
4	Piston side yoke	Rolled steel plate	Zinc chromated
5	External slider side yoke	Rolled steel plate	
6	Magnet A	—	
7	Magnet B	—	
8	Piston	Brass	Electroless nickel plated
9	Spacer	Rolled steel plate	Nickel plated
10	Retaining ring	Carbon tool steel	Nickel plated
11	Cushion ring	Stainless steel	
12	End cover A	Aluminum alloy	Hard anodized
13	End cover B	Aluminum alloy	Hard anodized
14	Attachment ring	Aluminum alloy	Hard anodized
45	Type C retaining ring	Stainless steel	REAR10
15	for axis	Hard steel wire material	Nickel plated (REAR15)
16	Hexagon socket head set screw	Chromium steel	Nickel plated
17	Retaining plate	Aluminum alloy	

Component Parts

No.	Description	Material	Note
18 *	Cylinder tube gasket	NBR	
19 *	Wear ring A	Special resin	
20 *	Wear ring B	Special resin	
21*	Piston seal	NBR	
22 *	Scraper	NBR	
23 *	Cushion seal	NBR	
24	Magnetic shielding plate	Rolled steel plate	Chromated
25	Switch rail	Aluminum alloy	Clear anodized
26	Magnet	_	
27	Hexagon socket head cap screw	Chromium steel	Nickel plated
28*	Wear ring C	Special resin	

Replacement Parts: Seal Kit

Bore size (mm)	Kit no.	Contents
10	REAR10-PS	Above nos (18, 19, 20, 21,
15	REAR15-PS	Above nos. 22, 23, 28 Note)

Note) It may be difficult to replace the cushion seal 23.

 Seal kit includes a grease pack (ø10: 5 g and 10 g, ø15: 10 g).
 Order with the following part number when only the grease pack is needed. For ø10 grease pack part no.: GR-F-005 (5 g) For external sliding part GR-S-010 (10 g) For tube interior For ø15 grease pack part no.: GR-S-010 (10 g)

Switch Rail Accessory Kit



Switch Rail Accessory Kit

Bore size (mm)	Kit no.	Contents
10	CYR10E-	Above nos. 25, 26, 27, 28
15	CYR15E-D	Above nos. 24, 25, 27, 28 (2)

Note 1) \Box indicates the stroke. Note 2) ø15 has internal magnets in the body.

SMC

Construction: ø20 to ø40



Component Parts

No.	Description	Material	Note		
1	Body	Aluminum alloy	Hard anodized		
2	Cylinder tube	Stainless steel			
3	Shaft	Stainless steel			
4	Piston side yoke	Rolled steel plate	Zinc chromated		
5	External slider side yoke	Rolled steel plate	Zinc chromated		
6	Magnet A	—			
7	Magnet B	—			
8	Bumper	Urethane rubber			
9	Cushion seal holder	Aluminum alloy	Chromated		
10	Piston	Aluminum alloy	Chromated		
11	Spacer	Rolled steel plate	Nickel plated		
12	Retaining ring	Carbon tool steel	Nickel plated		
10	Cushion ring	Brass	Electroless nickel plated (REAR 32, 40)		
13	Cushion ning	Stainless steel	REAR 20, 25		
14	Lock nut B	Carbon steel	Nickel plated		
15	End cover A	Aluminum alloy	Hard anodized		
16	End cover B	Aluminum alloy	Hard anodized		
17	Attachment ring	Aluminum alloy	Hard anodized		
10	Type C retaining ring	Stainless steel	REAR 25, 32		
10	for axis	Hard steel wire material	Nickel plated (REAR 20, 40)		
19	Hexagon socket head set screw	Chromium steel	Nickel plated		

Component Parts

No.	Description	Material	Note
20*	Cylinder tube gasket	NBR	
21*	Wear ring A	Special resin	
22 *	Wear ring B	Special resin	
23 *	Piston seal	NBR	
24*	Scraper	NBR	
25 *	Cushion seal	NBR	Chromated
26	Magnetic shielding plate	Rolled steel plate	Clear anodized
27	Switch rail	Aluminum alloy	
28	Magnet	—	Nickel plated
29	Hexagon socket head cap screw	Chromium steel	
30*	Wear ring C	Special resin	

 \ast Seal kit includes 0 to 0 , 0 . Order the seal kit, based on each bore size.

Replacement Parts: Seal Kit

Bore size	Kit no.	Contents	REA
20	REAR20-PS		RFB
20		Above nos	
25		20 21 22 23 24 25 30 Note	RFC
32	REAR32-PS		IILU
40	REAR40-PS		
Note) Cushion	seal 🗵 may be difficult to t	be replaced.	ll⊓i

Seal kit includes a grease pack (10 g).
 Order with the following part number when only the grease pack is needed.
 Grease pack part no.: GR-S-010 (10 g)

Switch Rail Accessory Kit



Switch Rail Accessory Kit								
Bore s	size (mm)	Kit no.	Contents					
20	For reed switch	CYR20E-□						
20	For solid state switch	CYR20EN-D	Above nos					
	25	CYR25E-□						
	32	CYR32E-□						
	40	CYR40E-□						
Note) □ indicates the stroke.								

SMC

C 🗆 X

MQ

RHC

RZQ

D-□

-X□

Individual -X□

Series **REAR**

Dimensions



(mm)

ക

Model	Α	В	С	СВ	CR	D	F	G	GP	GW	Н	HA	HC	HR	HS	HT	J×E
REAR10	10.5	6.5	3.2	2	0.5	12	6.5	6	27	25.5	26	24	25	24	5	14	M4 x 0.7 x 6
REAR15	12	8	4.2	2	0.5	17	8	7	33	31.5	32	30	31	30	8.5	17	M5 x 0.8 x 7
REAR20	9	9.5	5.2	3	1	22.8	9	6	39	37.5	39	36	38	36	7.5	21	M6 x 1 x 8
REAR25	8.5	9.5	5.2	3	1	27.8	8.5	6	44	42.5	44	41	43	41	6.5	23.5	M6 x 1 x 8
REAR32	10.5	11	6.5	3	1.5	35	10.5	7	55	53.5	55	52	54	51	7	29	M8 x 1.25 x 10
REAR40	10	11	6.5	5	2	43	13	7	65	63.5	67	62	66	62	8	36	M8 x 1.25 x 10

Madal	v			84	NANA	N		Р		DW	0	OW	т	w	We	v	v	7
Model	n n	L		IVI			Nil	TN	TF	FW	Q	GW	•	~~	w3	~		2
REAR10	9	38	3.5	4	M3 x 0.5	4.5	M5 x 0.8		—	26	68	14	19.5	20	8	15	39.5	80
REAR15	14	53	4.3	5	M4 x 0.7	6	M5 x 0.8		—	32	84	18	21	25	7	18	54.5	98
REAR20	11	62	5.6	5	M4 x 0.7	7	Rc 1/8	NPT 1/8	—	38	95	17	20.5	40	7	22	64	107
REAR25	15	70	5.6	6	M5 x 0.8	6.5	Rc 1/8	NPT 1/8	G 1/8	43	105	20	21.5	40	7	28	72	117
REAR32	13	76	7	7	M6 x 1	8.5	Rc 1/8	NPT 1/8	G 1/8	54	116	26	24	50	7	35	79	130
REAR40	15	90	7	8	M6 x 1	11	Rc 1/4	NPT 1/4	—	64	134	34	26	60	7	40	93	148

Auto Switch Proper Mounting Position (Detection at Stroke End)



Auto Switch Proper Mounting Position ø10 to ø40

<u>ø10 to ø</u>	40							(mm)		
Auto switch	4	4	I	3	(C	D			
Bore size (mm)	D-A 9□	D-M9□ D-M9□W	D-A 9□	D-M9□ D-M9□W	D-A 9□	D-M9□ D-M9□W	D-A9 □	D-M9□ D-M9□W		
10	30	34	50	46	50	46		34		
15	19.5	23.5	78.5	74.5		_	58.5	62.5		
20	19.5	23.5	87.5	83.5	39.5	35.5	67.5	71.5		
25	19	23	98	102	42	46	75	79		
32	22.5	26.5	107.5	111.5	45.5	49.5	84.5	88.5		
40	24.5	28.5	123.5	127.5	47.5	51.5	100.5	104.5		

Note 1) Auto switches cannot be installed in Area C in the case of ø15.

Note 2) D-A9 cannot be mounted on D of ø10.

Note 3) Adjust the auto switch after confirming the operating conditions in the actual setting.

ø25 to ø40

Ø 25 to Ø 40 (mm											
Auto switch	Α	В	С	D							
Bore size (mm)	D-Z7 D-Z80 D-Y59 D-Y7P D-Y7 W	D-Z7 D-Z80 D-Y59 D-Y7P D-Y7 W	D-Z7 D-Z80 D-Y59 D-Y7P D-Y7 W	D-Z7 D-Z80 D-Y59 D-Y7P D-Y7 W							
25	18	99	43	74							
32	21.5	108.5	46.5	83.5							
40	23.5	124.5	48.5	99.5							

Note) Adjust the auto switch after confirming the operating conditions in the actual setting.

Operating Range

Solid state

L

						(mm)				
Auto outitale model	Bore size (mm)									
Auto switch model	10	15	20	25	32	40				
D-A9□	13	8	6	7.5	8	9				
D-M9□W D-M9□	6.5	4.5	5.5	4	4.5	5				
D-Z7□/Z80	_		_	9	9	11				
D-Y5□/Y7P/Y7□W	-	-	—	7	6	6				

* Since this is a guideline including hysteresis, not meant to be guaranteed. (assuming approximately ±30% dispersion) There may be the case it will vary substantially depending on an ambient environment.



Auto Switch Mounting Bracket: Part No.

Diagnostic indication (2-color indication)

Other than the models listed in "How to Order", the following auto switches are applicable. For detailed specifications, refer to pages 1719 to 1827. Auto switch type Model Electrical entry (Fetching direction) Features D-Z73, Z76 Grommet (In-line) Reed Without indicator light D-Z80 D-Y59A, Y59B, Y7P

D-Y7NW, Y7PW, Y7BW



-X□

Applicable bore size

ø25 to ø40

For solid state auto switches, auto switches with a pre-wired connector are also available. Refer to pages 1784 and 1785 for details.

* Normally closed (NC = b contact) solid state auto switches (D-F9G/F9H/Y7G/Y7H types) are also available. Refer to pages 1746 and 1748 for details.



Grommet (In-line)



Series REAR Specific Product Precautions

Be sure to read before handling. Refer to front matters 42 and 43 for Safety Instructions and pages 3 to 11 for Actuator and Auto Switch Precautions.

Mounting

A Caution

- 1. Take care to avoid nicks or other damage on the outside surface of the cylinder tube. This can lead to a damage of the scraper and the wear ring, which in turn can cause malfunction.
- **2. Use caution to the rotation of the external slider.** Rotation should be controlled by connecting it to another shaft (linear guide, etc.).
- 3. Do not operate with the magnetic coupling out of position.

If the magnetic coupling is out of position, push the external slider by hand (or the piston slider with air pressure) back to the proper position at the stroke end.

- 4. The cylinder is mounted with bolts through the mounting holes in the end covers. Be sure they are tightened securely.
- 5. Be sure that both end covers are secured to the mounting surface before operating the cylinder. Avoid operation with the external slider secured to the surface.
- **6.** Do not apply a lateral load to the external slider. When a load is mounted directly to the cylinder, variations in the alignment of each shaft center cannot be offset, which results in the generation of a lateral load that can cause malfunction. The cylinder should be operated using a connection method which allows for shaft alignment variations and deflection due to the cylinder's own weight. A drawing of a recommended mounting is shown in Fig. (2).



Variations in the load and cylinder shaft alignment cannot be offset and may result in a malfunction.

Figure (1) Incorrect mounting

providing clearance between the mounting bracket and cylinder. Moreover, the mounting bracket is extended above the cylinder shaft center, so that the cylinder is not

Figure (2) Recommended mounting

subjected to moment.

7. Use caution regarding the allowable load mass when operating in a vertical direction.

The allowable load mass when operating in a vertical direction (reference values on page 942) is determined by the model selection method, however, if a load greater than the allowable value is applied, the magnetic coupling may break and there is a possibility of dropping the load. When using this type of application, please contact SMC regarding the operating conditions (pressure, load).

Disassembly and Maintenance

A Caution

1. Special tools are necessary for disassembly.



Special Tool No.

Part no.	Applicable bore size (mm)
CYRZ-V	10, 15, 20
CYRZ-W	25, 32, 40

Slider Type/Slide Bearing

Series **REAS**

ø10, ø15, ø20, ø25, ø32, ø40



	REA
[REB
	REC
	C□Y
	C□X
	MQ
	RHC
	RZQ

D-🗆
-X □
Individual -X□

SMC



SMC

Caution on Design 1

How to Find σ when Selecting the Allowable Load Mass

Since the maximum load mass with respect to the cylinder stroke changes as shown in the table below, σ should be considered as a coefficient determined in accordance with each stroke. Example) For REAS25-650

(1) Maximum load mass = 20 kg

(2) Load mass for 650 st = 13.6 kg

(3) $\sigma = \frac{13.6}{20} = 0.68$ is the result.

Calculation Formula for σ ($\sigma \leq 1$) ST: Stroke (mm)

Model	REAS10	REAS15	REAS20
σ=	$\frac{10^{(0.86 - 1.3 x 10^{-3} x ST)}}{3}$	$\frac{10^{(1.5-1.3x10^{-3}xST)}}{7}$	$\frac{10^{(1.71 - 1.3 x 10^{-3} x ST)}}{12}$
Model	REAS25	REAS32	REAS40
σ=	$10^{(1.98 - 1.3 \times 10^{-3} \times ST)}$	$10^{(2.26 - 1.3 \times 10^{-3} \times ST)}$	10 ^(2.48 - 1.3 x 10⁻³ x ST)

Note) Calculate with σ = 1 for all applications up to ø10–300 mmST, ø15–500 mmST, ø20-500 mmST , ø25-500 mmST, ø32-600 mmST, ø40-600 mmST.







Example of Allowable Load Mass Calculation Based on Cylinder Mounting Orientation

1. Horizontal Operation (Floor mounting)



Maximum Load Mass (Center of slide block)

						/ (
Bore size (mm)	10	15	20	25	32	40
Max. load mass (kg)	3	7	12	20	30	50
Stroke (Max.)	Up to 300st	Up to 500st	Up to 500st	Up to 500st	Up to 600st	Up to 600st

The above maximum load mass values will change with the stroke length for each cylinder size, due to limitation from warping of the guide shafts. (Take note of the coefficient σ .)

Moreover, depending on the operating direction, the allowable load mass may be different from the maximum load mass.

2. Horizontal Operation (Wall mounting)



Lo: Distance from mounting surface to load center of gravity (cm) Note) Consider a safety factor for drop prevention.

-X□

Individual

-X□

(ka)



Caution on Design 2

Example of Allowable Load Mass Calculation Based on Cylinder Mounting Orientation

4. Inclined Operation (in operating direction)



Angle coefficient (k): $\mathbf{k} = [up \text{ to } 45^{\circ} (= \theta)] = 1$, [up to 60°] = 0.9, [up to 75°] = 0.8, [up to 90°] = 0.7

Lo: Distance from mounting surface to load center of gravity (cm)

5. Inclined Operation (at a right angle to operating direction)



Lo: Distance from mounting surface to load center of gravity (cm)

Bore size (mm)	Allowable load mass WA (kg)
10	<u></u> σ·12.0
10	4 + 2 (2.2 + Lo) sinθ
15	σ.36.4
15	5.2 + 2 (2.7 + Lo) sinθ
	σ.74.4
20	6.2 + 2 (2.9 + Lo) sinθ
25	σ.140
25	$7 + 2 (3.4 + Lo) \sin\theta$
20	σ.258
32	8.6 + 2 (4.2 + Lo) sinθ
40	σ.520
40	10.4 + 2 (5.1 + Lo) sinθ

6. Load Center Offset in Operating Direction (Lo)



7. Horizontal Operation (Pushing load, Pusher)



F: Drive (from slide block to position Lo) resistance force (kg) Lo: Distance from mounting surface to load center of gravity (cm)

Bore size (mm)	10	15	20
Allowable load mass Wa (kg)	<u></u> σ·5.25 2.2 + Lo	<u></u> <u></u> <u></u>	<u> </u>
Bore size (mm)	25	32	40

8. Horizontal Operation (Load, Lateral offset Lo)



Lo: Distance from mounting surface to load center of gravity (cm)

Bore size (mm)	10	15	20
Allowable load mass WA (kg)	<u>σ.8.40</u> 4 + Lo	<u></u> σ·25.48 5.2 + Lo	<u></u> 0 ·52.1 6.2 + Lo
,	-		
Bore size (mm)	25	32	40

Caution on Design 3

Vertical Operation

When operating a load vertically, it should be operated within the allowable load mass and maximum operating pressures shown in the table below.

Use caution since operating above the prescribed values may lead to a dropping of the load with the magnetic coupling out of position.

When the cylinder is mounted vertically or sidelong, sliders may move downwards due to the self-weight or workpiece mass. If an accurate stopping position is required at the stroke end or the middle-stroke, use an external stopper to secure accurate positioning.

Bore size (mm)	Model	Allowable load mass Wv (kg)	Max. operating pressure Pv (MPa)
10	REAS10	2.7	0.55
15	REAS15	7.0	0.65
20	REAS20	11.0	0.65
25	REAS25	18.5	0.65
32	REAS32	30.0	0.65
40	REAS40	47.0	0.65

Stroke Adjustment

The adjusting bolt is adjusted to the optimum position for smooth acceleration and deceleration at the time of shipment, and should be operated at the full stroke. When stroke adjustment is necessary, the maximum amount of adjustment on one side is 2 mm. (Do not adjust more than 2 mm, as it will not be possible to obtain smooth acceleration and deceleration.)

Stroke adjustment method

Loosen the hexagon nut, and after performing the stroke adjustment from the plate side with a hexagon wrench, retighten and secure the hexagon nut.



Adjusting Bolt Position (at the time of shipment), Hexagon Nut Tightening Torque

Model	T (mm)	Tightening torque (N·m)
REAS10	1	1.67
REAS15	1	1.07
REAS20	1.5	3.14
REAS25	1.5	10.8
REAS32	3	23.5
REAS40	2	23.5

Intermediate Stop

The cushion effect (smooth start-up, soft stop) exists only before the stroke end in the stroke ranges indicated in the table below. The cushion effect (smooth start-up, soft stop) cannot be obtained in an intermediate stop or a return from an intermediate stop using an external stopper, etc.

Cushion Stroke

Model	Stroke (mm)
REAS10	20
REAS15	25
REAS20	30
REAS25	30
REAS32	30
REAS40	35

REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

RFA

D -□
-X □
Individual -X□





Applicable Auto Switch/Refer to pages 1719 to 1827 for further information on auto switches.

			light		L	oad volta	age	Auto swite	ch model	Lead		Lead wire length (n (m)*													
Туре	Special function	Electrical	ator	(Output)	DC		10			0.5	3	5	None	Pre-wired	Applica	icable											
	entry		India	(Output)	DC		AC	Perpendicular	In-line	(Nil)	(L)	(Z)	(N)	connector	load												
				3-wire (NPN)		5 V 40 V		F7NV	F79	•		0	—	0	IC												
_		Grommet		3-wire (PNP)		5 V, 12 V		F7PV	F7P	•		0	_	0	circuit												
tc h				0 wire		10.11		F7BV	J79	•	۲	0	—	0]											
Ň		Connector		2-wire		12 V		J79C	-	•																	
e				3-wire (NPN)	04.14			F7NWV	F79W	•	٠	0	—	0	IC	Relay.											
tat	Diagnostic indication		res	3-wire (PNP)	24 V	5 V, 12 V	—	-	F7PW	•		0	—	0	circuit	PLC											
ő	(2-color indication)	Crownet						F7BWV	J79W	•	۲	0	—	0													
ilo	Water resistant	Grommet		2-wire	_	12 V	12 V	-	F7BA	—	٠	0	—	0	_												
0	(2-color indication)							F7BAV	-	—	٠	0	—	0													
	With diagnostic output (2-color indication)			4-wire (NPN)		5	5 V, 12 V		-	F79F	•	٠	0	—	0	IC circuit											
_	5 Grommet	Grommet												Vez	3-wire (NPN equivalent)	_	5 V	—	-	A76H	•	•	_	_		IC circuit	_
/itcł			Yes		_	_	200 V	A72	A72H	•	٠	-	—	_													
l sv						12 V	100 V	A73	A73H	•	•		—	_		Delay											
leec			No	2-wire	04.14	5 V, 12 V	100 V or less	A80	A80H	•	•	—	—	_	IC circuit												
ш		Commenter	Yes		24 V	12 V		A73C	-	•	•			_	_												
		Connector	No			5 V, 12 V	_	A80C	-	•	٠	٠	•	_	IC circuit												
* Lea	Lead wire length symbols: 0.5 m Nil (Example) J79W 3 m L (Example) J79WL 5 m Z (Example) J79WZ None N (Example) J79WZ None N (Example) J79CN																										

• Since there are other applicable auto switches than listed, refer to page 962 for details.

• For details about auto switches with pre-wired connector, refer to pages 1784 and 1785.

* Auto switches are shipped together (not assembled).



Specifications

Bore size (mm)	10	15	20	25	32	40
Fluid	luid Air					
Proof pressure	1.05 MPa					
Maximum operating pressure	0.7 MPa					
Minimum operating pressure	0.18 MPa					
Ambient and fluid temperature			-10 to	60°C		
Piston speed (Max.) Note)	te) 50 to 300 mm/s					
Lubrication	Not required (Non-lube)					
Stroke length tolerance	0 to 250 st: ^{+1.0} / ₀ , 251 to 1000 st: ^{+1.4} / ₀ , 1001 st or longer: ^{+1.8} / ₀					
Holding force	53.9	137	231	363	588	922

Note) Piston speed above indicates the maximum speed. It takes approximately 0.5 seconds (for one side) after the slide block moves from the stroke end until it goes through the cushion stroke, while it takes approximately 1 second for both sides.

Standard Stroke

Bore size (mm)	Standard stroke (mm)	Maximum manufacturable stroke (mm)
10	150, 200, 250, 300	500
15	150, 200, 250, 300, 350, 400, 450, 500	750
20		1000
25	200, 250, 300, 350, 400, 450, 500, 600, 700, 800	1500
32		1500
40	200, 250, 300, 350, 400, 450, 500, 600, 700, 800, 900, 1000	1500

Note) Intermediate stroke is available by the 1 mm interval.

Mass

						(kg)	<u> </u>
Bore size (mm)	10	15	20	25	32	40	
Basic mass	0.48	0.91	1.48	1.84	3.63	4.02] [
Additional mass per each 50 mm of stroke	0.074	0.104	0.138	0.172	0.267	0.406	

REA
REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

Made to Order	Made to Order Specifications
	(For details, refer to pages 1955 to 2021.)

Symbol	Specifications
—X210	Non-lubricated exterior specifications
—X324	Non-lubricated exterior specifications with dust seal
—X431	Auto switch rails on both side faces (With 2 pcs.)
—X168	Helical insert thread specifications

Series **REAS**

Construction: ø10, ø15



REAS10

Component Parts

No.	Description	Material	Note
1	Cylinder tube	Stainless steel	
2	External slider tube	Aluminum alloy	
3	Shaft	Stainless steel	
4	Piston side yoke	Rolled steel plate	Zinc chromated
5	External slider side yoke	Rolled steel plate	Zinc chromated
6	Magnet A	—	
7	Magnet B	—	
8	Cushion seal holder	Aluminum alloy	Anodized
9	Piston	Brass	Electroless nickel plated
10	Slide block	Aluminum alloy	Hard anodized
11	Spacer	Rolled steel plate	Nickel plated
12	Slider spacer	Rolled steel plate	Nickel plated
13	Retaining ring	Carbon tool steel	Nickel plated
14	Bushing	Oil retaining bearing material	
15	Cushion ring	Stainless steel	
16	Plate A	Aluminum alloy	Hard anodized

Replacement Parts: Seal Kit

Bore size (mm) Kit no.		Contents			
10	REAS10-PS	Set of above. nos Note)			
15	REAS15-PS	26, 27, 28, 29 30, 31, 32			

Note) It may be difficult to replace the cushion seal (32).

* Seal kit includes a grease pack (ø10: 5 g and 10 g, ø15: 10 g).

Order with the following part number when only the grease pack is needed. For ø10 grease pack part no.: GR-F-005 (5 g) For external sliding part GR-S-010 (10 g) For tube interior

For ø15 grease pack part no.: GR-S-010 (10 g)

Component Parts

No.	Description	Material	Note
17	Plate B	Aluminum alloy	Hard anodized
18	Port cover	Aluminum alloy	Hard anodized
19	Guide shaft A	Carbon steel	Hard chrome plated
20	Guide shaft B	Carbon steel	Hard chrome plated
21	Adjusting bolt A	Chromium molybdenum steel	Nickel plated
22	Adjusting bolt B	Chromium molybdenum steel	Nickel plated
23	Hexagon nut	Carbon steel	Nickel plated
24	Switch mounting rail	Aluminum alloy	
25	Auto switch	_	
26 *	Cylinder tube gasket	NBR	
27 *	Guide shaft gasket	NBR	
28*	Wear ring A	Special resin	
29*	Wear ring B	Special resin	
30*	Piston seal	NBR	
31*	Scraper	NBR	
32*	Cushion seal	NBR	

* Seal kit includes (26) to (32). Order the seal kit, based on each bore size.



Construction: ø20 to ø40



Component Parts

No.	Description	Material	Note
1	Cylinder tube	Stainless steel	
2	External slider tube	Aluminum alloy	
3	Shaft	Stainless steel	
4	Piston side yoke	Rolled steel plate	Zinc chromated
5	External slider side yoke	Rolled steel plate	Zinc chromated
6	Magnet A	-	
7	Magnet B	—	
8	Bumper	Urethane rubber	
9	Cushion seal holder	Aluminum alloy	Chromated
10	Piston	Aluminum alloy	Chromated
11	Slide block	Aluminum alloy	Hard anodized
12	Spacer	Rolled steel plate	Nickel plated
13	Slider spacer	Rolled steel plate	Nickel plated
14	Retaining ring	Carbon tool steel	Nickel plated
15	Bushing	Oil retaining bearing material	
16	Cushion ring holder	Aluminum alloy	Anodized
47	Cushien ring	Brass	Electroless nickel plated (REAS32, 40)
17		Stainless steel	REAS20, 25

Replacement Parts: Seal Kit

Bore size (mm)	Kit no.	Contents	
20	REAS20-PS		
25	REAS25-PS	Set of nos. above	
32	REAS32-PS	28, 29, 30, 31 32, 33, 34	
40	REAS40-PS		

Note) Cushion seal \Im may be difficult to be replaced.

* Seal kit includes a grease pack (10 g). Order with the following part number when only the grease pack is needed. Grease pack part no.: GR-S-010 (10g)

Component Parts

No.	Description	Material	Note		
18	Lock nut B	Carbon steel	Nickel plated		
19	Plate A	Aluminum alloy	Hard anodized		
20	Plate B	Aluminum alloy	Hard anodized		
21	Guide shaft A	Carbon steel	Hard chrome plated		
22	Guide shaft B	Carbon steel	Hard chrome plated		
23	Adjusting bolt A	Chromium molybdenum steel	Nickel plated	REA	
24	Adjusting bolt B	Chromium molybdenum steel	Nickel plated	ПГП	
25	Hexagon nut	Carbon steel	Nickel plated	NED	
26	Switch mounting rail	Aluminum alloy		DEC	
27	Auto switch	—	With auto switch	REC	
28*	Cylinder tube gasket	NBR		∩ ⊓V	
29*	Guide shaft gasket	NBR		U∐I	
30 *	Wear ring A	Special resin			
31*	Wear ring B	Special resin			
32*	Piston seal	NBR		MO	
33*	Scraper	NBR		wių	
34*	Cushion seal	NBR		рис	
* Seal	Seal kit includes (28) to (34). Order the seal kit, based on each bore size.				

D-□ -X□ Individual -X□

RZQ

Series **REAS**

Dimensions: ø10



Dimensions: ø15 to ø40



* PA dimensions are for split from center.



REA

REB

REC

C V

D-🗆 -X□ Individual -X□
Series **REAS**

Auto Switch Proper Mounting Position (Detection at Stroke End)



B dimension A dimension Auto switch D-A72 D-A7□H/A80H D-A73C/A80C D-F7□/J79 D-A72 D-A7□H/A80H model D-A73C/A80C D-F7 //J79 D-F7 W/J79W D-J79C D-F7 V/F7 WV D-F7 W/J79W D-J79C D-F7 V/F WV D-A73/A80 **D-F7NTL** D-A73/A80 **D-F7NTL** Bore size D-F7BA D-F7BA D-F79F (mm) D-F79F 10 40.5 45 35 35.5 44.5 39.5 15 34.5 35 40 63 62 57.5 70 20 64.5 65 50.5 50 45 25 44 44.5 49.5 71.5 71 66 32 55.5 60.5 83.5 83 78 55 40 61 61.5 66.5 94.5 94 89

Note) Adjust the auto switch after confirming the operating conditions in the actual setting.

Operating Range

(mm)

(mm)

Auto owitch model	Bore size (mm)					
Auto switch model	10	15	20	25	32	40
D-A7□, A8□	6	6	6	6	6	6
D-F7□, J7□, F79F	3	4	3	3	3	3.5

 \ast Since this is a guideline including hysteresis, not meant to be guaranteed. (assuming approximately $\pm 30\%$ dispersion)

There may be the case it will vary substantially depending on an ambient environment.

	Other than the models applicable. For detaile	s listed in "How d specification	to Order", the following a s, refer to page 1770.	auto switches are
ī	Auto switch type	Model	Electrical entry (Fetching direction)	Features
L	Solid state	D-F7NTL	Grommet (In-line)	With timer
 	 For solid state auto switc Refer to pages 1784 and 	hes, auto switche 1785 for details.	s with a pre-wired connector a	are also available.



Series REAS Specific Product Precautions

Be sure to read before handling. Refer to front matters 42 and 43 for Safety Instructions and pages 3 to 11 for Actuator and Auto Switch Precautions.

Operation

Warning

1. Be aware of the space between the plates and the slide block.

Take sufficient care to avoid getting your hands or fingers caught when the cylinder is operated.

2. Do not apply a load to a cylinder which is greater than the allowable value stated in the "Model Selection" pages.

It may cause malfunction.

- 3. Consult with SMC when the cylinder is operated in an environment in which the cylinder is exposed to cutting fluid or water, or the cylinder sliding part lubrication deteriorates.
- 4. When applying grease to the cylinder, use the grease already used for the product. Contact SMC, grease packs are available.

Mounting

A Caution

1. Avoid operation with the external slider fixed to the mounting surface.

The cylinder should be operated with the plates fixed to the mounting surface.

2. Make sure that the cylinder mounting surface has a flatness of 0.2 mm or less.

If the flatness of a workpiece is not appropriate, it may adversely affect the operation since two guide shafts will be twisted. Furthermore, the increase of the sliding resistance and early abrasion of bearings may shorten the service life.

The cylinder mounting surface must have a flatness of 0.2 mm or less, and the cylinder must be mounted so as to be smoothly operated with a minimum operating pressure (0.18 MPa or less) for a full stroke.

Disassembly and Maintenance

\land Warning

1. Use caution, the attractive force of the magnets is very strong.

When removing the external slider and piston slider from the cylinder tube for maintenance, etc., handle with caution since the magnet installed in each slider has a very strong attractive force.

ACaution

1. Use caution when taking off the external slider, since the piston slider will be directly attracted to it.

When removing the external slider or piston slider from the cylinder tube, first force the sliders out of their magnetically coupled positions, and then remove them individually when there is no longer any holding force. If they are removed while still magnetically coupled, they will be directly attracted to one another and will not come apart.

2. Do not disassemble the magnetic components (piston and external sliders).

This may cause a loss of holding force and malfunction.

D- □
-X□
Individual -X 🗆

Slider Type/Ball Bushing Bearing

Series **REAL**

ø10, ø15, ø20, ø25, ø32, ø40



REA
REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

D- □
-X □
Individual -X□

SMC



SMC

Caution on Design 1

How to Find σ when Selecting the Allowable Load Mass

Since the maximum load mass with respect to the cylinder stroke changes as shown in the table below, $\boldsymbol{\sigma}$ should be considered as a coefficient determined in accordance with each stroke. Example) For REAL25-650

- (1) Maximum load mass = 20 kg (2) Load mass for 650 st = 13.6 kg

(3) $S = \frac{13.6}{20} = 0.68$ is the result.

Calculation Formula for σ ($\sigma \leq 1$) ST: Stroke (mm)

Model	REAL10	REAL15	REAL20
σ=	<u>10^(0.86 - 1.3 x 10⁻³ x ST)</u> 3	$\frac{10^{(1.5 - 1.3 \times 10^{-3} \times ST)}}{7}$	$\frac{10^{(1.71 - 1.3 \times 10^{-3} \times ST)}}{12}$
Model	REAL25	REAL32	REAL40
σ=	10 ^(1.98 - 1.3 x 10⁻³ x ST)	10 ^(2.26 - 1.3 x 10⁻³ x ST)	10 ^(2.48 - 1.3 x 10⁻³ x ST)

Note) Calculate with σ = 1 for all applications up to ø10–300 mmST, ø15–500 mmST, a20-500 mmST a25-500 mmST a32-600 mmST a40-600 mmST



<Data (B): Maximum Speed Load Mass Chart>



Examples of Allowable Load Mass Calculation Based on Cylinder Mounting Orientation

1. Horizontal Operation (Floor mounting)



Maximum Load Mass (Center of slide block)

Maximum Load Mass (Center of slide block)				(kg)		
Bore size (mm)	10	15	20	25	32	40
Maximum load mass (kg)	3	7	12	20	30	50
Stroke (max)	Up to 300 st	Up to 500 st	Up to 500 st	Up to 500 st	Up to 600 st	Up to 600 st

The above maximum load mass values will change with the stroke length for each cylinder size, due to limitation from warping of the guide shafts. (Take note of the coefficient σ .)

Moreover, depending on the operating direction, the allowable load mass may be different from the maximum load mass.

2. Horizontal Operation (Wall mounting)



Lo: Distance from mounting surface to load center of gravity (cm)

Bore size (mm)	Allowable load mass $\mathbf{W}\mathbf{A}$ (kg)
10	<u></u>
15	<u></u>
20	<u>σ.101</u> 13.6 + 2Lo
25	<u></u> <u></u> <u></u>
32	
40	<u></u> <u></u> <u></u> <u></u> <u></u> <u></u> <u></u> <u></u> <u></u> <u></u>

3. Vertical Operation



SMC

Bore size (mm)	Allowable load mass WA (kg)	MQ
10	<u>σ.5.00</u> 1.95 + Lo	RHC
15	<u> </u>	D70
20	<u> </u>	nzu
25	<u> </u>	
32	<u>σ.112.57</u> 3.95 + Lo	D -□
40	<u> </u>	-X□
		Individual

Lo: Distance from mounting surface to load center of gravity (cm) Note) Consider a safety factor for drop prevention.

REA

-X□

Caution on Design 2

Examples of Allowable Load Mass Calculation Based on Cylinder Mounting Orientation

4. Inclined Operation (in operating direction)



[up to 90°] = 0.7 [up to 90°] = 0.7

Lo: Distance from mounting surface to load center of gravity (cm)

5. Inclined Operation (at a right angle to operating direction)



Lo: Distance from mounting surface to load center of gravity (cm)

Bore size (mm)	Allowable load mass WA (kg)
10	σ ⋅15
10	5 + 2 (1.95 + Lo) sinθ
15	o .45.5
15	6.5 + 2 (2.4 + Lo) sinθ
20	<u></u> σ.115
20	8 + 2 (2.8 + Lo) sinθ
25	σ.180
25	9 + 2 (3.1 + Lo) sinθ
20	σ.330
32	11 + 2 (3.95 + Lo) sinθ
40	σ.624
40	13 + 2 (4.75 + Lo) sinθ

6. Load Center Offset in Operating Direction (Lo)



7. Horizontal Operation (Pushing load, Pusher)



F: Drive (from slide block to position Lo) resistance force (kg) Lo: Distance from mounting surface to load center of gravity (cm)

Bore size (mm)	10	15	20
Allowable load mass WA (kg)	<u></u> σ·5.55 1.95 + Lo	<u></u> σ·15.96 2.4 + Lo	<u></u> σ·41.7 2.8 + Lo
Bore size (mm)	25	32	40
Bore size (mm) Allowable load mass	25 σ.58.9	32 σ·106.65	40 σ.228

8. Horizontal Operation (Load, Lateral offset Lo)



Lo: Distance from center of side block to load's center of gravity (cm)

Bore size (mm)	10	15	20
Allowable load mass WA (kg)	<u>σ·15</u> 5 + Lo	<u>σ.45.5</u> 6.5 + Lo	<u>σ·80.7</u> 8 + Lo
Bore size (mm)	25	32	40

Caution on Design 3

Vertical Operation

When operating a load vertically, it should be operated within the allowable load weights and maximum operating pressures shown in the table below.

Use caution since operating above the prescribed values may lead to a dropping of the load with the magnetic coupling out of position.

When the cylinder is mounted vertically or sidelong, sliders may move downwards due to the self-weight or workpiece mass. If an accurate stopping position is required at the stroke end or the middle-stroke, use an external stopper to secure accurate positioning.

Bore size (mm)	Model	Allowable load mass Wv (kg)	Maximum operating pressure Pv (MPa)	
10	REAL10	2.7	0.55	
15	REAL15	7.0	0.65	
20	REAL20	11.0	0.65	
25	REAL25	18.5	0.65	
32	REAL32	30.0	0.65	
40	REAL40	47.0	0.65	

Stroke Adjustment

The adjusting bolt is adjusted to the optimum position for smooth acceleration and deceleration at the time of shipment, and should be operated at the full stroke. When stroke adjustment is necessary, the maximum amount of adjustment on one side is 2 mm. (Do not adjust more than 2 mm, as it will not be possible to obtain smooth acceleration and deceleration.)

Stroke adjustment method

Loosen the hexagon nut, and after performing the stroke adjustment from the plate side with a hexagon wrench, retighten and secure the hexagon nut.



Adjusting Bolt Position (at the time of shipment), Hexagon Nut Tightening Torque

Model	T (mm)	Tightening torque (N·m)		
REAL10	1	1.67		
REAL15	1	1.07		
REAL20	1	3.14		
REAL25	1	10.8		
REAL32 1		00 F		
REAL40	1	23.5		

Intermediate Stop

The cushion effect (smooth start-up, soft stop) exists only before the stroke end in the stroke ranges indicated in the table below. The cushion effect (smooth start-up, soft stop) cannot be obtained in an intermediate stop or return from an intermediate stop using an external stopper, etc.

Cushion Stroke

Model	Stroke (mm)
REAL10	20
REAL15	25
REAL20	30
REAL25	30
REAL32	30
REAL40	35

REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

RFA

D -□	
-X □	
Individual -X□	

Sine Rodless Cylinder Slider Type/Ball Bushing Bearing Series REAL Ø10, Ø15, Ø20, Ø25, Ø32, Ø40

How to Order



Refer to "Standard Stroke" on page 971.

Applicable Auto Switch/Refer to pages 1719 to 1827 for further information on auto switches.

			light		L	Load voltage		Auto switch model		Auto switch model		Lead wire length (m) *			(m) *									
Туре	Special function	Electrical	cator	(Output)	DC				10					0.5	3	5	None	Pre-wired	Appli	cable				
		entry	Indi	(Output)	L				Perpendicular	In-line	(Nil)	(L)	(Z)	(N)	CONNECTOR	10	au							
				3-wire (NPN)		5 V, 12 V		F7NV	F79			0	—	0	IC									
		Grommet		3-wire (PNP)			5 V, 12 V	F7PV	F7P			0	—	0	circuit									
ch				0 mine				F7BV	J79			0	—	0		1								
٧i		Connector	1	∠-wire		12 V		J79C	-	•		•	•	_	-									
e S				3-wire (NPN)	24 V .			F7NWV	F79W			0		0	IC	Relay.								
tat	Diagnostic indication		Yes	3-wire (PNP)		5 V, 12 V	• V 5 V, 12 V		– F7PW	•	•	0	—	0	circuit	PLC								
o p	(2-color indication)			, <i>,</i> , ,	2-wire 12 V wire (NPN) 5 V, 12 V	12 V	F7BWV	J79W		•	0	_	0											
i	Water resistant	Grommet		2-wire			v I I	-	F7BA	_	•	0	—	0	1 —									
S	(2-color indication)								F7BAV	-	_	•	0	_	0									
	With diagnostic output (2-color indication)			4-wire (NPN)		5 V, 12 V		_	F79F		•	0	_	0	IC circuit	1								
-			V	3-wire (NPN equivalent)	_	5 V	_	-	A76H	•	•	_	_	_	IC circuit	_								
itch		Grommet	res		_	—	200V	A72	A72H			—	—	_										
l sv	_					12 V	100V	A73	A73H				_	_	1 —	Delaw								
eec			No	2-wire 24 V	04 14	5 V, 12 V	100V or less	A80	A80H			—	_	_	IC circuit	Relay,								
<u>م</u>		<u> </u>	Yes		24 V	24 V	24 V	24 V	24 V	24 V	24 V	24 V	24 V	24 V	12 V		A73C	_	•	•	•		_	_
		Connector	No			5 V, 12 V	_	A80C	_	•	•	•		_	IC circuit	1								
* Lead wire length symbols: 0.5 m Nil (Example) J79W 3 m L (Example) J79WL * Solid state auto switches marked with "O" are produced upon receipt of order.																								

5 m ······· Z (Example) J79WZ

None N (Example) J79CN

Since there are other applicable auto switches than listed, refer to page 976 for details.

• For details about auto switches with pre-wired connector, refer to pages 1784 and 1785.

* Auto switches are shipped together (not assembled).



Made to Order Specifications (For details, refer to pages 2016 and 2017.)

Specifications -X431 Auto switch rails on both side faces (With 2 pcs.) -X168 Helical insert thread specifications

Made to Order

Symbol

Specifications

Bore size (mm)	10	15	20	25	32	40		
Fluid	Air							
Proof pressure			1.05	MPa				
Maximum operating pressure	imum operating pressure 0.7 MPa							
Minimum operating pressure	e 0.18 MPa							
Ambient and fluid temperature	-10 to 60°C							
Piston speed (Max.) Note) 50 to 300 mm/s								
Lubrication	Not required (Non-lube)							
Stroke length tolerance	e 0 to 250 st: ^{+1.0} ₀ , 251 to 1000 st: ^{+1.4} ₀ , 1001 st or longer: ^{+1.8} ₀							
Holding force	53.9	53.9 137 231 363 588 922						

Note) Piston speed above indicates the maximum speed. It takes approximately 0.5 seconds (for one side) after the slide block moves from the stroke end until it goes through the cushion stroke, while it takes approximately 1 second for both sides.

Standard Stroke

-		
Bore size (mm)	Standard stroke (mm)	Maximum manufacturable stroke (mm)
10	150, 200, 250, 300	500
15	150, 200, 250, 300, 350, 400, 450, 500	750
20		1000
25	200, 250, 300, 350, 400, 450, 500, 600, 700, 800	1500
32		1500
40	200, 250, 300, 350, 400, 450, 500, 600, 700, 800, 900, 1000	1500

Note) Intermediate stroke is available by the 1 mm interval.

Mass

						(kg)	
Bore size (mm)	10	15	20	25	32	40	R
Basic mass	0.580	1.10	1.85	2.21	4.36	4.83	D
Additional mass per each 50 mm of stroke	0.077	0.104	0.138	0.172	0.267	0.406	n

Calculation: (Example) **REAL32-500** • Basic mass ------ 4.36 kg • Additional mass ----- 0.267/50 st • Cylinder stroke ------ 500 st 4.36 + 0.267 x 500 ÷ 50 = 7.03 kg

REA
REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ





Series **REAL**

Construction: ø10, ø15



REAL10

Component Parts

No.	Description	Material	Note
1	Cylinder tube	Stainless steel	
2	External slider tube	Aluminum alloy	
3	Shaft	Stainless steel	
4	Piston side yoke	Rolled steel plate	Zinc chromated
5	External slider side yoke	Rolled steel plate	Zinc chromated
6	Magnet A	—	
7	Magnet B	—	
8	Cushion seal holder	Aluminum alloy	Anodized
9	Piston	Brass	Electroless nickel plated
10	Slide block	Aluminum alloy	Hard anodized
11	Spacer	Rolled steel plate	Nickel plated
12	Slider spacer	Rolled steel plate	Nickel plated
13	Retaining ring	Carbon tool steel	Nickel plated
14	Ball bushing	—	
15	Retaining ring	Carbon tool steel	Nickel plated
16	Cushion ring	Stainless steel	
17	Plate A	Aluminum alloy	Hard anodized

Replacement Parts: Seal Kit

Bore size (mm)	Kit no.	Contents
10	REAL10-PS	Set of nos. above Note)
15	REAL15-PS	28, 29, 30, 31, 32, 33, 34

Note) It may be difficult to replace the cushion seal 34.

Seal kit includes a grease pack (a10: 5 g and 10 g).
 Order with the following part number when only the grease pack is needed.

For ø10 grease pack part no.: GR-F-005 $(5\ g)$ For external sliding part GR-S-010 $(10\ g)$ For tube interior

For ø15 grease pack part no.: GR-S-010 (10 g)

Component Parts

No.	Description	Material	Note
18	Plate B	Aluminum alloy	Hard anodized
19	Guide shaft A	Carbon steel	Hard chrome plated
20	Guide shaft B	Carbon steel	Hard chrome plated
21	Adjusting bolt A	Chromium molybdenum steel	Nickel plated
22	Adjusting bolt B	Chromium molybdenum steel	Nickel plated
23	Hexagon nut	Carbon steel	Nickel plated
24	Grease nipple	Carbon steel	Nickel plated (Except REAL10)
25	Magnet for auto switch	—	
26	Switch mounting rail	Aluminum alloy	
27	Auto switch	—	
28 *	Cylinder tube gasket	NBR	
29 *	Guide shaft gasket	NBR	
30 *	Wear ring A	Special resin	
31 *	Wear ring B	Special resin	
32 *	Piston seal	NBR	
33 *	Scraper	NBR	
34 *	Cushion seal	NBR	

* Seal kit includes (28) to (34). Order the seal kit, based on each bore size.



Construction: ø20 to ø40



Component Parts

No.	Description	Material	Note	
1	Cylinder tube	Stainless steel		
2	External slider tube	Aluminum alloy		
3	Shaft	Stainless steel		
4	Piston side yoke	Rolled steel plate	Zinc chromated	
5	External slider side yoke	Rolled steel plate	Zinc chromated	
6	Magnet A	—		
7	Magnet B	—		
8	Piston side spacer	Aluminum alloy	Chromated	
9	Bumper	Urethane rubber		
10	Cushion seal holder	Aluminum alloy	Chromated	
11	Piston	Aluminum alloy	Chromated	
12	Slide block	Aluminum alloy	Hard anodized	
13	Spacer	Rolled steel plate	Nickel plated	
14	Slider spacer	Carbon steel	Nickel plated	
15	Retaining ring	Carbon tool steel	Nickel plated	
16	Ball bushing	—		
17	Retaining ring	Carbon tool steel	Nickel plated	
18	Cushion ring holder	Aluminum alloy	Anodized	
10	Cuchien ring	Brass	Electroless nickel plated (REAL32, 40)	
19	Cushion ring	Stainless steel	REAL20, 25	

Replacement Parts: Seal Kit

Bore size (mm)	Kit no.	Contents	
20	REAL20-PS		
25	REAL25-PS	Set of nos. above	
32	REAL32-PS	(32), (33), (34), (35) (36), (37), (38)	
40	REAL40-PS		

Note) It may be difficult to replace the cushion seal 38.

Seal kit includes a grease pack (10 g). Order with the following part number when only the grease pack is needed. Grease pack part no.: GR-S-010 (10 g)

Component Parts

No.	Description	Material	Note	
20	Lock nut B	Carbon steel	Nickel plated	
21	Plate A	Aluminum alloy	Hard anodized	
22	Plate B	Aluminum alloy	Hard anodized	
23	Guide shaft A	Carbon steel	Hard chrome plated	
24	Guide shaft B	Carbon steel	Hard chrome plated	DEA
25	Adjusting bolt A	Chromium molybdenum steel	Nickel plated	KEA
26	Adjusting bolt B	Chromium molybdenum steel	Nickel plated	DED
27	Hexagon nut	Carbon steel	Nickel plated	KER
28	Grease nipple	Brass	Nickel plated	DEO
29	Magnet for auto switch	—		REC
30	Switch mounting rail	Aluminum alloy		
31	Auto switch	—		UΠλ
32 *	Cylinder tube gasket	NBR		
33 *	Guide shaft gasket	NBR		ULIX
34 *	Wear ring A	Special resin		
35 *	Wear ring B	Special resin		WU
36 *	Piston seal	NBR		БША
37 *	Scraper	NBR		KHC
38 *	Cushion seal	NBR		D70
ا ادم؟ *	kit includes 30 to 38 Ord	or the seal kit based on	each hore size	KZŲ

* Seal kit includes 3 to 3. Order the seal kit, based on each bore size.

D-🗆
-X □
Individual
-X□

Series **REAL**

Dimensions: ø10



Sine Rodless Cylinder Slider Type/Ball Bushing Bearing Series REAL

Dimensions: ø15 to ø40



Model	Α	В	С	D	d	EA	EB	FA	FB	G	GP	Н	HA	HB	HG	HI	НО	HP
REAL15	7.5	9.5	5	16.6	12	6	13	3	6	6.5	65	40	6.5	4	16	14	38	39
REAL20	9.5	9.5	5	21.6	16	_	-	—	_	8.5	80	46	9	10	18	16	44	45
REAL25	9.5	11	6.5	26.4	16	8	14	4	7	8.5	90	54	9	18	23	21	52	53
REAL32	10.5	14	8	33.6	20	8	16	5	7	9.5	110	66	12	26.5	26.5	24.5	64	64
REAL40	11.5	14	8	41.6	25	10	20	5	10	10.5	130	78	12	35	30.5	28.5	76	74

															DEO	
Madal	це	υт		и		10	м	NANA	N	N	NINI		Р		DA *	REC
Model	пэ	пі	J	JK	L	LD	IVI	IVIIVI	IN	ININ	Nil	TN	TF	FA		
REAL15	25	21	M6 x 1.0	9.5	75	5.6	8	M5 x 0.8	7.5	M8 x 1.0	M5 x 0.8	—		45	UΠλ	
REAL20	31	10	M6 x 1.0	10	86	5.6	10	M6 x 1.0	10	M10 x 1.0	Rc 1/8	NPT 1/8	G 1/8	50		
REAL25	39	10	M8 x 1.25	10	86	7	10	M6 x 1.0	11	M14 x 1.5	Rc 1/8	NPT 1/8	G 1/8	60	UUX	
REAL32	47.5	17	M10 x 1.5	15	100	9.2	12	M8 x 1.25	11.5	M20 x 1.5	Rc 1/8	NPT 1/8	G 1/8	70		
REAL40	56	14	M10 x 1.5	15	136	9.2	12	M8 x 1.25	10.5	M20 x 1.5	Rc 1/4	NPT 1/4	G 1/4	90	WU	

Model	PB	PW	Q	QW	RW	S	Т	TT	ta	tb	W	Z
REAL15	70	95	90	30	15	77	12.5	22.5	0.5	1.0	92	112
REAL20	90	120	105	40	28	88	16.5	25.5	_	_	117	130
REAL25	100	130	105	50	22	88	16.5	25.5	0.5	1.0	127	130
REAL32	120	160	121	60	33	102	18.5	28.5	0.5	1.0	157	149
REAL40	140	190	159	84	35	138	20.5	35.5	1.0	1.0	187	194

* PA dimensions are for split from center.

RHC RZQ

REA

REB

Series **REAL**

Auto Switch Proper Mounting Position (Detection at Stroke End)



						(mm)		
Auto switch		A dimension		B dimension				
Bore size (mm)	D-A73/A80	D-A72 D-A7□H/A80H D-A73C/A80C D-F7□/J79 D-F7□WJ79W D-J79C D-F70W/F7□WV D-F7BA□ D-F79F	D-F7NTL	D-A73/A80	D-A72 D-A72H/A80H D-A73C/A80C D-F72/J79 D-F72W/J79W D-J79C D-F70K/72WV D-F78A D-F79F	D-F7NTL		
10	58	58.5	63.5	45	44.5	39.5		
15	65	65.5	70.5	47	46.5	41.5		
20	76	76.5	81.5	54	53.5	48.5		
25	76	76.5	81.5	54	53.5	48.5		
32	92	92.5	97.5	57	56.5	51.5		
40	130	130.5	135.5	64	63.5	58.5		

Note) Adjust the auto switch after confirming the operating conditions in the actual setting.

Operating Range

(mm)

Auto awitab madal	Bore size (mm)									
Auto Switch model	10	15	20	25	32	40				
D-A7□, A8□	6	6	6	6	6	6				
D-F7□, J7□, F79F	3	4	3	3	3	3.5				

 \ast Since this is a guideline including hysteresis, not meant to be guaranteed. (assuming approximately $\pm 30\%$ dispersion)

There may be the case it will vary substantially depending on an ambient environment.

Other than the models listed in "How to Order", the following auto switches are applicable. For detailed specifications, refer to page 1770.									
Auto switch type Model Electrical entry (Fetching direction) Features									
Solid state	D-F7NTL	Grommet (In-line)	With timer						
 For solid state auto swite Refer to pages 1784 and 	hes, auto switche I 1785 for details.	s with a pre-wired connector a	are also available.						



Series REAL Specific Product Precautions

Be sure to read before handling. Refer to front matters 42 and 43 for Safety Instructions and pages 3 to 11 for Actuator and Auto Switch Precautions.

Operation

Warning

1. Be aware of the space between the plates and the slide block.

Take sufficient care to avoid getting your hands or fingers caught when the cylinder is operated.

2. Do not apply a load to a cylinder which is greater than the allowable value stated in the "Model Selection" pages.

It may cause malfunction.

- 3. Consult with SMC when the cylinder is operated in an environment in which the cylinder is exposed to cutting fluid or water, or the cylinder sliding part lubrication deteriorates.
- 4. When applying grease to the cylinder, use the grease already used for the product. Contact SMC, grease packs are available.

Mounting

A Caution

1. Avoid operation with the external slider fixed to the mounting surface.

The cylinder should be operated with the plates fixed to the mounting surface.

2. Make sure that the cylinder mounting surface has a flatness of 0.2 mm or less.

If the flatness of a workpiece is not appropriate, it may adversely affect the operation since two guide shafts will be twisted. Furthermore, the increase of the sliding resistance and early abrasion of bearings may shorten the service life.

The cylinder mounting surface must have a flatness of 0.2 mm or less, and the cylinder must be mounted so as to be smoothly operated with a minimum operating pressure (0.18 MPa or less) for a full stroke.

Disassembly and Maintenance

A Warning

1. Use caution, the attractive force of the magnets is very strong.

When removing the external slider and piston slider from the cylinder tube for maintenance, etc., handle with caution since the magnet installed in each slider has a very strong attractive force.

A Caution

1. Use caution when taking off the external slider, since the piston slider will be directly attracted to it.

When removing the external slider or piston slider from the cylinder tube, first force the sliders out of their magnetically coupled positions, and then remove them individually when there is no longer any holding force. If they are removed while still magnetically coupled, they will be directly attracted to one another and will not come apart.

2. Do not disassemble the magnetic components (piston and external sliders).

This may cause a loss of holding force and malfunction.



D- □
-X □
Individual -X□

Linear Guide Type Single Axis/Double Axes

Series **REAH/REAHT**

Single Axis: Ø10, Ø15, Ø20, Ø25 Double Axes: Ø25, Ø32



SMC

REA
REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

D- □
- Y
-70
Individual
-X



SMC

Caution on Design 1

The load mass allowable moment differs depending on the workpiece mounting method, cylinder mounting orientation and piston speed. In making a determination of usability, do not allow the sum ($\Sigma \alpha$ n) of the load factors (α n) for each mass and moment to exceed "1".







Maximum speed U (mm/s)

REA

REB

REC

C

C 🗆 X

MQ

RHC

RZQ

D-🗆

-X□ Individual -X□

Selection Calculation -

The selection calculation finds the load factors (Ω n) of the items below, where the total ($\Sigma \Omega$ n) does not exceed 1.

$\Delta \Omega n =$	$\alpha_1 + \alpha_2 + \alpha_3 \leq 1$		
Item	Load factor $lpha$ n	Note	
1. Max. load mass	$\Omega_1 = W/Wmax$	Review W.	
2. Static moment	CL2 = M/Mmax	Review M1, M2, M3. Mmax is the allowable moment.	
3. Dynamic moment	CC3 = Me/Memax	Review Me1, Me3. Memax is the allowable moment.	
		U: Maximum speed	
louistion Example			
	ing Conditions —		- n -
Operat			

Cylinder: REAH15 Mounting: Horizontal wall mounting style Maximum speed: **U** = 300 [mm/s] Load mass: W = 1 [kg] (Except mass of arm section) L1 = 200 [mm] L2 = 200 [mm]

Item	Load factor $lpha$ n	Note
1. Maximum load mass	α1 = W/Wmax = 1/9 = 0.111	Examine W.
2. Static moment		Examine M2. Since M1 & M3 are not generated, investigation is unnecessary.
3. Dynamic moment	$We = 5 \times 10^{-3} \cdot W \cdot g \cdot U$ = 5 x 10 ⁻³ · 1 · 9.8 · 300 = 15 [N] Mes = 1/3 · We (L2-A) = 1/3 · 15 · 0.182 = 0.91 [N·m] O(3 = Mes/Mesmax = 0.91/10 = 0.091	Examine Me3.
	$Me1 = 1/3 \cdot We \cdot L1$ = 1/3 \cdot 15 \cdot 0.2 = 1 [N·m] Q4 = Me1 / Me1max = 1/10 = 0.1	Examine Me1.

 $\Sigma \Omega n = \Omega 1 + \Omega 2 + \Omega 3 + \Omega 4$

= 0.111 + 0.125 + 0.091 + 0.10 = 0.427 Can be used base on $\Sigma \alpha n = 0.427 \le 1$ 982

SMC

Caution on Design 2





Note) Deflection when a moment other than the above is applied can be specified by extending the lines in the graphs above.

Vertical Operation

When using in vertical operation, prevention of workpiece dropping due to breaking of the magnetic coupling should be considered. The allowable load mass and maximum operating pressure should be as shown in the table below. When the cylinder is mounted vertically or sidelong, sliders may move downwards due to the self-weight or workpiece mass. If an accurate stopping position is required at the stroke end or the middle-

Model	Allowable load mass Wv (kg)	Maximum operating pressure Pv (MPa)
REAH10	2.7	0.55
REAH15	7.0	0.65
REAH20	11.0	0.65
REAH25	18.5	0.65
REAHT25	18.5	0.65
REAHT32	30.0	0.65

oke end or the middlestroke, use an external stopper to secure accurate positioning.

∕⊘SMC

Intermediate Stop

The cushion effect (smooth start-up, soft stop) exists only before the stroke end in the stroke ranges indicated in the table below. The cushion effect (smooth start-up, soft stop) cannot be obtained in an intermediate stop or a return from an intermediate stop using an external stopper, etc.

Cushion Stroke

Model	Stroke (mm)
REAH10	20
REAH15	25
REAH20	30
REAH25	30
REAHT25	30
REAHT32	30



D -□
-X□
Individual -X□

Series REAH

Stroke Adjustment

The adjusting bolt is adjusted to the optimum position for smooth acceleration and deceleration at the time of shipment, and should be operated at the full stroke. When stroke adjustment is necessary, the maximum amount of adjustment on one side is 2 mm. (Do not adjust more than 2 mm, as it will not be possible to obtain smooth acceleration and deceleration.)

Do not adjust based on the stopper's movement, as this can cause cylinder damage.

Stroke adjustment method

Loosen the round head Phillips screws, and remove the top covers and dust covers (4 pcs.). Then loosen the hexagon nut, and after performing the stroke adjustment from the plate side with a hexagon wrench, retighten and secure the hexagon nut.



Adjusting Bolt Position (at the time of shipment), Hexagon Nut Tightening Torque

Model	T (mm)	Tightening torque (N·m)
REAH10	7	
REAH15	7	1.67
REAH20	7	
REAH25	9	
REAHT25	9	3.14
REAHT32	9	

After adjusting the stroke, replace the top covers and dust covers. Tighten the round head Phillips screws for securing the top covers with a torque of 0.58 N·m.

Sine Rodless Cylinder Linear Guide Type Series REAH Single Axis: Ø10, Ø15, Ø20, Ø25/Double Axes: Ø25, Ø32



									DED																						
			light	Miring		Load volt	oad voltage		Auto switch model		ength (m)*		ad wire length (m)*		Durand			NEB													
Туре	Special function	Electrical	cator	(Output)		DC	10			0.5	3	5	Pre-wired	Applic	cable load																
		entry	lndi	(Output)			AC.	Perpendicular	In-line	(Nil)	(L)	(Z)	CONTRECTO			REC															
				3-wire (NPN)		EV 10 V		Y69A	Y59A			0	0	IC																	
_ fe	_			3-wire (PNP)		5 V, 12 V		Y7PV	Y7P			0	0	circuit		C⊡Y															
tch	G Diagnostic indication (2-color indication)	Crommet	V	2-wire	24.11	12V		Y69B	Y59B			0	0	—	Relav.																
swi		Gronninet	res	3-wire (NPN)		24 V	5 V 40 V	5.V. 40.V	5.1. 40.1	514014			5 V 40 V	5.V. 40.V	EV 10.V	1 40.1	<u></u>		Y7NWV	Y7NW			0	0	IC	PLC	nπv				
Diagnostic in (2-color ind		(2-color indication)	Diagnostic indication	Diagnostic indication	Diagnostic indication	Diagnostic indication	ostic indication										3-wire (PNP)	NP)	5 V, 12 V	'			Y7PWV	Y7PW			0	0	circuit		
					2-wire		12 V		Y7BWV	Y7BW			0	0	—																
				3-wire		5 V			776					IC		MQ															
Reed switch	_	Promoted Ves (NPN equivalent) - 5 V - 276	•		-	_	circuit	_																							
		-		2 wire	12 V	100 V	_	Z73				—	_	Relay,	RHC																
			_		24 V	5 V,12 V	100 V or less	_	Z80			—	_	IC circuit	PLC																
								D70																							

* Lead wire length symbols: 0.5 m.....Nil (Example) Y7BW

 \ast Solid state auto switches marked with "O" are produced upon receipt of order.

3 m······L (Example) Y7BWL 5 m······Z (Example) Y7BWZ

 \cdot Since there are other applicable auto switches than listed, refer to page 993 for details.

For details about auto switches with pre-wired connector, refer to pages 1784 and 1785.

* Auto switches are shipped together (not assembled).

Series **REAH**



Specifications

Bore size (mm)	10	15	20	25	32	
Fluid	Air					
Action	Double acting					
Maximum operating pressure	0.7 MPa					
Minimum operating pressure	0.2 MPa					
Proof pressure	1.05 MPa					
Ambient and fluid temperature	rature -10 to 60°C					
Piston speed (Max.) Note) 70 to 300 mm/s						
Lubrication		Not re	quired (Nor	n-lube)		
Stroke length tolerance		(0 to 1.8 mn	ı		
Piping	Centralized piping type					
Piping port size	M5 x 0.8 1/8					
Holding force (N)	53.9	137	231	363	588	

Note) Piston speed above indicates the maximum speed. It takes approximately 0.5 seconds (for one side) after the slide block moves from the stroke end until it goes through the cushion stroke, while it takes approximately 1 second for both sides.

Standard Stroke



Symbol	Specifications
—XB10	Intermediate stroke (Using exclusive body)
—X168	Helical insert thread specifications

Bore size (mm)	Number of axes	Standard stroke (mm)	Maximum manufacturable stroke (mm)
10		150, 200, 300	500
15		150, 200, 300, 400, 500	750
20	1 axis	200, 300, 400, 500, 600	1000
25		200, 300, 400, 500, 600, 800	1000
25	0 0 000	200, 200, 400, 500, 600, 800, 1000	1200
32	2 axes	200, 300, 400, 300, 600, 800, 1000	1500

Note 1) Stroke exceeding the standard stroke will be available upon request for special.

Note 2) Intermediate strokes other than made-to-order (refer to -XB10) are available as special.

Mass

								(kg)
Madal			ę	Standard s	troke (mm	ı)		
Model	150	200	300	400	500	600	800	1000
REAH10	1.2	1.3	1.6	—	—	—	—	_
REAH15	2.5	2.7	3.2	3.6	4.1	—	—	_
REAH20	_	3.5	4.0	4.4	4.9	5.4	—	_
REAH25	_	5.3	6.0	6.6	7.3	8.0	9.4	_
REAHT25		6.2	7.3	8.3	9.4	10.4	12.5	14.6
REAHT32	_	9.6	10.7	11.9	13.0	14.2	16.5	18.8

Theoretical Output

_							(N)
Bore size	Piston area		Op	perating pro	essure (MF	Pa)	
(mm)	(mm²)	0.2	0.3	0.4	0.5	0.6	0.7
10	78	15	23	31	39	46	54
15	176	35	52	70	88	105	123
20	314	62	94	125	157	188	219
25	490	98	147	196	245	294	343
32	804	161	241	322	402	483	563

Note) Theoretical output (N) = Pressure (MPa) x Piston area (mm²)



Construction: ø10, ø15



Component Parts

No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Cylinder tube	Stainless steel	
3	External slider tube	Aluminum alloy	
4	Shaft	Stainless steel	
5	Piston side yoke	Rolled steel plate	Zinc chromated
6	External slider side yoke	Rolled steel plate	Zinc chromated
7	Magnet A	_	
8	Magnet B	_	
9	Piston	Brass	Electroless nickel plated
10	Spacer	Rolled steel plate	Nickel plated
11	Space ring	Aluminum alloy	Chromated (Except REAH10)
12	Slide table	Aluminum alloy	Hard anodized
13	Side plate A	Aluminum alloy	Hard anodized
14	Side plate B	Aluminum alloy	Hard anodized
15	Cushion ring	Stainless steel	
16	Internal stopper	Aluminum alloy	Anodized
17	Plate A	Aluminum alloy	Hard anodized

Replacement Parts: Seal Kit

Bore size (mm)	Kit no.	Contents
10	REAH10-PS	Set of nos. above
15	REAH15-PS	28, 29, 30, 31, 32, 33, 34

Note) It may be difficult to replace the cushion seal 34.

* Seal kit includes a grease pack (ø10: 5 g and 10 g, ø15: 10 g). Order with the following part number when only the grease pack is needed.

For ø10 grease pack part noniber when only the grease pack is needed. GR-F-005 (5 g) For external sliding part GR-S-010 (10 g) For tube interior

For ø15 grease pack part no.: GR-S-010 (10 g)

Component Parts

No.	Description	Material	Note	
18	Plate B	Aluminum alloy	Hard anodized	
19	Stopper	Aluminum alloy	Anodized	
20	Adjusting bolt	Chromium molybdenum steel	Nickel plated	REA
21	Hexagon nut	Carbon steel	Nickel plated	
22	Linear guide			REB
23	Top cover	Aluminum alloy	Hard anodized	
24	Dust cover	Special resin		REC
25	Magnet (for auto switch)	—		
26	Parallel pin	Carbon steel	Nickel plated	C
27	Square nut for body mounting	Carbon steel	Nickel plated (Accessory)	
28*	Wear ring A	Special resin		C
29*	Wear ring B	Special resin		
30 *	Piston seal	NBR		MQ
31 *	Scraper	NBR		
32*	O-ring	NBR		RHC
33*	O-ring	NBR		
34*	Cushion seal	NBR		RZO
	0 0			

Note 1) Seal kit includes B to B. Order the seal kit, based on each bore size. Note 2) Square nut for body mounting D: 4 pieces

D- □
-X □
Individual -X□

Series **REAH**

Construction: ø20, ø25

Single axis type: REAH



Component Parts

No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Cylinder tube	Stainless steel	
3	External slider tube	Aluminum alloy	
4	Shaft	Stainless steel	
5	Piston side yoke	Rolled steel plate	Zinc chromated
6	External slider side yoke	Rolled steel plate	Zinc chromated
7	Magnet A	_	
8	Magnet B	_	
9	Bumper	Urethane rubber	
10	Cushion seal holder	Aluminum alloy	Chromated
11	Piston	Aluminum alloy	Chromated
12	Spacer	Rolled steel plate	Nickel plated
13	Space ring	Aluminum alloy	Chromated
14	Slide table	Aluminum alloy	Hard anodized
15	Side plate A	Aluminum alloy	Hard anodized
16	Side plate B	Aluminum alloy	Hard anodized
17	Cushion ring	Stainless steel	
18	Internal stopper	Aluminum alloy	Anodized

Replacement Parts: Seal Kit

Bore size (mm)	Kit no.	Contents
20	REAH20-PS	Set of nos. above
25	REAH25-PS	30, 31, 32, 33, 34, 35, 36

Note) It may be difficult to replace the cushion seal (36).

* Seal kit includes a grease pack (10 g).

Order with the following part number when only the grease pack is needed. Grease pack part no.: GR-S-010 (10 g)

Component Parts

No.	Description	Material	Note
19	Plate A	Aluminum alloy	Hard anodized
20	Plate B	Aluminum alloy	Hard anodized
21	Stopper	Aluminum alloy	Anodized
22	Adjusting bolt	Chromium molybdenum steel	Nickel plated
23	Hexagon nut	Carbon steel	Nickel plated
24	Linear guide		
25	Top cover	Aluminum alloy	Hard anodized
26	Dust cover	Special resin	
27	Magnet (for auto switch)	—	
28	Parallel pin	Carbon steel	Nickel plated
29	Square nut for body mounting	Carbon steel	Nickel plated (Accessory)
30 *	Wear ring A	Special resin	
31 *	Wear ring B	Special resin	
32 *	Piston seal	NBR	
33 *	Scraper	NBR	
34 *	O-ring	NBR	
35 *	O-ring	NBR	
36 *	Cushion seal	NBR	

Note 1) Seal kit includes 30 to 30. Order the seal kit, based on each bore size. Note 2) Square nut for body mounting 30: 4 pieces



Construction: ø25, ø32



Component Parts

No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Cylinder tube	Stainless steel	
3	External slider tube	Aluminum alloy	
4	Shaft	Stainless steel	
5	Piston side yoke	Rolled steel plate	Zinc chromated
6	External slider side yoke	Rolled steel plate	Zinc chromated
7	Magnet A	—	
8	Magnet B	—	
9	Bumper	Urethane rubber	
10	Cushion seal holder	Aluminum alloy	Chromated
11	Piston	Aluminum alloy	Chromated
12	Spacer	Rolled steel plate	Nickel plated
13	Space ring	Aluminum alloy	Chromated (Except REAHT32)
14	Slide table	Aluminum alloy	Hard anodized
15	Side plate	Aluminum alloy	Hard anodized (Except REAHT32)
	Cuchion ring	Brass	Electroless nickel plated (REAHT32)
10	Cushion mig	Stainless steel	REAHT25
17	Internal stopper	Aluminum alloy	Anodized

Replacement Parts: Seal Kit

25 REAHT25-PS Set of nos. above	Bore size (mm)	Kit no.	Contents
	25	REAHT25-PS	Set of nos. above
32 REAHT32-PS	32	REAHT32-PS	29, 30, 31, 32, 33, 34, 35

Note) It may be difficult to replace the cushion seal (35).

* Seal kit includes a grease pack (10 g).

Order with the following part number when only the grease pack is needed. Grease pack part no.: GR-S-010 (10 g)

Component Parts

	-			
No.	Description	Material	Note	
18	Plate	Aluminum alloy	Hard anodized	DEA
19	Stopper	Aluminum alloy	Anodized	ne/A
20	Adjusting bolt	Chromium molybdenum steel	Nickel plated	DED
21	Hexagon nut	Carbon steel	Nickel plated	NED
22	Linear guide			DEC
23	Top cover	Aluminum alloy	Hard anodized	REC
24	Dust cover	Special resin		rπv
25	Magnet (for auto switch)	—		UΠI
26	Parallel pin	Carbon steel	Nickel plated	∩ ⊓v
27	Square nut for body mounting	Carbon steel	Nickel plated (Accessory)	
28	Hexagon socket head taper plug	Carbon steel	Nickel plated	MO
29 *	Wear ring A	Special resin		wių
30 *	Wear ring B	Special resin		рце
31 *	Piston seal	NBR		ппс
32 *	Scraper	NBR		D70
33 *	O-ring	NBR		nzų
34 *	O-ring	NBR		
35 *	Cushion seal	NBB		

Note 1) Seal kit includes 29 to 35. Order the seal kit, based on each bore size. Note 2) Square nut for body mounting (27): 4 pieces

D- □	
-X □	
Individual -X□	



Series **REAH**

Dimensions: ø10

Single axis type: REAH



Sine Rodless Cylinder Linear Guide Type Series REAH

Dimensions: ø15, ø20, ø25

Single axis type: REAH



					-						-				-	
Α	EA	EB	н	HA	НВ	HC	HG	HP	НТ	J	L	LL	LW	М	ММ	
97	26.5	21	46	33.5	33.5	45	17	42	19	M5 x 0.8	106	44	71.5	M5 x 0.8	8	
102.5	26.5	22	54	42.5	41.5	53	16	50	23.5	M5 x 0.8	108	48.5	75.5	M5 x 0.8	8	F
125	29	24	63	46	46	61.5	25	58.5	28	M6 x 1.0	138	56	86	M6 x 1.0	10	Ľ
	A 97 102.5 125	AEA9726.5102.526.512529	A EA EB 97 26.5 21 102.5 26.5 22 125 29 24	A EA EB H 97 26.5 21 46 102.5 26.5 22 54 125 29 24 63	A EA EB H HA 97 26.5 21 46 33.5 102.5 26.5 22 54 42.5 125 29 24 63 46	A EA EB H HA HB 97 26.5 21 46 33.5 33.5 102.5 26.5 22 54 42.5 41.5 125 29 24 63 46 46	A EA EB H HA HB HC 97 26.5 21 46 33.5 33.5 45 102.5 26.5 22 54 42.5 41.5 53 125 29 24 63 46 46 61.5	A EA EB H HA HB HC HG 97 26.5 21 46 33.5 33.5 45 17 102.5 26.5 22 54 42.5 41.5 53 16 125 29 24 63 46 46. 61.5 25	A EA EB H HA HB HC HG HP 97 26.5 21 46 33.5 33.5 45 17 42 102.5 26.5 22 54 42.5 41.5 53 16 50 125 29 24 63 46 46 61.5 25 58.5	A EA EB H HA HB HC HG HP HT 97 26.5 21 46 33.5 33.5 45 17 42 19 102.5 26.5 22 54 42.5 41.5 53 16 50 23.5 125 29 24 63 46 46. 61.5 25 58.5 28	A EA EB H HA HB HC HG HP HT J 97 26.5 21 46 33.5 33.5 45 17 42 19 M5 x 0.8 102.5 26.5 22 54 42.5 41.5 53 16 50 23.5 M5 x 0.8 125 29 24 63 46 46.5 25 58.5 28 M6 x 1.0	A EA EB H HA HB HC HG HP HT J L 97 26.5 21 46 33.5 33.5 45 17 42 19 M5 x 0.8 106 102.5 26.5 22 54 42.5 41.5 53 16 50 23.5 M5 x 0.8 108 125 29 24 63 46 46.6 61.5 25 58.5 28 M6 x 1.0 138	A EA EB H HA HB HC HG HP HT J L LL 97 26.5 21 46 33.5 33.5 45 17 42 19 M5 x 0.8 106 44 102.5 26.5 22 54 42.5 41.5 53 16 50 23.5 M5 x 0.8 108 48.5 125 29 24 63 46 61.5 25 58.5 28 M6 x 1.0 138 56	A EA EB H HA HB HC HG HP HT J L LW 97 26.5 21 46 33.5 33.5 45 17 42 19 M5 x 0.8 106 44 71.5 102.5 26.5 22 54 42.5 41.5 53 16 50 23.5 M5 x 0.8 108 48.5 75.5 125 29 24 63 46 61.5 25 58.5 28 M6 x 1.0 138 56 86	A EA EB H HA HB HC HG HP HT J L LW MM 97 26.5 21 46 33.5 33.5 45 17 42 19 M5 x 0.8 106 44 71.5 M5 x 0.8 102.5 26.5 22 54 42.5 41.5 53 16 50 23.5 M5 x 0.8 108 48.5 75.5 M5 x 0.8 125 29 24 63 46 61.5 25 58.5 28 M6 x 1.0 138 56 86 M6 x 1.0	A EA EB H HA HB HC HG HP HT J L LW LW M MM 97 26.5 21 46 33.5 33.5 45 17 42 19 M5 x 0.8 106 44 71.5 M5 x 0.8 8 102.5 26.5 22 54 42.5 41.5 53 16 50 23.5 M5 x 0.8 108 48.5 75.5 M5 x 0.8 8 125 29 24 63 46 61.5 25 58.5 28 M6 x 1.0 138 56 86 M6 x 1.0 10

Madal	N	NI	NT	Р			DA	DR	DD	6	TW	w	VD	7	77
Model	IN	INL		Nil	TN TF		PA	PD	PP	3	1 1 1	VV	VD	2	~~~
REAH15	16.5	15	8	M5 x 0.8	_	—	50	62	21	161	65	88.5		194	17.5
REAH20	18	15	8	Rc 1/8	NPT 1/8	G 1/8	50	65	23	169	70	92.5	_	205	19.5
REAH25	20.5	18	9	Rc 1/8	NPT 1/8	G 1/8	65	75	27	209	75	103	9.5	250	23.5

REA
REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

D- □
-X□
Individual -X□

Series **REAH**

Dimensions: ø25, ø32

Double axis type: REAHT



Model	Α	EA	EB	Н	HA	HB	HC	HG	HP	HT	J	LL	LW	М	MM	Ν
REAHT25	125	28.5	79	63	46	46	61.5	19.5	58.5	35	M6 x 1.0	56	119	M6 x 1.0	10	20.5
REAHT32	132.5	30	90	75	52.5	57.5	72.5	25	69.5	43	M8 x 1.25	63.5	130	M8 x 1.25	12	23

Madal	NI	NIT	Р			ВА	PB	DD	DC	c	тw		ХВ	z
Model			Nil	TN	TF	F		PP	P3	3	IVV	vv	VD	2
REAHT25	18	9	Rc 1/8	NPT 1/8	G 1/8	65	108	18	51	209	110	136	9.5	250
REAHT32	22.5	12	Rc 1/8	NPT 1/8	G 1/8	66	115	14	61	219	124	150	2	265

Auto Switch Proper Mounting Position (Detection at Stroke End)



Auto Switch Proper Mounting Position

Auto switch		Α		В					
model Cylinder model	D-Z7⊡ D-Z80	D-Y7⊡W D-Y7⊡WV	D-Y5□ D-Y6□ D-Y7P D-Y7PV	D-Z7⊡ D-Z80	D-Y7□W D-Y7□WV	D-Y5 D-Y6 D-Y7P D-Y7PV			
REAH10		65.5		59.5					
REAH15		72		122					
REAH20		77.5		127.5					
REAH25		86			164				
REAHT25		86		164					
REAHT32		82		183					

Note) Adjust the auto switch after confirming the operating conditions in the actual setting.

Operating Range

Operating Range	е					(mm)				
	Bore size (mm)									
Auto switch model		RE	REAHT							
	10	15	20	25	25	32				
D-Z7□, Z8□	8	6	6	6	6	9				
D-Y5□, Y6□, Y7□	6	5	5	5	5	6				

* Since this is a guideline including hysteresis, not meant to be guaranteed. (assuming approximately ±30% dispersion)

There may be the case it will vary substantially depending on an ambient environment.

Auto Switch Lead Wire Containment Groove

On models REAH20 and REAH25 a groove is provided on the side of the body (one side only) to contain auto switch lead wires. This should be used for placement of wiring.



REA
REB
REC
C□Y
C \
MQ
RHC
RZQ



Series REAH Specific Product Precautions

Be sure to read before handling. Refer to front matters 42 and 43 for Safety Instructions and pages 3 to 11 for Actuator and Auto Switch Precautions.

Mounting

A Caution

1. The interior is protected to a certain extent by the top cover, however, when performing maintenance, etc., take care not to cause scratches or other damage to the cylinder tube, slide table or linear guide by striking them or placing objects on them.

Cylinder bores are manufactured to precise tolerances, so that even a slight deformation may cause faulty operation.

2. Because the slider is supported by precision bearings, take care not to apply strong impacts or excessive moments to the table when loading a workpiece.

3. Mounting of the cylinder body

The body is mounted using the square nuts, which are included, in the two T-slots on the bottom of the body. Refer to the table below for mounting bolt dimensions and tightening torque.

Model		REAH10	REAH15	REAH20	REAH25	REAHT25	REAHT32
Bolt	Thread size	M4 x 0.7	M5 :	x 0.8	M6 x	< 1.0	M8 x 1.25
dimensions	Dimension t	<i>l</i> -7	<i>l</i> -8		l-	9	<i>t</i> -12
Tightening torque	N∙m	1.37	2.6	65	4	.4	13.2



Operation

▲ Caution

1. The unit can be used with a direct load within the allowable range, but when connecting to a load which has an external guide mechanism, careful alignment is necessary.

Since variation of the shaft center increases as the stroke becomes longer, a connection method should be devised which allows for this displacement.

- 2. Since the guide is adjusted at the time of shipment, unintentional movement of the adjustment setting should be avoided.
- 3. Please contact SMC before operating in an environment where there will be contact with cutting chips, dust (paper debris, lint, etc.) or cutting oil (gas oil, water, warm water, etc.).
- 4. Do not operate with the magnetic coupling out of position.

In case the magnetic coupling is out of position, push the external slider back into the correct position by hand at the end of the stroke (or correct the piston slider with air pressure).

Direct Mount Type

Series **REBR**

ø15, ø25, ø32



REA
REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

D- □
-X □
Individual -X 🗆





Caution on Design 1

Selection Method





<Data (B): Maximum Speed ——Load mass Chart>

C 🗆 X

MQ

RHC

RZQ

D-🗆

-X□ Individual

-X□

Cylinder Self-weight Deflection

When the cylinder is mounted horizontally, deflection appears due to its own weight as shown in the data, and the longer the stroke, the greater the amount of variation in the shaft centers. Therefore, a connection method should be considered which allows for this variation as shown in the drawing.



Note) Referring to the self-weight deflection in the graph below, provide clearance so that the cylinder does not touch the mounting surface or the load section, and is able to operate smoothly within the minimum operating pressure range for a full stroke.



^{*} The above deflection data indicate values when the external slider has moved to the middle of the stroke.

Caution on Design 2

Vertical Operation

The load should be guided by a ball type bearing (LM guide, etc.). If a slide bearing is used, sliding resistance will increase due to the load mass and moment, and this can cause malfunction.

When the cylinder is mounted vertically or sidelong, sliders may move downwards due to the self-weight or workpiece mass. If an accurate stopping position is required at the stroke end or the middle-stroke, use an external stopper to secure accurate positioning.



Maximum Load Mass when Loaded Directly on Body

When the load is applied directly to the body, it should be no greater than the maximum values shown in the table below.

Model	Maximum load mass Wemax (kg)
REBR15	1.0
REBR25	1.2
REBR32	1.5



Bore size (mm)	Model	Allowable load mass Wv (kg)	Maximum operating pressure Pv (MPa)
15	REBR15	7.0	0.65
25	REBR25	18.5	0.65
32	REBR32	30.0	0.65

Note)Use caution, since the magnetic coupling may be dislocated if it is used over the maximum operating pressure.

Intermediate Stop

The cushion effect (smooth start-up, soft stop) exists only before the stroke end in the stroke ranges indicated in the table below.

The cushion effect (smooth start-up, soft stop) cannot be obtained in an intermediate stop or return from an intermediate stop using an external stopper, etc.

Cushion Stroke

Model	Stroke (mm)
REBR15	25
REBR25	30
REBR32	30

Caution on Design 3

Body Non-rotating Accuracy and Max. Allowable Moment (With switch rail) (Reference values)

Reference values for non-rotating accuracy and maximum allowable moment at stroke end are indicated below.



SMC



Note 1) Avoid operations where rotational torque (moment) is applied. In such a case, the use of an external guide is recommended.
 Note 2) The above reference values will be satisfied within the allowable stroke ranges. However, caution is

Note 2) The above reference values will be satisfied within the allowable stroke ranges. However, caution is necessary because as the stroke becomes longer the inclination (rotation angle) within the stroke can be expected to increase.

Note 3) When a load is applied directly to the body, the loaded mass should be no greater than the allowable load masss on page 998.

D- □
-X □
Individual -X□
Sine Rodless Cylinder / Direct Mount Type Series **REBR** ø15, ø25, ø32



Applicable Auto Switch/Refer to pages 1719 to 1827 for further information on auto switches.

		Fleetrical	ight) A (inim m		Load volta	age	Auto suitale	Lead	wire le	ngth (m)	Dro wirod					
Туре	e Special function	entry	Indicator	(Output)	D	C	AC	model	0.5 (Nil)	1 (M)	3 (L)	5 (Z)	connector	Applica	ble load			
				3-wire (NPN)		5 V 10 V		M9N		•	•	0	0	IC circuit				
te	—			3-wire (PNP)		5 V, 12 V		M9P		\bullet		0	0					
sta tch		Grommot	SS	2-wire	24 V 12 V	12 V	12 V	12 V	2 V	M9B		\bullet		0	0	—	Relay,	
lid svi	Diagnostic indication	n	≻	3-wire (NPN)			_	M9NW		\bullet		0	0	IC aircuit	PLC			
°,								3-wire (PNP)		5 V, 12 V		M9PW			•	0	0	
				2-wire		12 V	12 V	M9BW		\bullet		0	0	—				
ed ich		Crommet	res	3-wire (NPN equivalent)	—	5 V	_	A96	•	_	•	-	_	IC circuit	_			
Ree swit	_	Gronniner	ſ	Quviro	24.14	10.1/	10 V	A93	•	-		-	_	—	Relay,			
			٤	۶	2-wire	24 V	24 V 12 V	100 V or less	A90	۲	—	۲	—	_	IC circuit	PLC		
* Lead	wire length symbols: 0.5 m	Nil (Exa	mple	e) M9NW	*	Solid sta	te auto swito	Lead wire length symbols: 0.5 m Nil (Example) M9NW * Solid state auto switches marked with "O" are produced upon receipt of order										

3 m L 5 m......Z (Example) M9NWZ

* Since there are other applicable auto switches than listed, refer to page 1004 for details

For details about auto switches with pre-wired connector, refer to pages 1784 and 1785.

* Auto switches are shipped together (not assembled).

¹ m...... M (Example) M9NWM 3 m...... L (Example) M9NWL

Sine Rodless Cylinder Direct Mount Type Series REBR

Specifications



Made to Order Specifications (For details, refer to page 1939.) Specifications

Made to Order

Symbol

-XC57 With Floating Joint

Bore size (mm)	10 15 32						
Fluid	Air						
Proof pressure	1.05 MPa						
Maximum operating pressure	0.7 MPa						
Minimum operating pressure	0.18 MPa						
Ambient and fluid temperature		–10 to 60°C					
Piston speed (Max.) Note)		50 to 600 mm/s					
Lubrication	Not required (Non-lube)						
Stroke length tolerance	0 to 250 st: $^{+1.0}_{0}$, 251 to 1000 st: $^{+1.4}_{0}$, 1001 st and up to: $^+$						
Holding force	137 363 588						

Note) Piston speed above indicates the maximum speed. It takes approximately 0.5 seconds (for one side) after the body moves from the stroke end until it goes through the cushion stroke, while it takes approximately 1 second for both sides.

Standard Stroke

Bore size (mm)	Standard stroke (mm)	Maximum manufacturable stroke (mm)	Maximum stroke with switch (mm)
15	150, 200, 250, 300, 350, 400 450, 500	1000	750
25 32	200, 250, 300, 350, 400, 450 500, 600, 700, 800	2000	1500

Note) Intermediate stroke is available by the 1 mm interval.

Mass

				(kg)
Item	Bore size (mm)	15	25	32
Basic	REBR □ (with switch rail)	0.277	0.660	1.27
(for 0 st)	REBR□-□N (without switch rail)	0.230	0.580	1.15
Additional (when equ	mass per each 50 mm of stroke ipped with switch rail)	0.045	0.083	0.113
Additional (when not e	mass per each 50 mm of stroke equipped with switch rail)	0.020	0.050	0.070
Calculation:	(Example) REBR25-500 (with swit	tch rail) • Basic mas • Additional	ss0.66 mass0.08	0 (kg) 3 (kg/50 st)

D- □
-X □
Individual -X□



Construction: ø15, ø25, ø32







REBR15

Component Parts

No.	Description	Material	No	ote	
1	Body	Aluminum alloy	Hard a	nodized	
2	Cylinder tube	Stainless steel			
3	Shaft	Stainless steel			
4	Piston side yoke	Rolled steel plate	Zinc ch	romated	
5	External slider side yoke	Rolled steel plate	Zinc ch	romated	
6	Magnet A	—			
7	Magnet B	—			
8	Bumper	Urethane rubber	Except	REBR15	
9	Piston	Aluminum alloy	Chro	mated	
10	Spacer	Rolled steel plate	Nicke	l plated	
11	Retaining ring	Carbon tool steel	Nicke	l plated	
10	Quality since	Stainless steel	REBR15, 25	Compound	
12	Cushion ring	Brass	REBR32	nickel plated	
13	End cover A	Aluminum alloy	Hard a	nodized	
14	End cover B	Aluminum alloy	Hard a	nodized	
15	Attachment ring	Aluminum alloy	Hard a	nodized	
10	Type C retaining ring	Hard steel wire material	Nickel plate	ed (REBR15)	
16	for axis	Stainless steel	REBI	R25, 32	
17	Hexagon socket head set screw	Chromium steel	Nicke	l plated	
18	Hexagon socket head plug	Chromium steel	Nicke	l plated	
19	Cylinder tube gasket	NBR			

Component Parts

No.	Description	Material	Note
20	Wear ring A	Special resin	
21	Wear ring B	Special resin	
22	Piston seal	NBR	
23	Scraper	NBR	
24	Cushion seal	NBR	
25	Switch rail gasket	NBR	
26	Magnetic shielding plate	Rolled steel plate/Chromated	
27	Switch rail	Aluminum alloy/Clear anodized	
28	Magnet	_	
29	Hexagon socket head cap screw	Chromium steel/Nickel plated	
30	Wear ring C	Special resin	

Replacement Parts: Seal Kit

Bore size (mm)	Kit no.	Contents
15	REBR15-PS	
25	REBR25-PS	A set of (19, 20, 2), 22, 23, 24,
32	REBR32-PS	

Note) Cushion seal 29 may be difficult to be replaced.

* Seal kit includes a grease pack (10 g). Order with the following part number when only the grease pack is needed. Grease pack part no.: GR-S-010 (10 g)

Switch Rail Accessory Kit



Switch Rail Accessory Kit

Bore size (mm)	Kit no.	Contents	
15	CYR15E-□		
25	CYR25E-□	Above nos. @, @, @, @ @	
32	CYR32E-□	6,3	

Note 1) \Box indicates the stroke.

Note 2) ø15 has internal magnets in the body.



Dimensions: ø15, ø25, ø32



Model	JxE	K	L	LD	М	MM	N	Р	PW	Q	QW	Т	ТС	W	WP	UЦΪ
REBR15	M5 x 0.8 x 7	14	53	4.3	5	M4 x 0.7	6	M5 x 0.8	32	84	18	21	17	25	_	
REBR25	M6 x 1 x 8	15	70	5.6	6	M5 x 0.8	6.5	Rc 1/8	43	105	20	25.5	22.5	40	21.5	UUX
REBR32	M8 x 1.25 x 10	13	76	7	7	M6 x 1	8.5	Rc 1/8	54	116	26	33	28	50	27	N40
								•								INIQ

Model	X	Y	Z
REBR15	18	54.5	98
REBR25	28	72	125
REBR32	35	79	148

Individual -X□

RHC

RZQ

REA

REB

REC

Auto Switch Proper Mounting Position (Detection at Stroke End)



Auto Switch Proper Mounting Position ø15, ø25, ø32

ø15, ø2	15 , Ø 25 , Ø 32 (mm)											
Auto switch		4		В	(C		D				
Bore size	re size D-A9 D-I		D-A9□	D-M9□ D-M9□W	D-A9 □	D-M9□ D-M9□W	D-A9□	D-M9□ D-M9□W				
15	19.5	23.5	78.5	74.5	—	—	58.5	62.5				
25	23	27	102	98	46	42	79	83				
32	31.5	35.5	116.5	112.5	54.5	50.5	93.5	87.5				

Note 1) Auto switches cannot be installed in Area C in the case of ø15.

Note 2) Adjust the auto switch after confirming the operating conditions in the actual setting.

ø25. ø32

Ø 25, Ø 32 (mm)					
Auto switch	Α	В	С	D	
model Bore size	D-Z7 D-Z80 D-Y59 D-Y7P D-Y7 W	D-Z7 D-Z80 D-Y59 D-Y7P D-Y7 W	D-Z7 D-Z80 D-Y59 D-Y7P D-Y7 W	D-Z7 D-Z80 D-Y59 D-Y7P D-Y7 W	
25	22	103	47	78	
32	30.5	117.5	55.5	92.5	

Note) Adjust the auto switch after confirming the operating conditions in the actual setting.

Operating Range

			(mm)		
	B	Bore size			
Auto switch model	15	25	32		
D-A9□	8	7.5	8		
D-M9□W D-M9□	4.5	5.5	4.5		
D-Z7□/Z80	_	9	9		
D-Y5□/Y7P/Y7□W	_	7	6		

* Since this is a guideline including hysteresis, not meant to be guaranteed.

(assuming approximately $\pm 30\%$ (dispersion) There may be the case it will vary substantially depending on an ambient environment.

Auto Switch Specifications

	(mm)
	Bore size
Auto switch model	ø25, ø32
D-A9□ D-M9□ D-M9□W	BMG2-012

D-A9□/M9□/M9□W



Other than the models listed in "How to Order", the following auto switches are applicable. For detailed specifications, refer to pages 1719 to 1827.					
	Auto switch type Model Electrical entry (Fetching direction) Features Applicable bore size				
	_ .	D-Z73, Z76		_	
	Reea	D-Z80	Grommet (In-line)	Without indicator light	a05 a00
O all'al atata		D-Y59A, Y59B, Y7P	Crommet (In line)	_	025, 052
D-Y7NW, Y7PW, Y7BW Diagnostic indication (2-color indication)					

SMC

Normally closed (NC = b contact) solid state auto switches (D-F9G/F9H/Y7G/Y1 types) are also available. Refer to pages 1746 and 1748 for details.



Series REBR Specific Product Precautions

Be sure to read before handling.

Refer to front matters 42 and 43 for Safety Instructions and pages 3 to 11 for Actuator and Auto Switch Precautions.

Mounting

A Caution

- 1. Take care to avoid nicks or other damage on the outside surface of the cylinder tube. This can lead to a damage of the scraper and the wear ring, which in turn can cause malfunction.
- **2. Use caution to the rotation of the external slider.** Rotation should be controlled by connecting it to another shaft (linear guide, etc.).
- 3. Do not operate with the magnetic coupling out of position.

If the magnetic coupling is out of position, push the external slider by hand (or the piston slider with air pressure) back to the proper position at the stroke end.

- 4. The cylinder is mounted with bolts through the mounting holes in the end covers. Be sure they are tightened securely.
- 5. Be sure that both end covers are secured to the mounting surface before operating the cylinder. Avoid operation with the external slider secured to the surface.
- **6.** Do not apply a lateral load to the external slider. When a load is mounted directly to the cylinder, variations in the alignment of each shaft center cannot be offset, which results in the generation of a lateral load that can cause malfunction. The cylinder should be operated using a connection method which allows for shaft alignment variations and deflection due to the cylinder's own mass. A drawing of a recommended mounting is shown in Fig. (2).



Variations in the load and cylinder shaft alignment cannot be offset and may result in a malfunction.

Fig. (1) Incorrect mounting

providing clearance between the mounting bracket and cylinder. Moreover, the mounting bracket is extended above the cylinder shaft center, so that the cylinder is not subjected to moment.

Fig. (2) Recommended mounting

7. Use caution regarding the allowable load mass when operating in a vertical direction.

The allowable load mass when operating in a vertical direction (reference values on page 998) is determined by the model selection method. However, if a load greater than the allowable value is applied, the magnetic coupling may break and there is a possibility of dropping the load. When using this type of application, please contact SMC regarding the operating conditions (pressure, load, speed, stroke, frequency, etc.).

Disassembly and Maintenance

▲ Caution

1. Special tools are necessary for disassembly.



Special Tool Number

Part no.	Applicable bore size (mm)
CYRZ-V	15
CYRZ-W	25, 32

REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

REA

D -□	
-X □	
Individual -X□	

Linear Guide Type Single Axis/Double Axes

Series **REBH/REBHT**

Single Axis: ø15, ø25 Double Axes: ø25, ø32



REA
REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

D- □
-X □
Individual -X 🗆



Series REBH Model Selection 2

Caution on Design 1

The load mass allowable moment differs depending on the workpiece mounting method, cylinder mounting orientation and piston speed. In making a determination of usability, do not allow the sum ($\Sigma \alpha$ n) of the load factors (α n) for each mass and moment to exceed "1".



Caution on Design 2

Load Mass

					W		
Maximum Load	Mass (kg)	W	,11111111111111		50	REBHT32	
Model	Wmax				30	REBH25,RE	BHT25
REBH15	9				20 20		
REBH25	25				16	REBH15	
REBHT25	25				(j) (j) (j) (j) (j) (j) (j) (j) (j) (j)		
REBHT32	40		- 🕇		1) 88 5		
			Ŵ		a a a a a a a a a a a a a a a a a a a		
					° ad		
				w	Ľ		

Moment



SMC

0.5

70

300

Maximum speed (mm/s)

<Graph (1)>

500 60

-X□ Individual -X□



<Data (B): Maximum speed—Load Mass Chart>



Series REBH Model Selection 3

Selection Calculation -

The selection calculation finds the load factors (α n) of the items below, where the total ($\Sigma \alpha$ n) does not exceed 1.

$\sum \Omega n = 0$	$\chi_1 + \Omega_2 + \Omega_3 \leq 1$		
Item	Load factor $lpha$ n	Note	
1. Max. load mass	Ω1 = W/Wmax	Review W. Wmax is the maximum load mass.	
2. Static moment	C(2 = M/Mmax	Review M1, M2, M3. Mmax is the allowable moment.	
3. Dynamic moment	ि्र3 = Me/Memax	Review Me1, Me3. Memax is the allowable moment.	
Calculation Example		U: Maximum speed	
Cylinder: REBH15 Mounting: Horizontal wall mountin Maximum speed: U = 500 [mm/s] Load mass: W = 1 [kg] (excluding L1 = 200 [mm] L2 = 200 [mm]	ng Conditions — g style mass of arm section)		
Item		Load factor Cln	Note
1. Maximum load mass 의	W	C(1 = W/Wmax = 1/3 = 0.111 = 0.333	Examine W. (For Wmax, find the value in <graph (1)=""> when U = 500 mm/s.)</graph>
2. Static moment	W M	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	Examine M₂. Since M₁ & M₃ are not generated, investigation is unnecessary.
3. Dynamic momen	t Guide central axis	$We = 5 \times 10^{-3} \cdot W \cdot g \cdot U$ = 5 x 10 ⁻³ · 1 · 9.8 · 500 = 25 [N] Mes = 1/3 · We (L ₂ - A) = 1/3 · 25 · 0.182 = 1.52 [N·m] C(3 = Mes/Mesmax = 1.52/6 = 0.25	Examine Me3. (For Memax, find the value in <graph (2)=""> when U = 500 mm/s.)</graph>
$We \leftarrow U = V = V = V = V = V = V = V = V = V =$		Me1 = $1/3 \cdot We \cdot L1$ = $1/3 \cdot 25 \cdot 0.2$ Examine Me1. = $1.6 [N \cdot m]$ (For Memax, find the value in $OL4$ = Me1 /Me1max <graph (2)=""> when U = 500 mm/s.) = $1.6/6$ = 0.27</graph>	

 $\begin{aligned} & = 0.333 + 0.125 + 0.25 + 0.27 \\ & = 0.978 \le 1 \end{aligned}$

And it is possible to use.



REA

REB

REC

C V

C 🗆 X

MQ

RHC

RZQ

D-🗆

-X□ Individual -X□

Series REBH Model Selection 4

Caution on Design 2

Table Deflection Amount



Note) Deflection when a moment other than the above is applied can be specified by extending the lines in the graphs above.

Vertical Operation

When using in vertical operation, prevention of workpiece dropping due to breaking of the magnetic coupling should be considered. The allowable load mass and maximum operating pressure should be as shown in the table below. When the cylinder is mounted vertically or sidelong, sliders may move downwards due to the self-weight or workpiece mass. If an accurate stopping position is required at the stroke end or the middle-stroke, use an external stopper to secure accurate positioning.

Model	Allowable load mass Wv (kg)	Maximum operating pressure Pv (MPa)
REBH15	7.0	0.65
REBH25	18.5	0.65
REBHT25	18.5	0.65
REBHT32	30.0	0.65

Intermediate Stop

The cushion effect (smooth start-up, soft stop) exists only before the stroke end in the stroke ranges indicated in the table below.

The cushion effect (smooth start-up, soft stop) cannot be obtained in an intermediate stop or a return from an intermediate stop using an external stopper, etc.

Cushion Stroke

Model	Stroke (mm)
REBH15	25
REBH25	30
REBHT25	30
REBHT32	30

Sine Rodless Cylinder Linear Guide Type Series REBH

Stroke Adjustment

The adjusting bolt is adjusted to the optimum position for smooth acceleration and deceleration at the time of shipment, and should be operated at the full stroke. When stroke adjustment is necessary, the maximum amount of adjustment on one side is 2 mm. (Do not adjust more than 2 mm, as it will not be possible to obtain smooth acceleration and deceleration.)

Do not adjust based on the stopper's movement, as this can cause cylinder damage.

Stroke adjustment method

Loosen the round head Phillips screws, and remove the top covers and dust covers (4 pcs.). Then loosen the hexagon nut, and after performing the stroke adjustment from the plate side with a hexagon wrench, retighten and secure the hexagon nut.



Adjusting Bolt Position (at the time of shipment), Hexagon Nut Tightening Torque

Model	T (mm)	Tightening torque (N•m)
REBH15	7	1.67
REBH25	9	
REBHT25	9	3.14
REBHT32	9	

After adjusting the stroke, replace the top covers and dust covers. Tighten the round head Phillips screws for securing the top covers with a torque of 0.58 N-m.

SMC

REA
REB
REC
C□Y
C 🗆 X
MQ
RHC
RZQ

D -□	
-X □	
Individual -X□	

Sine Rodless Cylinder / Linear Guide Type Series **REBH** Single Axis: ø15, ø25 / Double Axes: ø25, ø32



Applicable Auto Switch/Refer to pages 1719 to 1827 for further information on auto switches.

	Special function							light			Load volt	tage	Auto ouit	oh model	Lead wire le	ength	(m)*						
Туре		Electrical	ator	Wiring			10	Auto Switch model		0.5	3	5	Pre-wired	Applie	cable load								
		entry	lndi Di	(Output)		DC	AC	Perpendicular	In-line	(Nil)	(L)	(Z)	CONNECTOR										
				3-wire (NPN)		5 V 10 V		Y69A	Y59A			0	0	IC circuit									
ate	_			3-wire (PNP)		5 V, 12 V		Y7PV	Y7P			0	0										
it cr		Crommet	S	2-wire	04.14	12 V		Y69B	Y59B			0	0	—	Polov PLC								
swi	Diagnostic indication (2-color indication)	Grommet	⊁	3-wire (NPN)	24 V	5 V, 12 V		Y7NWV	Y7NW			0	0	IC circuit	neiay, FLO								
ů,				3-wire (PNP)			5 V, 12 V	Y7PWV	Y7PW			0	0										
														2-wire		12 V		Y7BWV	Y7BW			\circ	0
tch					(es	, es	3-wire (NPN equivalent)	_	5 V	_	—	Z76	•	•	-	_	IC circuit	—					
Re	-	Gronmet		0	24.14	12 V	100 V	_	Z73				—	—									
			-	∠-wire	24 V	5 V, 12 V	100 V or less	_	Z80			-	—	IC circuit	Helay, PLC								

* Solid state auto switches marked with "O" are produced upon receipt of order. * Lead wire length symbols: 0.5 m Nil (Example) Y59A (Example) Y59AL 3 m I (Example) Y59AZ 5 m 7

• Since there are other applicable auto switches than listed, refer to page 1020 for details.

For details about auto switches with pre-wired connector, refer to pages 1784 and 1785.

* Auto switches are shipped together (not assembled).

Sine Rodless Cylinder Linear Guide Type Series REBH

Specifications



Bore size (mm)	15	25	32			
Fluid	Air					
Maximum operating pressure		0.7 MPa				
Minimum operating pressure		0.2 MPa				
Proof pressure	1.05 MPa					
Ambient and fluid temperature	-10 to 60°C					
Piston speed (Max.) Note)	70 to 600 mm/s					
Lubrication	Not required (Non-lube)					
Stroke length tolerance	0 to 1.8 mm					
Piping	Centralized piping type					
Piping port size	M5 x 0.8 Rc ¹ / ₈					
Holding force (N)	137	363	588			

Note) Piston speed above indicates the maximum speed. It takes approximately 0.5 seconds (for one side) after the slide table moves from the stroke end until it goes through the cushion stroke, while it takes approximately 1 second for both sides.

Standard Stroke

Made to Order Specifications (For details, refer to pages 1857 and 2016.)				
Symbol	Specifications			
-XB10	Intermediate stroke (Using exclusive body)			
-X168	Helical insert thread specifications			

Bore size (mm)	Number of axes	Standard stroke (mm)	Maximum manufacturable stroke (mm)
15	1 ovio	150, 200, 300, 400, 500	750
25	Taxis	200, 300, 400, 500, 600, 800	1000
25	0 0 0000	200 200 400 500 600 800 1000	1200
32	2 axes	200, 300, 400, 300, 800, 800, 1000	1500

Note 1) Stroke exceeding the standard stroke will be available upon request for special.

Note 2) Intermediate strokes other than made-to-order (refer to -XB10) are available as special.

Mass

								(kg)				
Madal		Standard stroke (mm)										
iviodei	150	200	300	400	500	600	800	1000				
REBH15	2.5	2.7	3.2	3.6	4.1	_		_				
REBH25	—	5.3	6.0	6.6	7.3	8.0	9.4	_				
REBHT25	—	6.2	7.3	8.3	9.4	10.4	12.5	14.6				
REBHT32		9.6	10.7	11.9	13.0	14.2	16.5	18.8				

Theoretical Output

ľ								(NI)	
1	Bore size	Piston area		Or	erating pre	essure (MF	Pa)	(N)	C ⊓ X
	(mm)	(mm ²)	0.2	0.3	0.4	0.5	0.6	0.7	
	15	176	35	52	70	88	105	123	MQ
	25	490	98	147	196	245	294	343	пис
	32	804	161	241	322	402	483	563	КПС

Note) Theoretical output (N) = Pressure (MPa) x Piston area (mm²)

D-🗆
-X□
Individual
-X□

RZQ

REA

REB

REC

C□Y

Construction: ø15, ø25



Component Parts

-			
No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Cylinder tube	Stainless steel	
3	External slider tube	Aluminum alloy	
4	Shaft	Stainless steel	
5	Piston side yoke	Rolled steel plate	Zinc chromated
6	External slider side yoke	Rolled steel plate	Zinc chromated
7	Magnet A	—	
8	Magnet B	—	
9	Bumper	Urethane rubber	Except REBH15
10	Piston	Aluminum alloy	Chromated
11	Spacer	Rolled steel plate	Nickel plated
12	Space ring	Aluminum alloy	Chromated
13	Slide table	Aluminum alloy	Hard anodized
14	Side plate A	Aluminum alloy	Hard anodized
15	Side plate B	Aluminum alloy	Hard anodized
16	Cushion ring	Stainless steel	Compound electroless nickel plated
17	Internal stopper	Aluminum alloy	Anodized
18	Plate A	Aluminum alloy	Hard anodized

Component Parts

No.	Description	Material	Note		
19	Plate B	Aluminum alloy	Hard anodized		
20	Stopper	Aluminum alloy	Anodized		
21	Adjusting bolt	Chromium molybdenum steel	Nickel plated		
22	Hexagon nut	Carbon steel	Nickel plated		
23	Linear guide				
24	Top cover	Aluminum alloy	Hard anodized		
25	Dust cover	Special resin			
26	Magnet (for auto switch)	—			
27	Parallel pin	Carbon steel	Nickel plated		
28	Square nut for body mounting	Carbon steel	Nickel plated (Accessory)		
29	Wear ring A	Special resin			
30	Wear ring B	Special resin			
31	Piston seal	NBR			
32	Scraper	NBR			
33	O-ring	NBR			
34	O-ring	NBR			
35	Cushion seal	NBR			

Note) Square nut for body mounting B: 4 pieces

Replacement Parts/Seal Kit

Bara aiza (mm)	Kit no	Contonto
Bore size (mm)	KIL NO.	Contents
15	REBH15-PS	Set of nos. above 29, 30,
25	REBH25-PS	31, 32, 33, 34, 35

Note) Cushion seal ${\rm 35}$ may be difficult to be replaced.

* Seal kit includes a grease pack (10 g).

Order with the following part number when only the grease pack is needed. Grease pack part no.: GR-S-010 (10 g)

Construction: ø25, ø32

Double axis type: REBHT



Component Parts

No.	Description	Material	No	ote	
1	Body	Aluminum alloy	Hard ar	rd anodized	
2	Cylinder tube	Stainless steel			
3	External slider tube	Aluminum alloy			
4	Shaft	Stainless steel			
5	Piston side yoke	Rolled steel plate	Zinc chromated		
6	External slider side yoke	Rolled steel plate	Zinc chromated		
7	Magnet A	—			
8	Magnet B	—			
9	Bumper	Urethane rubber			
10	Piston	Aluminum alloy	Chromated		
11	Spacer	Rolled steel plate	Nickel plated		
12	Space ring	Aluminum alloy	Chromated (Ex	cept REBHT32)	
13	Slide table	Aluminum alloy	Hard anodized		
14	Side plate	Aluminum alloy	Hard anodized (E	Except REBHT32)	
15	Cuchien ring	Stainless steel	REBHT25	Compound	
15	Cushion ring	Brass	REBHT32	nickel plated	
16	Internal stopper	Aluminum alloy	Anoc	dized	
17	Plate	Aluminum alloy	Hard ar	nodized	

Replacement Parts/Seal Kit

Bore size (mm)	Kit no.	Contents		
25	REBHT25-PS	Set of nos. above 28, 29,		
32	REBHT32-PS	30, 31, 32, 33, 34		

Note) Cushion seal 3 may be difficult to be replaced.

* Seal kit includes a grease pack (10 g).

Order with the following part number when only the grease pack is needed. Grease pack part no.: GR-S-010 (10 g)

REBHT32 **Component Parts**

No.	Description	Material	Note	
18	Stopper	Aluminum alloy	Anodized	
19	Adjusting bolt	Chromium molybdenum steel	Nickel plated	REA
20	Hexagon nut	Carbon steel	Nickel plated	
21	Linear guide			REB
22	Top cover	Aluminum alloy	Hard anodized	
23	Dust cover	Special resin		REC
24	Magnet (for auto switch)	—		
25	Parallel pin	Carbon steel	Nickel plated	C 🗆 Y
26	Square nut for body mounting	Carbon steel	Nickel plated (Accessory)	
27	Hexagon socket head taper plug	Carbon steel	Nickel plated	C
28	Wear ring A	Special resin		
29	Wear ring B	Special resin		MQ
30	Piston seal	NBR		
31	Scraper	NBR		RHC
32	O-ring	NBR		
33	O-ring	NBR		KZQ
34	Cushion seal	NBR		L

Note) Square nut for body mounting 26: 4 pieces

D-🗆
-X□
Individual
-X□

Dimensions: ø15, ø25

Single axis type: REBH



Model	Α	EA	EB	Н	HA	HB	HC	HG	HP	HT	J	L	LL	LW	М	MM
REBH15	97	26.5	21	46	33.5	33.5	45	17	42	19	M5 x 0.8	106	44	71.5	M5 x 0.8	8
REBH25	125	29	24	63	46	46	61.5	25	58.5	28	M6 x 1.0	138	56	86	M6 x 1.0	10

Model	Ν	NL	NT	Р	PA	PB	PP	S	TW	w	ХВ	Z	ZZ
REBH15	16.5	15	8	M5 x 0.8	50	62	21	161	65	88.5	_	194	17.5
REBH25	20.5	18	9	1/8	65	75	27	209	75	103	9.5	250	23.5

Dimensions: ø25, ø32

Double axis type: REBHT



REB																		
	N	ММ	М	LW	LL	J		HT	HP	HG	нс	HB	HA	н	EB	EA	A	Model
REC	20.5	10	M6 x 1.0	119	56	x 1.0	M6 x	35	58.5	19.5	61.5	46	46	63	79	28.5	125	REBHT25
	23	12	M8 x 1.25	130	63.5	1.25	M8 x	43	69.5	25	72.5	57.5	52.5	75	90	30	132.5	REBHT32
C□Y	·					_					•		•			•		
							Z	ХВ	w	TW	S	PS	PP	PB	PA	NT	NL	Model
C□X						_	250	9.5	136	110	209	51	18	108	65	9	18	REBHT25
							265	2	150	124	219	61	14	115	66	12	22.5	REBHT32
MQ						-												

D-🗆
-X □
Individual -X□

RHC

RZQ

SMC

Proper Auto Switch Mounting Position (Detection at stroke end)



Proper Auto Switch Mounting Position

Auto switch		A dimension		B dimension			
model Cylinder model	D-Z7□ D-Z80	D-Y7□W D-Y7□WV	D-Y5 D-Y6 D-Y7P D-Y7PV	D-Z7□ D-Z80	D-Y7□W D-Y7□WV	D-Y5□ D-Y6□ D-Y7P D-Y7PV	
REBH15		72			122		
REBH25		86		164			
REBHT25		86		164			
REBHT32		82		183			

Note) Adjust the auto switch after confirming the operating conditions in the actual setting.

Operating Bange

Operating Range (mm										
		Bore siz	ze (mm)							
Auto switch model	RE	BH	REBHT							
	15	25	25	32						
D-Z7□/Z8□	6	6	6	9						
D-Y5□/Y6□/Y7□	5	5	5	6						

* Since this is a guideline including hysteresis, not meant to be guaranteed. (assuming approximately ±30% dispersion)

There may be the case it will vary substantially depending on an ambient environment.

Auto Switch Lead Wire Containment Groove

On model REBH25 a groove is provided on the side of the body (one side only) to contain auto switch lead wires. This should be used for placement of wiring.





Series **REBH Specific Product Precautions**

Be sure to read before handling.

Refer to front matters 42 and 43 for Safety Instructions and pages 3 to 11 for Actuator and Auto Switch Precautions.

Mounting

A Caution

1. The interior is protected to a certain extent by the top cover, however, when performing maintenance, etc., take care not to cause scratches or other damage to the cylinder tube, slide table or linear guide by striking them or placing objects on them.

Cylinder bores are manufactured to precise tolerances, so that even a slight deformation may cause faulty operation.

2. Because the slider is supported by precision bearings, take care not to apply strong impacts or excessive moments to the table when loading a workpiece.

3. Mounting of the cylinder body.

The body is mounted using the square nuts, which are included, in the two T-slots on the bottom of the body. Refer to the table below for mounting bolt dimensions and tightening torque.

Model		REBH15	REBH25	REBHT25	REBHT32
Bolt dimensions	Thread size	M5 x 0.8	M6 x 1.0		M8 x 1.25
	Dimension t	<i>l</i> -8	<i>t</i> -9		<i>t</i> -12
Tightening torque	N∙m	2.65	4	.4	13.2



Operation

∧ Caution

1. The unit can be used with a direct load within the allowable range, but when connecting to a load which has an external guide mechanism, careful alignment is necessary.

Since variation of the shaft center increases as the stroke becomes longer, a connection method should be devised which allows for this displacement.

- 2. Since the guide is adjusted at the time of shipment, unintentional movement of the adjustment setting should be avoided.
- 3. Please contact SMC before operating in an environment where there will be contact with cutting chips, dust (paper debris, lint, etc.) or cutting oil (gas oil, water, warm water, etc.).
- 4. Do not operate with the magnetic coupling out of position.

In case the magnetic coupling is out of position, push the external slider back into the correct position by hand at the end of the stroke (or correct the piston slider with air pressure).



D- □
-X□
Individual
-X□