

- The AWM series is made up of a regulator and a mist separator to provide optimum results in applications such as clean air blow operations. (Nominal filtration rating: 0.3 m)
- The AWD series is made up of a regulator and a micro mist separator to provide optimum results in applications such as ultraclean air blow operations. (Nominal filtration rating 0.01 m)

How to Order

				AW AW	/M 30 - 03 BE - 7	Option / Set to i.     Option / Set than one sp ascending a Example) AW	mi-standard: Selec mi-standard symb vecification is requ alphanumeric orde /M30-03BE-1N	ot one each for <b>a</b> ol: When more ired, indicate in rr.
/							1	
				Symbol	Description		Body size	
						20	30	40
	1							
		-	have a state on a	NII	Rc			
0		11	nread type	Note 2)	NPI			
				F 1000 L/	G	•		
				T	1/9			
				02	1/8			
3			Port size	02	3/8			
				03	1/2			
				+	172		1	•
				Nil	Without mounting option	•		
		а	Mounting	B Note 4)	With bracket	•	•	•
				н	With set nut	•		
				Ŧ	'		-	-
			<b></b>	Nil	Without auto drain	•		
	Note 3)	b	Float type	С	Float type auto drain (N.C.)	•		
	E		auto urain	D	Float type auto drain (N.O.)			
4	ptic			+				
	0		Prossure	Nil	Without pressure gauge	•	•	
		с	gauge	E	Square embedded type pressure gauge	•		
				G	Round type pressure switch	•	•	
			Disital	E1 Note 5)	NPN output / Wiring bottom entry	•	•	
			Digital	E2 Note 5)	NPN output / Wiring top entry	•		
			switch	E3 Note 5)	PNP output / Wiring bottom entry	•	•	•
				E4 Note 5)	PNP output / Wiring top entry	•		
				+				
		d	Set pressure	NII Noto 6)				
				1 11010 0)	0.02 to 0.2 MPa set	•	•	
					Polycorhonato how			
				2				
	ard			6	Nylon bowl			
	and	е	Bowl	8	Metal bowl with level gauge			
5	-sta			C	With bowl guard	•	-	<b>—</b>
	emi			6C	Nylon bowl with bowl guard	•		
	Ś			+	,	-	1	1
				Nil	With drain cock	•		
					Drain guide 1/8	•		
		f	Drain port Note 7)	J Note 8)	Drain guide 1/4			
				W Note 9)	Drain cock with barb fitting: For ø6 x ø4 nylon tube	_		



## Mist Separator Regulator Series AWIM20 to AWIM40 Micro Mist Separator Regulator Series AWD20 to AWD40



AWM20, AWD20

AWM40, AWD40

_									
	<u> </u>	_					0		
				Symbol	Description		Body size		
						20	30	40	
			Exhaust	Nil	Relieving type		•	•	
		g	mechanism	N	Non-relieving type	•	•	•	
	Ð			+		L I			
	Jda		Flow direction	Nil	Flow direction: Left to right			•	
6	staı	n	Flow direction	R	Flow direction: Right to left				
	, ,			+					
	Se			Nil	Name plate, caution plate for bowl, and pressure gauge in imperial units: MPa			•	
		i	Pressure unit	Z Note 10)	Name plate, caution plate for bowl, and pressure gauge in imperial units (PSI, F)	O Note 12)	O Note 12)	O Note 12)	
				ZA Note 11)	Digital pressure switch: With unit switching function	△ <sup>Note 13)</sup>	△ Note 13)	△ Note 13)	
Note	1) Di A\ to fo (a A\	ain g ND20 AWM r auto pplica ND40	uide is NPT1/8 (appli )) and NPT1/4 (applic 140, AWD30 to AWD o drain comes with ø3 able to the AWM30 to )).	cable to th cable to the 40). The e 8/8" One-to AWM40, 2	e AWM20, Note 5) When choosing with H (panel mount), the installation space for leac wires will not be secured. In this case, select "wiring dowr entry' uch fitting for the lead wire entry. AWD30 to Note 6) The only difference from the standard specifications is the adjusting spring for the	Note 10) For thread overseas Measurer for use in be equipo setting to	d type NPT. This or use only according nent Law. (The S' u Japan.) The digita Japan.) The digita bed with the unit swit PSI initially.	oduct is for tc the new nit type is provided pressure switch will tcning function,	
Note	Note 2) Drain guide is G1/8 (applicable to the AWM20 and AWD20) and G1/4 (applicable to the AWM30 to AWH40, AWD30 to AWD40).				WM20 and regulator. It does not restrict the setting of 0.2 WM30 to MPa or more. When the pressure gauge is attached, a 0.2 MPa pressure gauge will be fitted.	Note 11) For options E1 E2, E3, E4 This product is for overseas use only according to the new Measurement Law. (The S! unit is provided for			
NOLE	SL SL	pplie	d loose at the time of	shipment.	and D is not available.	Note 12) O: For thread type. NPT only			
Note 4) Assembly of a bracket and set nuts Not					Note 8) Without a valve function	Note 13)  Complication available for options: E1. E2			

selected.

#### **Standard Specifications**

Model		AWM20 AWD20	AWM30 AWD30	AWM40 AWD40		
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2		
Fluid			Air			
Proof pressure			1.5 MPa			
Maximum operating pressure			1.0 MPa			
Set pressure range			0.05 to 0.85 MPa			
Pressure gauge port size Note 1)		1	/8	1/4		
Ambient and fluid temperature Not	te 2)	-5 to 60°C (with no freezing)				
Nominal filtration rating	AWM20 to AWM40	0.3 m (95% filtered particle size)				
	AWD20 to AWD40	0.01 m (95% filtered particle size)				
Outlet side oil mist	AWM20 to AWM40	Maximum 1.0 mg/m <sup>3</sup> (ANR) ( 0.8 ppm) Note 3) Note 4)				
concentratio	AWD20 to AWD40	Max. 0.1 mg/m <sup>3</sup> (ANR) (Before saturated with 0.001 mg/m <sup>3</sup> (ANR) or less 0.008 ppm) Note 3) N				
Potod flow ((min (ANP)) Note 5)	AWM20 to AWM40	150	330	820		
	AWD20 to AWD40	90	180	450		
Drain capacity (cm <sup>3</sup> )		8	25 45			
Bowl material		Polycarbonate				
Bowl guard		Semi-standard Standard				
Regulator construction		Relieving type				
Weight (kg)		0.44	0.59	1.25		

 Note 1) Pressure gauge connection threads are not available for F.R.L. unit with a square embedded type pressure gauge.
 Note 2) –5 to 50°™C for the products with the digital pressure switch.
 Note 3) When the compressor oil mist discharge concentration is Note 4) Bowl O-ring and other C-rings are slightly lubricated.

Note 5) Conditions: Mist separator intel pressure 0.7 MPa; The ratec flow variees depending on the inlet pressure. Keep the air flow within the rated flow tc prevent ar outflow of lubricant to the outlet side

30 mg/m<sup>3</sup> (ANR).



Note 8) Without a valve function
 Note 13)
 Combination available for options: E1, E2

 Note 9) Metal bowl
 The combination of 2 and 8 cannot be
 E3, E4

## Series AWM20 to AWM40 Series AWD20 to AWD40

#### **Option / Part No.**

Option		Model	AWM20 AWD20	AWM40 AWD40			
Bracket as	sembly Note 1)		AW20P-270AS	AR30P-270AS	AR40P-270AS		
Set nut			AR20P-260S	AR30P-260S	AR40P-260S		
	<b>D</b> I I Noto 2)	Standard	G36-1	0-□01	G46-10-□02		
Pressure	Round type Note 2)	0.02 to 0.2 MPa set	G36-2	G46-2-□02			
gauge	Square embedded	Standard	GC3-10AS [GC3P-010AS (Pressure gauge cover only)]				
	type Note 3)	0.02 to 0.2 MPa set	GC3-2AS [GC3P-010AS (Pressure gauge cover only)]				
		NPN output / Wiring bottom entry	ISE35-N-25-MLA [ISE35-N-25-M (Switch body only)]				
Digital proc	Note 4)	NPN output / Wiring top entry	ISE35-R-25-MLA [ISE35-R-25-M (Switch body only)]				
Digital pres	sule switch	PNP output / Wiring bottom entry	ISE35-N-65-MLA [ISE35-N-65-M (Switch body only)]				
		NPN output / Wiring top entry	ISE35-R-65-MLA [ISE35-R-65-M (Switch body only)]				
Elect type	Note 5)	N.O.	—	AD38	AD48		
гюат туре а		N.C.	AD37	AD37	AD47		

Note 1) Assembly of a bracket and set nuts

Note 2) 
in part numbers for a round pressure gauge indicates a type of connection thread. No indication is necessary for R; however, indicate N for NPT. Please contact SMC regarding the connection thread NPT and pressure gauge supply for PSI unit specifications.

Note 3) Including O-ring and 2 mounting screws. [ ]: Pressure gauge cover only

Note 4) Lead wire with connector (2 m), adaptor, lock pin, O-ring (1 pc.), mounting screw (2 pcs.) are attached. [ ]: Switch body only. Also, regarding how to order the digital pressure switch, please refer to page 73.

Note 5) Minimum operating pressure: N.O. type–0.1 MPa; N.C. type–0.1 MPa (AD27) and 0.15 MPa (AD37/47). Please contact SMC for PSI unit and F specifications.

## ▲ Specific Product Precautions

Be sure to read this before handling. Refer to "Precautions for Handling Pneumatic Devices" (M-03-E3A) for Safety Instructions and F.R.L. Unit Precautions.

#### Selection

## \land Warning

1. Residual pressure release (outlet pressure release) is not complete by releasing inlet pressure. Please contact SMC regarding residual pressure release.

#### Air Supply

### **A** Caution

- 1. Install an air filter (the AF series) as a preliminary filter on the inlet side of the mist separator regulator to prevent premature clogging.
- **2.** Install an air filter (the AFM series) as a preliminary filter on the inlet side of the micro mist separator regulator to prevent premature clogging.

#### Maintenance

## \land Warning

1. Replace the element every 2 years or when the pressure drop becomes 0.1 MPa, whichever comes first, to prevent damage to the element.

#### Mounting and Adjustment

### \land Caution

- 1. Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- 2. The pressure gauge included with regulators for 0.02 to 0.2 MPa setting is for up to 0.2 MPa use only (except for the AR10). Exceeding 0.2 MPa of pressure can damage the gauge.
- **3.** Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

#### Mounting and Adjustment

### \land Warning

- 1. Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure. Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.
  - Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)







 A knob cover is available to prevent careless operation of the knob. Refer to "Features 1" for details.

# Mist Separator Regulator Series AWM20 to AWM40 Micro Mist Separator Regulator Series AWD20 to AWD40



#### Pressure Characteristics (Representative values)









Conditions inlet pressure 0.7 MPa, Outlet pressure 0.2 MPa, Flow rate 20 //miri (ANR)





**SMC** 

## Series AWM20 to AWM40 Series AWD20 to AWD40

#### Construction





#### **Component Parts**

No.	Description	Material Model		Note
1	Zinc die-cast		AWM20 AWD20	
	Boay	Aluminum die-cast	AWM30, AWM40 AWD30, AWD40	Platinum silver
2	Bonnet	Polyacetal AWM20 to AWM40 AWD20 to AWD40		Black

#### **Replacement Parts**

				Part no.					
No.	Descript	ion	Material	AWM20 AWD20	AWM30 AWD30	AWM40 AWD40			
3	Valve assembly		Brass, HNBR	AWM20P-090AS	AWM30P-090AS	AWM40P-090AS			
		AWM20 to AWM40	—	AFM20P-060AS	AFM30P-060AS	4FM40F-060AS			
4	Element assembly	AWD20 to AWD40	—	AFD20P-060AS	AFD30P-060AS	AFD40P-0604S			
5	Diaphragm assembly		Weatherable NBR	AR20P-150AS	AR30P-150AS	AF40P-150AS			
6	Bowl O-ring		NBR	C2SFP-260S	C3SFP-260S	C4SFE-260S			
7	Bowl assembly Note 1)		Polycarbonate	C2SF	C3SF Note 2)	C4SF Note 2			

Note 2) Including O-ring. Please contact SMC regarding the bowl assembly supply for PSI and F unit specifications Note 3) Bowl assembly for the AWM30, AWM40/AWD30, AWD40 comes with a bowl guard (stee band material).

# Mist Separator Regulator Series AWW20 to AWW40 Micro Mist Separator Regulator Series AWD20 to AWD40

Dimensi	ons														
AWM20 AWD20	(Pr	<u>F</u> <u>P2</u> essure gaug port size)			B C	⊻ 			 (Option, 	_ _	Pane <u>IN</u> <u>Z</u> .WM20/	fitting di	Max 3.	5	
AWM30, AWD30,	AWM40 AWD40	F IN P2 ssure gauge oort size)				<b>2-P1</b> (Port size)			Option Option	et n A	Pane <u>IN</u> <u>Z</u> WM30/ WM40/	fitting di	Max 3. Max 5	5	
Applicable model	0	4	AWM20,	AWM40/	WD20 to	AWD40									
Dimensions		Center of piping			Center of piping		J J	Cente	er of						
Applicable model		AWM20	), AWD2	0				AW	'M30, AV	VM40/A	WD30,	AWD40			
Optional/Semi-standard specifications	With auto drain (f	N.C.) Met	al bowl	With dra	in guide V	With auto drain (N.O	./N.C.)	Metal bo	owl Met	tal bowl with	level gauge	With drair	n guide	Drain cock wit	h barb fitting
Dimensions	M5 x	<b>n</b> 0.8		Width ac	1/8 ross flats 14	I.O.: Black I.C.: Gray					8	Width across	1/4 ss flats 17	Applicable	fitting tubing: T0604
Model	P1	Ρ2 Δ	R Note)	Standard s	pecification	ns <b>F</b>	G		ĸ	Squar pressur	e type e gauge	Dptional sp Dig pressure	ecificatio ital gauge	ns Round pressure	d type e gauge
AWM20/AWD20	1/8, 1/4	1/8 40	160	73 2	6 —	M28 x 1	40	26	5	□28	27	□27.8	37.5	ø37.5	63
AWM30/AWD30	1/4, 3/8	1/8 53	201	86 2	9.5 30	M38 x 1.5	55	29.5	3.5	□28	30.5	□27.8	41	ø37.5	66
AWM40/AWD40	1/4, 3/8, 1/2	1/4 70	239	92 3	37.5 38	M42 x 1.5	80	37.5	1.5	□28	38.5	□27.8	49	ø42.5	76
Model		Bracke	t mount	Optional	specificatio	ons Panel r	nount	Wi	ith auto draii	n With bar	Ser b fitting Wi	mi-standar ith drain guide	d specific Metal b	cations	al bowl with vel gauge
	M N	Q 1	RS	T	U	v w	Y	Z	В	E	3	В	B		В

8.5 Note) The total length of B dimension is the length when the filter regulator handle is unlocked.

5.4

6.5

15.4

10.5

2.3

2.3

2.3

35.5

AWM20/AWD20

AWM30/AWD30

AWM40/AWD40



28.5

38.5

42.5

# **Options Digital Pressure Switch**

15	SE35-[		25 M L A 9 8 9 5		
	<u></u>			Applicable Series	S
		Symbol	Description	FBL unit	AC20, AC25, AC30, AC40, AC50, AC55, AC60
					AC20A, AC30A, AC40A, AC50A, AC60A
	`				AC20B, AC25B, AC30B, AC40A,
					AC50A, AC55B, AC60B
					AC20C AC25C V30C AC40C
		N	Wiring bottom entry	Pequiator	AB20 AB25 AB30 AB40 AB50 AB60
				Filter regulator	
			Ц	Mist congrator regulator	AWM20, AWM30, AWM40
1	Lead wire entry			Mist separator regulator	AWW20, AWW50, AWW40
			H H	regulator	AWD20, AWD30, AWD40
		R	Wiring top entry	Diigta	Pressure Switch Details
					Lock pin
		+			M3 x 0.5 x 7
2	Output	25	NPN output		(Screw for aluminum materials)
		<u> </u>			
		Nil Note 2)	With unit switching function		Digital pressure switch
6	Display unit Note 1)	M	Fixed SI unit		(Body only )
	Diopidy drift	P Note 2)	Pressure unit: PSI (initial value) with unit display switching function		
		+			
4	Lead wire	Nil	Without lead wire	Adap	tor O ring
	2000 1110	ļĻ	Lead wire with connector	Example)	
		<b>T</b>	Without appagazing (quitab hady apply)	Regulator	Wiring
5	Lead wire entry		With accessories (adaptor O-ring (1 pc), mounting screw (2 pcs), lock pin)		bottom entry
Nata	1) This was duet is few		with accessories (adaptor, O-mig (1 pc.), mounting sciew (2 pcs.), lock pin)	J	C-ring
Note	2) Unit name plate is	overseas US	e only according to the new Measurement Law.		Wiring top entry
Note	3) Instruction manual	is attached		Digital press	ure switch
Note	4) When ordering the	body only, s	select the symbol from $lacksquare$ to $lacksquare$ respectively.	(Body only)	
					Contraction of the second

**SMC** 

#### Specifications

apecificati	lons				
Rated press	sure range	0 to 1 MPa			
Set pressur	re range	-0.1 to 1 MPa			
Withstand p	oressure	1.5 MPa			
Set pressur	re resolution	0.01 MPa			
Power supp	oly voltage	12 to 24 VDC, Ripple (p-p) 10% or less (with power supply polarity protection)			
Current cor	nsumption	55 mA or less (at no load)			
Switch outp	out	NPN or PNP open collector 1 output			
	Max. load current	80 mA			
	Max. applied voltage	30 V (with NPN output)			
	Residual voltage	1 V or less (with load current of 80 mA)			
	Response time	1 s (Response time selections: 0.25, 0.5, 2, 3)			
	Anti-chattering function				
	Short circuit protection	With short circuit protection			
Repeatabili	ty	1%F.S. or less			
Ulvataraala	Hyseresis mode	Variable (see he act from 0)			
nysteresis	Window comparator mode	Vallable (call be set from 0)			
Display		3-digit, 7-segment indicator, 2-color display (Red/ Green) can be interlocked with the switch output.			
Display accuracy		2%F.S. 1 digit (at 25°C 3°C)			
Indication I	ight	Illuminates when output is turned ON. (Green)			
Environmental resistance	Enclosure	IP40			
Lead wire w	vith connector	ø3.4 3-wire 25AWG 2 m			

#### Output

NPN open collector

Max 30 V, 80 mA Residual output voltage V or less



Leac wire

#### PNP open collector

#### Max 80 m4

Residual output voltage V or less



# Series AC Safety Instructions

These safety instructions are intended to prevent a hazardous situation and/or equipment damage. These instructions indicate the level of potential hazard by labels of **"Caution"**, **"Warning"** or **"Danger"**. To ensure safety, be sure to observe ISO 4414 <sup>Note 1</sup>, JIS B 8370 <sup>Note 2</sup>) and other safety practices.

#### ■Explanation of the Labels

Labels	Explanation of the labels
\land Danger	In extreme conditions, there is a possible result of serious injury or loss of life.
\land Warning	Operator error could result in serious injury or loss of life.
<b>A</b> Caution	Operator error could result in injury Note 3) or equipment damage. Note 4)

Note 1) ISO 4414: Pneumatic fluid power - General rules relating to systems

Note 2) JIS B 8370: General Rules for Pneumatic Equipment

Note 3) Injury indicates light wounds, burns and electrical shocks that do not require hospitalization or hospital visits for long-term medical treatment.

Note 4) Equipment damage refers to extensive damage to the equipment and surrounding devices.

#### Selection/Handling/Applications

1. The compatibility of the pneumatic equipment is the responsibility of the person who designs the pneumatic system or decides its specifications.

Since the products specified here are used in various operating conditions, their compatibility for the specific pneumatic system must be based on specifications or post analysis and/or tests to meet the specific requirements. The expected performance and safety assurance are the responsibility of the person who has determined the compatibility of the system. This person should continuously review the suitability of all items specified, referring to the latest catalog information with a view to giving due consideration to any possibility of equipment failure when configuring a system.

- 2.Only trained personnel should operate pneumatic machinery and equipment. Compressed air can be dangerous if handled incorrectly. Assembly, handling or repair of the systems using pneumatic equipment should be performed by trained and experienced operators. (Understanding JIS B 8370 General Rules for Pneumatic Equipment, and other safety rules are included.)
- 3. Do not service the machinery/equipment or attempt to remove components until safety is confirmed.
  - 1. Inspection and maintenance of the machinery/equipment should only be performed once measures to prevent falling or runaway of the driven objects have been confirmed.
  - If the equipment must be removed, confirm the safety process as mentioned above. Turn off the supply pressure for the equipment and exhaust all residual compressed air in the system, and release all the energy (liquid pressure, spring, condenser, gravity).
     Before the machinery/equipment is restarted, take measures to prevent quick extension of a cylinder piston rod, etc.
- 4. If the equipment will be used in the following conditions or environment, please contact SMC first and be sure to take all necessary safety precautions.
  - 1. Conditions and environments beyond the given specifications, or if product is used outdoors.
  - Installation on equipment in conjunction with atomic energy, railway, air navigation, vehicles, medical equipment, food and beverages, recreation equipment, emergency stop circuits, clutch and brake circuits in press applications, or safety equipment.
     An application which has the possibility of having negative effects on people, property, requiring special safety analysis.
  - An application which has the possibility of having negative effects on people, property, requiring special safety analysis.
     If the products are used in an interlock circuit, prepare a double interlock style circuit with a mechanical protection function for the prevention of a breakdown. And, examine the devices periodically if they function normally or not.

#### ■Exemption from Liability

- 1. SMC, its officers and employees shall be exempted from liability for any loss or damage arising out of earthquakes or fire, action by a third person, accidents, customer error with or without intention, product misuse, and any other damages caused by abnormal operating conditions.
- 2. SMC, its officers and employees shall be exempted from liability for any direct or indirect loss or damage, including consequential loss or damage, loss of profits, or loss of chance, claims, demands, proceedings, costs, expenses, awards, judgments and any other liability whatsoever including legal costs and expenses, which may be suffered or incurred, whether in tort (including negligence), contract, breach of statutory duty, equity or otherwise.
- 3. SMC is exempted from liability for any damages caused by operations not contained in the catalogs and/or instruction manuals, and operations outside of the specification range.
- 4. SMC is exempted from liability for any loss or damage whatsoever caused by malfunctions of its products when combined with other devices or software.



# SMC'S GLOBAL MANUFACTURING, DISTRIBUTION



EUROPE

AUSTRIA SMC Pneumatik GmbH **BELGIUM** SMC Pneumatics N.V./S.A. **BULGARIA** SMC Industrial Automation Bulgaria EOOD CROATIA SMC Industrijska automatika d.o.o. CZECH REPUBLIC SMC Industrial Automation CZ s.r.o. DENMARK SMC Pneumatik A/S **ESTONIA** SMC Pneumatics Estonia OÜ FINI AND SMC Pneumatics Finland OY FRANCE SMC Pneumatique SA GERMANY SMC Pneumatik GmbH HUNGARY SMC Hungary Ipari Automatizalasi Kft. IRELAND SMC Pneumatics (Ireland) Ltd. ITALY SMC Italia S.p.A. LATVIA SMC Pnuematics Latvia SIA LITHUANIA SMC Pneumatics Lietuva, UAB NETHERLANDS SMC Pneumatics BV

NORWAY

SMC Pneumatics Norway 4/S POLAND SMC Industrial Automation Polska Sp.z.c.o ROMANIA SMC Romania s.r.l.

RUSSIA SMC Pneumatik LLC. **SLOVAKIA** 

SMC Priemyselna automatizacia s.r.o SLOVENIA

SMC INDUSTRIJSKA AVTOMATIKA d.o.o SPAIN/PORTUGAL

SMC España, S.A. SWEDEN SMC Pneumatics Sweder AB

SWITZERLAND SM<sup>C</sup> Pneumatik AG UK

SMC Pneumatics (U.K.) Ltd.

ASIA CHINA SM<sup>2</sup> (China) Co., Ltd. HONG KONG SMC Pneumatics (Hong Kong) Ltd INDIA SMC Pneumatics (India) Pvt. Ltd. INDONESIA PT SMC Pneumatics Indonesia MALAYSIA SMC Pneumatics (S.E.A.) Sdn. Bhd. PHILIPPINES SHOKETSU-SMC Corporation

SINGAPORE SMC Prieumatics (S.E.A.) Pte Ltd. SOUTH KOREA SMC Pneumatics Korea Co., Ltd. TAIWAN SMC Prieumatics (Taiwan) Co., Ltd THAILAND SMC Thailand Ltd

#### NORTH AMERICA

CANADA SMC Pneumatics (Canada) Ltd. MEXICO SMC Corporation (Mexico) S.A. de C V USA SMC Corporation of America

#### SOUTH AMERICA

ARGENTINA SMC Argentina S.A BOLIVIA SMC Pneumatics Bolivia S.R.L. BRAZI. SMC Pneumaticos Do Brazil Ltda. CHILE SMC Pneumatics (Chile) S.A. SMC Neumatica Venezuela S.A

OCEANIA AUSTRA\_IA SMC Pneumatics (Australia) Ptv Ltd. NEW ZEALAND SMC Pneumatics (N.Z.) Ltd.

A Safety Instructions Be sure to read "Precautions for Handling Pneumatic Devices" (M-03-E3A) before using.

## **SMC** Corporation

Akihabara UDX 15F 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249 FAX: 03-5298-5362 URL http://www.smcworld.com © 2006 SMC Corporation All Rights Reserved