Vacuum Manifold for Fieldbus System



Ejector System

Fieldbus-compatible

- Requires no input/output unit. Space saving
- Reduced wiring time
- Compatible protocol

Vacuum Ejector Air consumption 90% reduction

Air saving by the energy saving SI unit and built-in pressure sensor (Under SMC's measurement conditions)

Supply valve: N.O. specification

- Can hold vacuum^{*1} even when the power goes out or is turned off
- Prevents the sudden dropping of workpieces^{*1}
- *1 Supposing the supply pressure is being maintained







Space saving/Less wiring work

■ Vacuum manifold for fieldbus system/For ZKJ

- Requires no separate input/output units
- Reduction of network load
- Less communication/power supply cables and wiring work
- Simple wiring/Minimized disconnection risk





Wiring and piping are integrated on one side.



Energy saving

Air saving by the energy saving SI unit and built-in pressure sensor



Energy saving efficiency: 90% reduction

Power consumption cost per year reduced by 10,098 JPY/year^{*2}

The energy saving function shortens the exhaust time, which reduces the annual power consumption cost.

With energy saving function

Per ejector		saving function			
	Power consumption cost per year	Annual air consumption	Air consumption (1 cycle)	Exhaust time (1 cycle)	
ZKJ/Energy saving function ON	1,122 JPY/year	748 m³/year	0.68 L	0.6 s	
ZKJ/Energy saving function OFF	11,220 JPY/year	7,480 m ³ /year	6.8 L	6 s	
	2	· · · · · · · · · · · · · · · · · · ·			



Valve protection

During operation of energy saving function, if the switching of vacuum stop/generate has reached the 'Count value', energy saving operation automatically switches to continuous adsorbing to prevent excessive valve operation.





Remote control and monitoring are available.



Vacuum port located above the exhaust port Easier replacement of the filter element

* The location of the vacuum port and exhaust port is different from ZK2 series.







Applicable for the high performance silencer exhaust





*2 Adsorbs the workpiece (nozzle diameter Ø0.7 (1 station)). (Under SMC's measurement conditions)

Variations

Nozzle size

ø0.7, ø1.0, ø1.2, ø1.5



Manifold stations

4 stations, 8 stations, 12 stations, 16 stations

Combination of supply valve and release valve

Supply valve	Release valve
N.O.	N.C.
N.C.	N.C.

Manual override for residual pressure release

None (Plug)/Red manual override*1

*1 Option

Air pressure supply (P) port

ø8, ø5/16" One-touch fittings

Air pressure supply (P) port

None (Plug)/ø6, ø1/4" One-touch fittings

Vacuum (V) port

ø6, ø8 One-touch fittings ø1/4", ø5/16" One-touch fittings

Wiring type

Communication —— connector (M12) Power supply connector — (M12)

Vacuum break flow adjusting needle



Manual override type



Screwdriver operation type long lock nut*1 *1 Option



High-noise reduction silencer exhaust



Port exhaust



Vacuum Manifold for Fieldbus System ZKJ Series

PROFINET Compatible

MRP/MRPD function

MRP (Media Redundancy Protocol) function

Communication can be continued even if one of the communication cables in the network is disconnected or damaged.

Furthermore, as it is possible to identify the disconnection point quickly, the network disconnection time can be kept within 200 ms.

 In order to use the MRP function, the PLC must be able to support it.



MRPD (Media Redundancy for planned duplication)

It is possible to duplicate routes with a ring topology configured with PROFINET IRT communication.

Or

for S^r fu

Communication reconnection time is faster than with the MRP function, so communication can be continued without recovery time.

Fast Start Up function

Time from power ON to communication connection:

Approx. 10 s

In the case of a tool changer, it takes about 10 seconds for communication to be connected in some products after the power to the device installed on the tool is turned ON.

For products which support the Fast Start Up function, communication can be operational even faster.

* In order to use the Fast Start Up function, the PLC must be able to support it.

FW (firmware) updates



5 s	Tabatan (1)	Save time when connecting and improve productivity
the Fast eart Up nction	Hodot arm	
	C C C C C C C C C C C C C C C C C C C	

ŧ٥.	Sel	Device Name	IP Address	Subnet Mask	Default Gateway	MAC Address	Vendor	Device Type	Device ID	Finnere	Update Result
		plcxbldled	192.168.0.1	255.255.255.0	192.168.0.1	AC-64-17-6E-88-80	SIEMEN	\$7-1500	276	list or over	
	Н	ex280-vpn1-16	182.168.0.2	255.255.255.0	192.168.0.3	00-23-08-AA-AA-AA	SMC Corp.	SHC EX260	18	Unknown	

- Batch firmware updating for up to 255 units is possible from the Ethernet line.
- Easy to handle future version upgrades

PROFINET Compatible

Shared Device function

An I/O data connected to an SI unit can be controlled and checked by multiple I/O controllers (PLC).

Example: PLC1 controls the valve while PLC2 checks pressures or diagnostic data.



- Information can be shared with up to 3 controllers in addition to the control PLC.
- The cost of the hardware, cables, and installation space can be reduced.
- Example: PLC4 controls the valves and checks pressures. Information of PLC4 is shared and monitored by PLC1 to 3.



* The Shared Device function enables an I/O module connected to the I/O device to be controlled by multiple I/O controllers (PLC). The control status can be shared among other I/O controllers. As the function can be used across the entire PROFINET line, the cost for hardware, cables, and installation space can be reduced.

SMC

CONTENTS

Vacuum Manifold for Fieldbus System ZKJ Series



How to Order	р. 9
Specifications	p. 11
Exhaust Characteristics/Flow Rate Characteristics	p. 13
Vacuum Release Flow Rate Characteristics,	
How to Read the Flow Rate Characteristics Graph	p. 15
Dimensions	p. 16
Air Circuit Diagram, Construction	p. 17
How to Order Replacement Parts	p. 18
Exploded View of Manifold	p. 19
How to Increase Manifold Stations	p. 20
Manifold Options	p. 21
Accessories	p. 22

Specific Product Precautions		p. 26
------------------------------	--	-------

Vacuum Manifold for Fieldbus System ZKJ Series (E RoHS

How to Order



Manifold stations

Symbol	Manifold stations	Vacuum ejector stations
04	4	Max. 4 stations
08	8	Max. 8 stations
12	12	Max. 12 stations
16	16	Max. 16 stations

* The product outline is every four stations manifold. Be sure that the total number of the ejectors and the blanking plates is equal to the manifold stations.

* The manifold model number cannot be ordered alone.

* The ejector can be increased by exchanging the blanking plate to an ejector, and also decreased for maintenance. Refer to How to Increase Manifold Stations on page 20.

2 SI Unit Specifications

Symbol	Protocol
FAN	PROFINET

3 U-side end plate and supply (P) port

Symbol	Supply (P) port
L8	ø8 Elbow One-touch fittings
LN9	ø5/16" Elbow One-touch fittings

Ordering Example

Example 1

 \cdot When the number of vacuum ejector stations is 6, select 8 stations for a manifold and order 2 sets of blanking plates.



Example 2

• When the number of vacuum ejector stations is 8 and it is possible that the stations increase to 12, select 12 stations for a manifold and order 4 sets of blanking plates.



When the manifold is viewed from V port, the first station starts from the left (D side).
After the manifold part number, specify the installed single unit from the first station.

[·] Please refer to Manifold Options on page 21 for details of the blanking plate.



Vacuum Manifold for Fieldbus System **ZKJ** Series





0	Nominal	nozzle	size
-			

Symbol	Nominal nozzle size
07	ø0.7
10	ø1.0
12	ø1.2
15	ø1.5

Ejector

Supply valve/ Release valve se

Pressure Option

ensor		

Symbol

н

Ρ

inch: ø5/16"

B Exhaust (EXH) port

Exhaust High-noise reduction silencer

exhaust

Port exhaust*2 *2 Port size of exhaust port; mm: ø8,

2 Vacuum (V) port, supply (P) port

Symbol	Standard	Vacuum (V) port	Supply (P) port	
C6	Motrio	ø6		
C8	weinc	ø8	Dlug	
N7	Inch	ø1/4"	Flug	
N9	Inch	ø5/16"		
C6U	Matria	ø6	~6*1	
C8U	weinc	ø8	00	
N7U	Inch	ø1/4"	a1/4"*1	
N9U	men	ø5/16"	01/4	

*1 When selecting "Plug for individual supply" for options (8) or increasing the flow rate of supply air, select Supply (P) port.

4 Combination of supply valve and release valve

Symbol Supply valve		Release valve
Α	N.C.	N.C.
E	N.O.	N.C.

7 Pressure sensor

Symbol	Specifications	
T1	-100 to 100 [KPa]	

5 Rated voltage

Symbol	Voltage
5	24 VDC

6 Light/surge voltage suppressor and common specification

Symbol	With light	Surge voltage suppressor	Common specification
U	Yes	Yes	Non-polar

8 Option

Symbol	Туре
Nil	Without option
Е	Vacuum break flow adjusting needle screwdriver operation type long lock nut
М	Plug for individual supply ^{*3} (Blocking the air supply passage to the D side)
R	With manual override for residual pressure release*4
Y	Vacuum (V) port release to atmosphere type (Check valve: 1 pc.)*5

*3 The supply (P) port for vacuum manifold is mounted only on the U side. Select the supply (P) port for 2 on the D side of the

ejector where the plug for individual supply is mounted. For detail, refer to Manifold Option on page 21.

*4 Manual override to release vacuum (V) port to atmosphere. *5 When "Y" is selected, the energy saving function is not

available. When the vacuum generation is stopped, the vacuum (V) port is released to the atmosphere.

ZKJ Series



Specifications

Ejector Specifications*1

Model		ZKJ07	ZKJ10	ZKJ12	ZKJ15
Fluid			A	ir	
Nozzle size [mm]		0.7	1.0	1.2	1.5
Standard supply	pressure [MPa]		0.	.4	
Max. vacuum pre	ssure [kPa]*2		-8	39	
Max. suction	Port exhaust	31	53	63	74
flow rate [L/min (ANR)]*3	High-noise reduction silencer exhaust	31	51	60	68
Air consumption	[L/min (ANR)]*2	26	48	68	102
Supply pressure	range [MPa]		0.3 te	o 0.5	
Type of actuation		Supply valve: N.C., Release valve: N.C. (ZKJ-JSY3A) Supply valve: N.C., Release valve: N.C. (ZKJ-JSY3E)			
Response time (a	at 0.5 MPa)*4	23 ms or less			
Max. operating fr	requency	3 Hz			
Manual override		Non-locking push type			
Power consumpt	ion	0.4 W			
Operating temperature range 0 to 50°C (No condens		condensation)		
Environmontol	Vibration resistance*5		30 r	n/s²	
resistance	Impact resistance*6		150	m/s²	
	Withstand voltage	500 VAC fo	or 1 minute be	tween termin	als and FE
	Insulation resistance	500 VDC, 10	$\ensuremath{M}\Omega$ or more	between term	inals and FE
Enclosure*7			IP	65	
Standards		CE marking (EMC directive/RoHS directive)			

*1 The supply valve and release valve mounted on this product is the SMC dual 3-port valve JSY3000 series. Refer to the Web Catalog for details on the JSY3000 series.

*2 Values are at the standard supply pressure and based on SMC's measurement standards. They depend on atmospheric pressure (weather, altitude, etc.) and the measurement method.

*3 If the vacuum port diameter is ø6 or ø1/4", Max. Suction flow rate is reduced by 15% or less.
 *4 It shows supply valve/release valve specification. Based on dynamic performance test, JIS B

- 8419-2010. (Coil temperature: 20°C, at rated voltage) *5 The characteristics are satisfied when tested for 2 hours in each of the X, Y and Z directions
- at 10 to 500 Hz without energization. (Initial value)
 The characteristics are satisfied when tested on 2 hours in each of the X, Y and Z directions at 10 to 500 Hz without energization. (Initial value)
- *6 The characteristics are satisfied when tested one time in each of the X, Y and Z directions without energization. (Initial value)
- *7 Cannot be used in an environment where oil such as cutting oil splashes or it is constantly exposed to water

Take appropriate protective measures.

Max. Number of Manifold Stations that Can Operate Simultaneously*8

Model	ZKJ07	ZKJ10	ZKJ12	ZKJ15
Air supply: 1 section (U-side end plate P port (ø8))	16	6	5	3
Air supply: 2 sections (U-side end plate P port (ø8), Vacuum ejector P port (ø6))	16	8	7	4

*8 Values are the number of ejector stations that can be generated vacuum simultaneously.

Noise Level (Reference values)

Model	ZKJ07	ZKJ10	ZKJ12	ZKJ15
Noise level [dB(A)]	52	63	67	71

*9 Values are at the standard supply pressure.

*10 Values are with 1 ejector generating vacuum pressure adequately for adsorption with highnoise reduction silencer (Not guaranteed values)

Weight

Manifold stations (ejectors)	4 stations	8 stations	12 stations	16 stations
Weight [kg]	1.7	2.5	3.3	4.1
	• • • •			·

*11 When the blanking plate is mounted, please subtract 0.1 [kg] per unit.

Specifications





Model			EX260-VPN1	
Electrical	Power supply	Power supply voltage	24 VDC ±10%	
	Input	Internal current consumption	100 mA or less	
	Power supply for output	Power supply voltage	24 VDC +10%, -5%	
	Protocol		PROFINET	
	Device type		PROFINET IO	
	Configuration file		GSD File	
	Version		PROFINET Specification Version 2.3	
	Communication speed		100 Mbps full duplex	
Communication	Applicable function		MRP function MRPD function Fast Start Up function Shared Device function FW update function Conformance Class C Net Load Class III	
Vacuum	Im Applicable function		Energy saving Valve protection Zero-clear function	

Control Unit Specifications

	Model	ZKJ-S004-A	ZKJ-S008-A	ZKJ-S012-A	ZKJ-S016-A
Station		4	8	12	16
	Pressure sensor	4	8	12	16
Input	Pressure sensor short circuit detection/Protection circuit Built-in (Common detection)		letection/pro	tection)	
	Number of valve outputs	8	16	24	32
Output	Valve short circuit detection/ Protection circuit	Built-in (Individual detection/protection)			

Pressure Sensor Specifications

(For details, refer to the PSE54 series in the Web Catalog, and the Operation Manual.)

Item	Specifications
Rated pressure range	-100 to 100 [kPa]
Withstand pressure*1	500 [kPa]
Accuracy	±3% F.S.
Current consumption	15 mA or less
Sensor pressure receiving area	Silicon

*1 Do not use the product to drive an actuator such as a cylinder (when release pressure is constantly applied).

Connector/LED Indicator

	Part no.	EX260-VPN1	EX260-VPN1	
	Protocol	PROFINET	I /A 1: BLIS IN state	I /A 2: BUS OUT state
	Communication connector (M12) BUS OUT	4-pin, Socket, D-coded (SPEEDCON)		
	Communication connector (M12) BUS IN	4-pin, Socket, D-coded (SPEEDCON)		
£•	Ground terminal			
	Power supply connector (M12)	4-pin, Plug, A-coded (SPEEDCON)	SF: SI Unit diagnostic	PWR(V): Power supply for output
			BF: Communication state	PWR: Power supply for control and input

ZKJ Series

- Values are based on standard of SMC measurements. They depend on atmospheric pressure (weather, altitude, etc.) and measurement method.
- The flow rate characteristics correspond to the standard supply pressure.

Exhaust Characteristics/Flow Rate Characteristics (Representative value)

ZKJ07







* Port exhaust: V port ø8, no exhaust port piping

ZKJ10

Exhaust Characteristics





Vacuum Manifold for Fieldbus System **ZKJ** Series

- Values are based on standard of SMC measurements. They depend on atmospheric pressure (weather, altitude, etc.) and measurement method.
- The flow rate characteristics correspond to the standard supply pressure.

Exhaust Characteristics/Flow Rate Characteristics (Representative value)

ZKJ12

Exhaust Characteristics





* Port exhaust: V port ø8, no exhaust port piping

ZKJ15

Exhaust Characteristics





ZKJ Series

Vacuum Release Flow Rate Characteristics (Representative value)

The graph shows the flow rate characteristics at different supply pressures when the vacuum break flow adjusting needle is open from the fully closed state. The actual suction flow at the point of suction varies depending on the piping conditions.



How to Read the Flow Rate Characteristics Graph



The flow rate characteristics indicate the relationship between the vacuum pressure and the suction flow of the ejector. They also show that when the suction flow changes, the vacuum pressure also changes. In general, this indicates the relationship at the ejector's standard operating pressure. In the graph, **Pmax** indicates the max. vacuum pressure, and **Qmax** indicates the max. suction flow. These are the values that are published as specifications in catalogs, etc. Changes in vacuum pressure are explained in the order below.

- 1. If the ejector's suction port is closed and sealed tight, the suction flow becomes "0," and the vacuum pressure increases to the max. (**Pmax**).
- 2. If the suction port is opened gradually and air is allowed to flow (the air leaks), the suction flow increases, and the vacuum pressure decreases. (The condition of P1 and Q1)
- 3. If the suction port is opened completely, the suction flow increases to the max. (Qmax), while the vacuum pressure then drops almost to "0" (atmospheric pressure).

As described above, the vacuum pressure changes when the suction flow changes. In other words, when there is no leakage from the vacuum (V) port, the vacuum pressure can reach its maximum, but as the amount of leakage increases, the vacuum pressure decreases. When the amount of leakage and the maximum suction flow become equal, the vacuum pressure becomes almost zero. When adsorbing workpieces which are permeable, subject to leakage, etc., caution is required as the vacuum pressure will not be very high.

Vacuum Manifold for Fieldbus System **ZKJ** Series







62



υţ

Supply (P) port Metric: ø6 Inch: ø1/4"

							[mm]
Manifold stations		4	8		12	16	
L1		142	202		262	322	
L2		118	178	178 238			298
Port type		е	Α	A Hexagon width across flats B		С	
Motrio	C6	ø6	14.8		4		9.7
Metho	C8	ø8	18	6		—	
Inch	N7	ø1/4"	16.3	4.76			12.3
IIICII	N9	ø5/16"	18		6		_

ZKJ Series

Air Circuit Diagram



Construction



Component Parts

No.	Description	Material	Note	
1	Valve adapter assembly	PBT	FKM, HNBR, Stainless steel, and Aluminum are also used.	
2	Valve body assembly	PBT	FKM and Stainless steel are also used.	
3	Sealing valve body assembly	PBT	FKM, HNBR, Stainless steel, and Aluminum are also used.	
4	4 Ejector body assembly PBT HNBR and Stainless steel are also used.		HNBR and Stainless steel are also used.	
5	Supply valve and release valve assembly	_	Refer to page 18 for replacement parts.	
6 Pressure sensor assembly — — —		_		
7	Vacuum port adapter assembly	—	Refer to page 18 for replacement parts. With One-touch fitting and filter element	
8	Filter element	Non-woven fabric	Refer to page 18 for replacement parts. Nominal filtration rating: 30 μ m, 10 pcs. per set	
9	High-noise reduction silencer assembly	POM, PVA	Refer to page 28 for replacement procedure. With sound absorbing material (Part number: ZK2-SE4-6-A)	
10	Needle assembly	Brass	Electroless nickel plated brass, resin, steel and FKM are used.	
11	Check valve	HNBR	When option "Y" is selected, the check valve on the left side as shown in the above figure is not mounted	

How to Order Replacement Parts



O Vacuum port adapter assembly (Purchasing order is available in units of 1 piece.)



For replacement procedure, refer to the "Specific Product Precautions" on page 27.



For replacement procedure, refer to the "Specific Product Precautions" on page 27.



For replacement procedure, refer to the "Specific Product Precautions" on page 28.

ZKJ Series Exploded View of Manifold



Component Parts

No.	Description	Material	Note
1	SI unit	—	Refer to (1) below for replacement parts.
2	Control unit	—	Refer to 2 below for replacement parts.
3	D-side end plate	Stainless steel	_
4	U-side end plate	Stainless steel	—
5	Elbow type One-touch fitting assembly	_	Refer to (5) below for replacement parts.
6	Protection plate	PC	Refer to (6) below for replacement parts.
7	Tension bolt	Steel	Refer to $\overline{\mathcal{O}}$ below for replacement parts.
8	DIN rail	Aluminum	Refer to (8) below for replacement parts.

1) SI unit

EX260 - V PN 1

2 Control unit

ZKJ - S0 04 - A

SI unit specifications				
Symbol	Protocol			
PN	PROFINET			

6 Protection plate

-	
12	Manifold stations: 12 stations
16	Manifold stations: 16 stations

(7) Tension bolt (3 pcs. per set)

ZKJ – TB1 – 4 – A • Length symbol				
4	Manifold stations: 4 stations			
8	Manifold stations: 8 stations			
12	Manifold stations: 12 station			
16	Manifold stations: 16 station			

8 DIN rail

Length symbol

- 1 Manifold stations: 4 stations (Length: 110.5 mm)
- 6 Manifold stations: 8 stations (Length: 173 mm)
- **10** Manifold stations: 12 stations (Length: 223 mm)
- 15 Manifold stations: 16 stations (Length: 285.5 mm)

•Length symbol			
04	Manifold stations: 4 stations		
08	Manifold stations: 8 stations		
12	Manifold stations: 12 stations		
16	Manifold stations: 16 stations		

Elbow type One-touch fitting assembly
 SZ3000 - 74 - 1A - L8 (ø8 elbow)

KQ2L09 - 14 - X224 (ø5/16" elbow)



How to Increase Manifold Stations



When increasing over 4, 8, 12 manifold stations, exchange the Control Unit, Tension bolts, Protection plate and DIN rail for suitable parts for manifold stations. Refer to Exploded View of Manifold on page 19.



Manifold Options

Blanking plate

[With two connector plug assembly] Used in situations where ejectors are not mounted for manifold.





Plug for individual supply

By placing "Plug for individual supply" in an ejector manifold's pressure supply passage, two different pressures can be supplied to one manifold.

The supply (P) port for vacuum manifold is mounted only on the U side. Be sure to select the supply (P) port for ejector model number on the D side of the ejector where the plug for individual supply is mounted.









Communication Cable





EX9-AC 005 EN-PAPA (With angled connector on both sides (Plug/Plug))



Conductor nominal cross section Wire O.D. (Including insulator)

Min. bending radius (Fixed)

Item	Specifications
Cable O.D.	ø6.5 mm
Conductor nominal cross section	0.34 mm ² /AWG22
Wire O.D. (Including insulator)	1.55 mm
Min. bending radius (Fixed)	19.5 mm

0.34 mm²/AWG22

1.55 mm

19.5 mm

ZKJ Series

Communication Cable



2 Field-wireable Communication Connector

PCA-1446553



Applicable Cable

	Item	Specifications
Cable O.D.		4.0 to 8.0 mm
Wire gauge (S	tranded wire cross section)	0 14 to 0 34 mm ² /AWG26 to 22

The table above shows the specifications for the applicable cable. Adaptation for the connector may vary on account of the conductor construction of the electric wire.



Over Supply Cable





2 3 5

ZKJ Series

Power Supply Cable



Seal Cap (10 pcs.)

Use this on ports that are not being used for communication connector (M12 connector socket).

Use of this seal cap maintains the integrity of the IP65 enclosure.

 $\ast~$ Tighten the seal cap with the prescribed tightening torque. (For M12: 0.1 N·m)



Connector specification
 TS For M12 connector socket (10 pcs.)



For M12 connector socket

One waterproof cap is provided for an EX260-VPN1.



Be sure to read this before handling the products. Refer to the back cover for safety instructions. For vacuum equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

Design / Selection

▲ Warning

1. Confirm the specifications.

Products represented in this catalog are designed only for use in compressed air systems (including vacuum).

Do not operate at pressures, temperatures, etc., beyond the range of specifications, as this can cause damage or malfunction. (Refer to the specifications.)

Please contact SMC when using a fluid other than compressed air (including vacuum).

We do not guarantee against any damage if the product is used outside of the specification range.

2. Do not use the product to drive an actuator such as a cylinder (when release pressure is constantly applied).

Failure to do so may lead to performance issues or damage to the body of the product.

3. Vacuum pressure

Since valves are subject to air leakage, they cannot be used for applications such as holding vacuum in a pressure vessel. SMC can issue no guarantees regarding the maintenance of workpiece adsorption when using check valves. Take separate safety measures to prevent workpieces from dropping in the case of an electrical power outage, etc.

4. Cannot be used as an emergency shutoff valve, etc.

The valves presented in this catalog are not designed for safety applications such as an emergency shutoff valve. If the valves are used in this type of system, other reliable safety assurance measures should also be adopted.

5. Release of residual pressure

For maintenance and inspection purposes, ensure to install the residual pressure release system when piping.

6. Vacuum adsorption

At the time of vacuum adsorption, be sure to supply a constant supply of vacuum. Failure to do so may result in foreign matter sticking to the adsorption pad or air leakage, causing the workpiece to drop.

7. Ventilation

Provide ventilation when using a vacuum ejector in a confined area, such as in a closed control panel. For example, install a ventilation opening, etc., in order to prevent pressure from increasing inside of the confined area and to release the heat generated by the valve.

8. Extended periods of continuous energization

If a valve will be continuously energized for an extended period of time, the temperature of the valve will increase due to the heat generated by the coil assembly. This will likely adversely affect the performance of the valve and any nearby peripheral equipment. Therefore, if the valve is to be energized for periods of longer than 30 minutes at a time, or if during the hours of operation the energized period per day is longer than the de-energized period, we advise using a N.O. (normally open) valve.

9. Resumption after a long period of holding time

When resuming operation after a long period of holding time, there are cases in which, regardless of whether the product is in an ON or OFF state, there is a delay in the initial response time due to adhesion. Conducting several cycles of running-in operation will solve this problem. Please consider implementing this before resumption.

Design / Selection

▲ Caution

- 1. For specific product precautions on solenoid valves, refer to the solenoid valve (JSY3000 series) catalog.
- 2. For specific product precautions on pressure sensors, refer to the pressure sensor (PSE54□ series) catalog.

Supply Valve / Release Valve

A Warning

1. Manual override operation

Regardless of an electric signal for the valve, the manual override is used for switching the main valve. Connected actuator is started by manual operation. An alarm may occur when using the manual override during PROFINET communication. Use the manual override when the power supply is turned off.

Manual override is non-locking push type. Push the manual override with a screwdriver of a diameter smaller than indicated in the diagram until it reaches the end.



2. Energization

When workpiece is being adsorbed, please keep generating the vacuum pressure to prevent the workpiece from dropping. Do not perform the operation to generate vacuum and release pressure at the same time as this may cause malfunction.





Be sure to read this before handling the products. Refer to the back cover for safety instructions. For vacuum equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

Supply Valve / Release Valve

▲ Warning

3. LED indication

Red LED turns on when supply valve is energized. Green LED turns on when release valve is energized.

LED light position



4. Air leakage

Zero air leakage is not guaranteed for the supply valve or release valve.

Be aware that because there is a chance of air and vacuum leakage, the pressure may change if the V port side is tightly sealed.

Manual Override for Residual Pressure Release

\land Warning

V port is released to atmosphere when performing the manual override for residual pressure release. Please perform after ensuring measured are in place to prevent the workpieces from dropping, etc.



Manual override for residual pressure release Option

Replacement Procedure

A Caution

1. Replacement Procedure for Filter Element

- 1) To pull out the vacuum port adapter, rotate the adapter by about 90 degrees in direction A and pull in direction B. The adapter can be removed with the filter element from the sealing valve body.
- 2) Remove the filter element from the vacuum port adapter and replace it with a new filter element.



3) When installing the filter, insert the filter to the end so that there is no gap*1 or bending*2 between the filter and the vacuum port adapter.

A gap or bending will cause interference with internal parts, the filter element to deform and deterioration of the performance.

Bending ^{*2}

- 4) Put the filter element back into the sealing valve body following this procedure in reverse.
- To mount the vacuum port adapter into the sealing valve body, turn the adapter so that the mark of the adapter is on top (rotation stops there.).



• If it is difficult to remove the vacuum port adapter, you can remove the adapter with a hexagon wrench using the hexagonal hole in V port. The table shows the port size and the width across flats.



SMC



Be sure to read this before handling the products. Refer to the back cover for safety instructions. For vacuum equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

Replacement Procedure

▲ Caution

2. Replacement Procedure for High-noise Reduction Silencer Assembly

1) Flip the ejector.

 To remove the clip that holds the High-noise reduction silencer, insert a precision screwdriver. Move the screwdriver to pull out the clip.



3) Remove the high-noise reduction silencer.

(Procedure to put parts back together)

- 4) Insert the High-noise reduction silencer and insert the clip into the groove. (Push completely to the end.)
 - * Do not pull or bend the two projections at the end surface of the diffuser. These are spacers to prevent the displacement of the diffuser and they may break if force is applied.

Replacement Procedure

A Caution

- 3. When only replacing the sound absorbing material (for high-noise reduction silencer exhaust)
 - 1) Use the notch to remove the cap.
 - 2) Use a precision screwdriver to remove the sound absorbing material.
 - 3) Insert the new sound absorbing material, and return the cap.



Ejector Exhaust / Exhaust Noise

A Caution

1. Ejector exhaust

The exhaust resistance should be as small as possible to obtain the full ejector performance. There should be no shield around the exhaust slit for silencer exhaust type.

For port exhaust type, ensure that the back pressure does not exceed 5 kPa. Increased back pressure may lead to the reduction of suction flow and delays in the transport cycle time. Do not operate the ejector or apply pressure to the exhaust port with the exhaust port closed. This increases the pressure in the product and can damage the vacuum ejector.

2. Sound absorbing material

If the sound absorbing material is clogged, it will cause a reduction in the ejector performance.

Sometimes, if the operating environment contains a lot of particles or mist, the replacement of the filter element only is not enough to recover vacuum performance - as the sound absorbing material may be clogged.

Replace the sound absorbing material. (Regular replacement of the filter element and the sound absorbing material is recommended.)



Be sure to read this before handling the products. Refer to the back cover for safety instructions. For vacuum equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

Ejector Exhaust / Exhaust Noise

▲ Caution

3. Exhaust noise

When vacuum ejector generates vacuum, noise can be heard from the exhaust port when the standard supply pressure is close to the pressure that generates peak vacuum pressure making vacuum pressure unstable. If the vacuum pressure range is adequate for adsorption, there should not be a problem. If the noise causes a problem or affects the setting of the SI unit, change the supply pressure slightly to avoid the pressure range of the noise.



Models with a large nozzle diameter generate a large exhaust noise if the exhaust (EXH) port is opened. Install piping or a silencer to the exhaust port to reduce the exhaust noise.

4. Exhaust air

If solid substances are sucked in through the vacuum (V) port, they will be discharged from the exhaust port at a high speed if the exhaust (EXH) port is opened. Therefore, do not look into the exhaust port or direct the exhaust port toward a person when the ejector is operating.

Operating Supply Pressure

▲ Caution

Use the product within the specified supply pressure range. Operation over the max. operating pressure can cause damage to the product.

The parts around the vacuum port of this product are designed to be used with vacuum pressure.

Port Size

▲ Caution

1. Air pressure supply (P) port

P port (End plate U) and P port (Ejector) are connected inside. For an adequate performance, the number of stations when operated simultaneously depends on the nozzle diameter. Refer to page 11 for the number of stations that can operate simultaneously for each ejector size.

How to Mount a Manifold

▲ Caution

1. Do not drop, hit, or apply excessive impact to the product when handling it. Even if the body looks undamaged, the internal

components may be damaged, leading to a malfunction.

2. Load to the body

The product body is made of resin; therefore, do not apply load to the port after mounting. Prevent any kind of operation which generates moment as this may cause reduced performance or damage to the body.

3. Installation

Manifold can be mounted onto the floor using M6 holes on the end plate. The DIN rail installed in the product is used for connecting the ejectors. Do not use mounting holes of the DIN rail to mount the product.

4. Ensure sufficient space for maintenance activities.

When installing the products, allow access for maintenance and inspection.

Vacuum Break Flow Adjusting Needle

▲ Caution

1. The flow rate characteristics show the representative values of the product itself.

They may change depending on piping, circuit and pressure conditions, etc. The flow rate characteristics and the number of needle rotations vary due to the range of the specifications of the product.

2. The needle has a retaining mechanism, so it will not turn further when it reaches the rotation stop position.

Turning the needle too far may cause damage.

3. Do not tighten the handle with tools such as nippers.

This can result in breakage due to idle turning.

4. Do not over tighten the lock nut.

It is possible to tighten the standard lock nut (hexagon) manually.

When tightening further with tools, tighten by approximately 15° to 30°. Over tightening may cause breakage.

5. When vacuum break flow adjusting needle screwdriver operation type (-E) is selected as option, make sure the lock nut is not loose to prevent the nut from coming off due to vibration.

■ Vacuum Release Air

When fully closed, leakage cannot be prevented completely. There is an allowance for a certain amount of leakage in the product's specifications. Tightening the needle to reduce leakage to zero may result in equipment damage.



Be sure to read this before handling the products. Refer to the back cover for safety instructions. For vacuum equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

Operating Environment

A Warning

- 1. Do not use in an atmosphere containing corrosive gases, chemicals, sea water, water, water steam, or where there is direct contact with any of these.
- 2. IP65 enclosure: The protection structure against solid foreign objects is dust-tight type and the protection structure against water is water-jet-proof type.

Dust-tight means that no dust can enter the inside of the equipment. Water-jet-proof means that the product is not adversely affected by direct water jets from any direction. That is, even when direct water jets are applied to the product for 3 minutes by means of the pre-determined method, there is no water entry that hinders the correct operation inside the equipment. Be sure to take appropriate protective measures if the product is to be used in an environment where it will be constantly exposed to water or fluids other than water splash. In particular, the product cannot be used in environments where oils, such as cutting oil or cutting fluid, are present.

- 3. IP65 is achieved when the following conditions are met.
 - 1) Provide appropriate wiring between the SI units using electrical wiring cables, communication connectors, and cables with M12 connectors.
 - Suitable connecting of connectors for supply valve and release valve assembly, pressure sensor assembly and the control unit.
 - 3) Suitable mounting of SI Unit, control unit and vacuum ejectors.
 - 4) Be sure to fit a seal cap on any unused connectors.
- 4. When the high performance silencer is used for an IP65 compliant manifold, prevent water from splashing onto the silencer outlet.

Piping

A Caution

When piping to the product, be careful not to confuse a vacuum port with an exhaust port. Otherwise this can result in damage or reduced performance. Apply compressed air after confirming that the piping is connected correctly.

If each exhaust piping for the port exhaust ejectors are connected and made into centralized piping, the exhausted air will flow back into the exhaust path which is not operating, and will then be exhausted from the vacuum port. Exhaust individually.

Adjustment / Operation

▲ Caution

- 1. Please refer to the PLC manufacturer's manual, etc. for details of the SI unit programming and addresses. The programming content related to the protocol is designed by the manufacturer of the PLC used.
- 2. For the first operation, always perform zero clear with no pressure applied.



▲ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "**Caution**," "**Warning**" or "**Danger**." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)^{*1}, and other safety regulations.

- Caution: indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.
- Warning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

AWarning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
 - The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.

- 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
- 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
- An application which could have negative effects on people, property, or animals requiring special safety analysis.
- 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

- *1) ISO 4414: Pneumatic fluid power General rules relating to systems.
 - ISO 4413: Hydraulic fluid power General rules relating to systems. IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements)
 - ISO 10218-1: Manipulating industrial robots Safety. etc.

 The product is provided for use in manufacturing industries. The product herein described is basically provided for peaceful use in manufacturing industries. If considering using the product in other industries, consult SMC beforehand

and exchange specifications or a contract if necessary. If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
 - *2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

- The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

A Safety Instructions Be sure to read the "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" before use.