

Mist Separator

Series AM

Series AM can separate and remove oil mist in compressed air which is difficult to remove by ordinary air filters and remove solid particles such as rust or carbon of more than 0.3μm. It is the most suitable for air sources that drive pilot, metal seal solenoid valves.



Model

Model	AM150	AM250	AM350	AM450	AM550	AM650	AM850
Rated flow (ℓ/min (ANR)) ⁽¹⁾	300	750	1500	2200	3500	6000	12000
Port size (Nominal size B)	1/8, 1/4, 3/8	1/4, 3/8, 1/2	3/8, 1/2, 3/4	1/2, 3/4, 1	3/4, 1	1, 1 1/2	1 1/2, 2
Weight (kg)	0.38	0.55	0.9	1.4	2.1	4.2	10.5



Note 1) Max. flow capacity at a pressure of 0.7MPa. It varies depending on operating pressure. Refer to "Flow Characteristics" (p.4.6-2) and figure of "Max. air flow" (p.4.6-3).

Specifications

Fluid	Compressed air
Max. operating pressure	1.0MPa
Min. operating pressure ⁽¹⁾	0.05MPa
Proof pressure	1.5MPa
Ambient and fluid temperature	5 to 60°C
Filtration	0.3μm (95% particle size collection)
Oil mist removal rate	Max.1.0mg/m ³ (ANR) (≒0.8ppm) ⁽²⁾
Element life	2 years or when pressure drop reaches 0.1MPa

Note 1) With Auto drain: 0.15MPa

Note 2) At oil mist removal rate blowing compressor is 30mg/m³(ANR) (ANR)

Accessories (Options)

Applicable models	AM150	AM250	AM350	AM450	AM550	AM650	AM850
Bracket assembly (With cap bolt, spring washer)	BM51	BM52	BM53	BM54	BM55	BM56	BM57

Symbol



P.4.6-6

How to Order

AM 250 03 B J

Body size

150	1/8
250	1/4
350	3/8
450	1/2
550	3/4
650	1
850	1 1/2

Thread

—	Rc(PT)
F	G(PF)
N	NPT

Port size

01	1/8 ^B	06	3/4 ^B
02	1/4 ^B	10	1 ^B
03	3/8 ^B	14	1 1/2 ^B
04	1/2 ^B	20	2 ^B

Accessories (Options)*

Symbol	Description
—	None
B	Bracket
C	N.C. auto drain
D	N.O. auto drain

*Refer to the table below for accessory/option combinations.

Options *

J	Drain guide 1/4 ^B female thread
R	IN→OUT reversal
T	Element service indicator



Note) Refer to p.4.7-7 for "How to Order" of case assembly.

Table: Accessory/Option combinations

○Available ■Not available ○ Depending on model








Accessories /Options		Accessories		Options			Applicable models						
		C	D	J	R	T	AM150	AM250	AM350	AM450	AM550	AM650	AM850
Accessories	N.C. auto drain	C				○	○	○	○	○	○		
	N.O. auto drain	D				○	○	○	○	○	○	○	○
Options	Drain guide 1/4 ^B	-J				○	○	○	○	○	○	○	
	IN→OUT reversal	-R	○	○	○		○	○	○	○	○	○	○
	Element service indicator	-T	○	○	○	○		○	○	○	○	○	○

Flow Characteristics

Element oil saturation



Note) Compressed air over max. flow line in the table below may not meet the specification of product. It may cause damage to the element.



- ③ When using the type with a drain valve, drain guide, or a ball valve, discard the drainage before the drainage level reaches the center of the sight glass. If the drainage is not discarded properly, it will flow to the secondary side.



Precautions

Be sure to read before handling. Refer to p.0-26 and 0-27 for Safety Instructions and common precautions on the products mentioned in this catalog, and refer to p.4.0-5 to 4.0-7 for more detailed precautions of every series.

Design



Caution


- Design the layout so that the mist separator is installed in an area that is less susceptible to pulsations. The element could be damaged if the difference in internal and external pressures exceeds 0.1MPa.
- When using the auto drain, connect the drain piping in the following range:
Normally closed (N.C.)
Normally open (N.O.)
Because tube fittings are provided, use a tube with a bore of 10mm, and keep the overall pipe length within 5m.
AM850 type (N.O)
Use a tube with a bore of 9mm or more, and keep the overall pipe length within 2.8m.
If the normally open (N.O.) auto drain is used, because it is designed so that the valve will not open unless the air pressure is 0.15MPa or higher, air could continue to blow out of the drainage discharge area if an air compressor with a small air discharge volume is used. Therefore, when using a compressor that is smaller than 3.7kW, make sure to use the normally closed (N.C.) auto drain.
- The bracket that is provided with the product is for supporting the product itself. Thus, it cannot support the piping or other items that are connected. If these items need to be supported, provide an additional support.

Mounting



Caution

- Verify the direction of the flow of the compressed air and the "▷" mark that indicates the inlet of the product before connecting. It cannot be used if connected in the opposite direction.



- Make sure to install this product on horizontal piping. If it is installed diagonally, laterally, or upside down, the drainage that is separated by the element will splash to the secondary side.

Maintenance



Caution

- The replacement interval for the element is when the pressure drop reaches 0.1MPa or after 2 years of operation, whichever comes first. A pressure drop can be verified with the type with a clogging checker (-T) or with the type with a pressure differential gauge (Made to Order).
- When the element has reached its replacement interval, replace it immediately with a new element. Replace the O-ring, the gasket, and the element with new parts. For note ③, refer to the left.

HA ☐

AT ☐

ID ☐

AMG ☐

AFF ☐


AM ☐

Related products


Series AM

Construction

AM150 to AM550



AM650 to AM850



Component Parts

No.	Description	Material	Note
①	Body	Aluminum die cast	Chromate treatment
②	Housing	Aluminum die cast *	Epoxy coating on inner surface
③	Sight glass	Tempered glass	

* AM850 is aluminum cast.



Note) Sight glass is indicated in the figure above for easy understanding of parts, however mounting position is different. Refer to Dimensions for details. (p.4.6-4 through p.4.6-5)


Replacement Parts

No.	Description	Material	Part No.						
			AM150	AM250	AM350	AM450	AM550	AM650	AM850
④	Element assembly	Glass fiber NBR	AM-EL150	AM-EL250	AM-EL350	AM-EL450	AM-EL550	AM-EL650	AM-EL850

* With gasket and O ring

Max. Air Flow

Max. Flow






How to Select

Select the model in accordance with the following procedure taking the inlet pressure and max. air flow into consideration.
(Example) Inlet pressure: 0.6MPa
Max. air flow capacity: 5m³/min.(ANR)
① Select the point of contact A of inlet pressure and max. air flow capacity in the graph.
② Select the type whose max. air flow capacity is over that point; AM650.
Note) Make sure to select a model that has the maximum flow rate line above the obtained intersecting point. With a model that has the maximum flow rate line below the obtained intersecting point, the flow rate will be exceeded, thus leading to a problem such as being unable to satisfy the specifications.




Dimensions: AM150 to AM650




Accessories

D: With auto drain (N.O.)




C: With auto drain (N.C.)




*N.C. auto drain not available for AM650

Options

J: With drain guide



T: With element service indicator



Model	Port size (Nominal size B)	A	B	C	D	E	F	G	Dimensions with mounting bracket												Element service indicator		
									H	I	J	K	L	M	N	O	P	Q	R	S	T	U	
AM150	1/8, 1/4, 3/8	159	13	100	63	20	63	10	166	56	15	5	9	5.5	35	54	70	26	4.5	1.6	24	37	
AM250	1/4, 3/8	172	13	113	76	20	76	10	187	66	20	8	12	6	40	66	84	28	5	2.0	27	37	
	1/2	178	16	119	76	20	76	10	187	66	17	8	12	6	40	66	84	28	5	2.0	27	37	
AM350	3/8, 1/2	204	16	145	90	20	90	10	218	80	22	8	14	7	50	80	100	34	5	2.3	32	37	
	3/4	210	19	151	90	20	90	10	218	80	19	8	14	7	50	80	100	34	5	2.3	32	37	
AM450	1/2, 3/4	225	19	166	106	20	106	10	241	90	25	10	14	9	55	88	110	50	9	3.2	37	37	
	1	232	22	173	106	20	106	10	241	90	21	10	14	9	55	88	110	50	9	3.2	37	37	
AM550	3/4, 1	259	22	200	122	20	122	10	277	100	30	10	16	9	65	102	130	60	10	4.5	39	37	
AM650	1, 1 1/2	311	32	253	160	20	160	10	334	150	40	15	20	11	85	136	180	76	12	4.5	55	37	



AM150.....SAM, #1 AM450.....SAM, #4
 AM250.....SAM, #2 AM550.....SAM, #5
 AM350.....SAM, #3 AM650.....SAM, #6

HA

AT

ID

AMG

AFF


AM

Related products

Series **AM**




Dimensions: AM850





Accessory

D: With auto drain (N.O.)
for AMD850



Options

T: With element service indicator



Mdel	Port size (Nominal size B)	A	B	C	D	E	F	G	Dimensions with mounting bracket											
									H	I	J	K	L	M	N	O	P	Q	R	S
AM850	1 1/2, 2	460.5	42	348	220	57.5	220	10	463.5	180	30	15	24	13	120	184	220	110	18	6.0



AM850.....SAM, #7


① With Pressure Differential Gauge (GD40-2-01)

A pressure differential gauge can be installed in the body to check the life of filter element. It allows for easier piping and compact size.


Specification

Applicable model	AM150 to AM850
------------------	----------------

How to Order *Refer to "How to Order" for standard type (p.4.6-1).



Dimensions



Model	Port size	A	B
AM150	1/8, 1/4, 3/8	239	80
AM250	1/4, 3/8	252	80
	1/2	258	
AM350	3/8, 1/2	284	80
	3/4	290	
AM450	1/2, 3/4	305	80
	1	312	
AM550	3/4, 1	339	80
AM650	1, 1 1/2	391	80
AM850	1 1/2, 2	540.5	80


② With IN-OUT Flange

For easier flange piping.


Specification

Applicable model	AM450 to AM850
------------------	----------------

How to Order *Refer to "How to Order" for standard type (p.4.6-1).



Dimensions



Model	Connection	A	B
AM450	3/4B/FF/10K	240	256
AM550	1B/FF/10K	260	300
AM650	1 1/2 B/FF/10K	300	349
AM850	2B/FF/10K	380	496.5

HA ☐

AT ☐

ID ☐

AMG ☐

AFF ☐

AM ☐

Related
products



Precautions/With Differential Pressure Gauge(GD40-20-01)

Be sure to read before handling. Refer to p.0-26 and 0-27 for Safety Instructions and common precautions on the products mentioned in this catalog, and refer to p.4.0-5 to 4.0-7 for precautions on every series.

Please refer to p.4.5-7 for with pressure differential gauge (GD40-2-01).