
Piping Module Series KB



Suitable for centralized distribution of supply air!

Easy distribution utilizing One-touch fittings!

One-touch fitting installation without the use of tools.

Locking system makes the use of tools unnecessary and piping more efficient.

Air output direction possible through 360°.

Universal construction allows for changes in air output direction after connections are completed.



Applicable Tubing

Tube materialNylon, Soft nylon, PolyurethaneTube O.D.Ø4, Ø6, Ø8, Ø10, Ø12, Ø16

Applicable Thread Size

 Male thread
 R(PT) 1/₆, R(PT) 1/₄, R(PT) 3/₈, R(PT) 1/₂

 Female thread
 M5 X 0.8, M6 X 1, Rc(PT) 1/₈, Rc(PT) 1/₄, Rc(PT) 3/₈, Rc(PT) 1/₂

Specifications

fluid	Air			
ating pressure	1.0MPa			
ing vacuum pressure	-100kPa			
ssure	3.0MPa			
nd fluid temperature	–5 to 60°C (No freezing)			
Thread portion	JIS B 0203 (Taper pipe thread)			
Thread portion	JIS B 0209, Class 2 (Metric coarse thread)			
Nut	JIS B 0211, Class 2 (Metric fine thread)			
Male thread)	With sealant (standard)			
ee specification	All brass parts electroless nickel plated (standard			
	ating pressure ing vacuum pressure ssure nd fluid temperature Thread portion Nut Male thread)			


Component Materials

Body	C3604BD, PBT, POM
Stud	POM
Lock ring	POM
Spring	SUS304WPB
Spring guide	POM
Stopper	POM
Thread	C3604BD
Guide	SUS304, C3604BD, POM
Collet, Release button	POM
Packing, O ring	NBR
Chuck	Stainless steel (SUS304)


M□ H□ D□ MS


K□

How to Order



Combination Examples






A Precautions

Be sure to read before handling. Refer to p.0-26 and 0-27 for Safety Instructions and common precautions on the products mentioned in this catalog, and refer to p.2.0-7 and 2.0-8 for more detailed precautions of every series.

How to Install

A Caution

- ①Insert each piping module by matching the arrows on the lock ring and the body of the other module. Insert together. If it becomes difficult to match both modules, rotate modules to left and right while pushing together. When a match is not done, piping material will eject under pressure.
 - *Refer to piping module insertion and removal diagram.
 - (To secure rigidity, it is slightly stiff.)



②Confirm insertion by turning modules to right and left or pulling on them. But do not touch the lock ring in the process.




How to Remove

▲ Caution

①Exhaust the pressure in pipe before removing. If lock is released under pressure, piping material will eject. Turn the lock ring 90°clockwise (in the direction of the arrow). This will cancel out the affects of the lock ring. You need not hold lock ring in place. Lock ring will hold automatically in this position



②Remove the modules by pulling apart. Do not touch the lock ring. After removal, the lock ring will return to normal position automatically because of a return spring.




▲ Caution

- ①If unit is longer than 5 stations, please use brackets to prevent deflection and/or bending of unit.
- ②Each type of module materials is capable of being piped with all other materials.
- 3)When attaching female connector union and female connector elbow union, use the body's hexagon surface and tighten threads with a suitable wrench. Use the root nearest the thread when tightening with a wrench.


Piping Module-Insertion and Removal Structual Drawing

Piping Module-Male Side


Piping Module-Female Side




①Match arrows together and insert piping module male side into female side.



②By inserting the lock ring, the lock portion touches female side guide portion and falls into the direction shown with the arrow.



③By pushing tighter, lock portion goes over female side guide portion and snaps into window slot portion. Male side protruding portion snaps into female side groove portion. This performs the function of a detent.





Male module inserted fully into position.

④To remove, rotate lock ring 90° to release lock portion from female side window slot, then the lock is released. Removal is complete.



Elbow module: KBV






Elbow socket module: KBV



ΠΠ


Part No.	T Connecting thread	H (Hex.)	D1	D2	D3	L1	L2	Lз	L4	А	Weight (g)
KBV1-M5	M5 X 0.8			13.6	10.0	25.0	22.0	10.1	13.0	40 F	12.4
KBV1-M6	M6 X 1	12	12.8		16.8	25.0	33.0	10.4	13.0	19.5	11.6
KBV2-M5	M5 X 0.8	12	-	17.6	21.0	26.0 3		10.1	15.5	22.5	14.8
KBV2-M6	M6 X 1						36.0				14.0
KBV2-R1	Rc(PT) 1/8	14	15.2			29.5					15.3
KBV3-R1	RU(FI) 98	14	15.2	25.2	28.6	30.5	42.6	11.4	20.5	27.0	22.0
KBV3-R2	Rc(PT)1/4	19	18.5	25.2	20.0	32.0	42.0	11.4	19.5		27.0
KBV4-R2	πυ(Γ1)/4	(PT) 1/4 22	20.9	27.0	30.4	36.5	41.4	12.2	18.0	25.0	40.6
KBV4-R3	Rc(PT)3/8	22	20.9	27.0	50.4	43.0	41.4	12.2	10.0	25.0	44.7



Branch elbow module: KBZ



Part No.	Tube O.D.	D1	D2	D3	L1	L2	Lз	L4	A	М	Р	Weig (g)
KBZ1-04	4	10.4	10.0	10.0	22.0	22.0	10.4	10.0	10 5	16.0	10.4	5.8
KBZ1-06	6	12.8	13.0	16.8	24.0	33.0	10.4	13.0	19.5	17.0	12.8	7.1
KBZ2-08	8	15.2	17.6	21.0	28.5	36.0	10.1	15.5	22.5	18.5	15.2	11.
KBZ3-10	10	18.5	25.2	28.6	31.5	126	11.4	10.5	27.0	21.0	18.5	24.
KBZ3-12	10	20.9	25.2	20.0	34.0	42.0	11.4	19.5	27.0	22.0	20.0	27.
KBZ4-12	12	20.9	27.0	30.4	35.0	41.4	12.2	18.0	25.0	22.0	20.9	28.






Series **KB**



Female connector union: KBH



Part No.	Connecting thread	н (Hex.)	D	L	Α*	(g)
KBH1-R1S	R(PT) 1/8	14	13.6	27.0	20.0	13.4
KBH2-R1S	R(PT) 1/8	17	17.6	29.0	21.5	19.2
KBH2-R2S	R(PT) 1/4			32.0	22.5	23.3
KBH2-R3S	R(PT) 3/8			27.5	17.5	22.5
KBH3-R2S	R(PT) ¹ /4	19		35.5	25.4	26.5
KBH3-R3S	R(PT) 3/8	15	25.2	31.0	20.5	23.2
KBH3-R4S	R(PT) 1/2	22		31.0	19.0	41.5
KBH4-R3S	R(PT) 3⁄8	24	27.0	35.5	24.5	44.5
KBH4-R4S	R(PT) 1/2	24	27.0	31.5	19.0	36.5




M/alala

* Reference dimensions after R(PT) thread installation.

Female connector elbow union: KBL



Part No.	T Connecting thread	H (Hex.)	D	L1	L2	A1*	A2	Weight (g)
KBL1-R1S	R(PT)1/8	14	13.6	18	38.0	27.0	15.0	14.8
KBL2-R1S	K(FI) 1/8				43.5	30.5		23.2
KBL2-R2S	R(PT)1⁄4	17	17.6	19	46.5	31.5	15.5	27.3
KBL2-R3S	R(PT) ³ /8				42.0	26.5		26.5
KBL3-R2S	R(PT)1/4	19			56.0	37.5		32.6
KBL3-R3S	R(PT) 3/8	19	25.2	22	51.5	32.5	18.0	29.3
KBL3-R4S	R(PT) 1/2	22			51.5	31.0		47.6
KBL4-R3S	R(PT) 3/8	24	27.0	24	61.5	41.5	19.5	57.6
KBL4-R4S	R(PT)1/2	24	21.0	24	57.5	36.0	19.5	48.8




* Reference dimensions after R(PT) thread installation.

Bulkhead female connector: KBE




Part No.	Tube O.D.	T Connectiong thread	H1 (Hex.)	H2 (Hex.)	D	L	A1	A2	М	Weight (g)
KBE1-04	4	M12 X 1	14	14	13.6	34.5	15.0	31.5	16.0	17.9
KBE1-06	6	M14 X 1	17	17	13.0	35.5	15.5	32.0	17.0	27.0
KBE2-06	0	W14 A 1			17.6	37.5	17.0	33.5	17.0	26.0
KBE2-08	8	M16 X 1		19		39.0	15.5	35.5	18.5	29.5
KBE2-10	10	M20 X 1		24		41.5	15.5	38.0	21.0	57.5
KBE3-08	8	M16 X 1	22	19		43.5	19.5	39.5	18.5	51.6
KBE3-10	10	M20 X 1		24	25.2	45.0	18.5	41.0	21.0	63.0
KBE3-12	12	M22 X 1	24	27		46.0	10.0	42.0	22.0	83.4
KBE4-12	12		24	27	27.0	44.0	18.0	41.5	22.0	66.6





Male connector socket: KBB


Part No.	T Connecting thread	H (Hex.)	D	L1	L2	А	Weight (g)	
KBB1-M5	M5 X 0.8	8	16.8	29.5	11.5	19.0	6.0	
KBB2-M6	M6 X 1	10	21.0	23.0	5.0	12.5	6.3	
KBB3-R1	Rc(PT)1/8	14	28.6	27.5	6.5	16.0	11.4	
KBB4-R2	Rc(PT) ¹ /4	19	30.4	31.5	9.5	19.5	24.1	




Female connector socket: KBS



Part No.	T Connecting thread	H (Hex.)	D	L1	L2	А	Weight (g)
KBS1-R1	Rc(PT) 1/8	14	13.6	28.0	11.0	25.0	17.8
KBS2-R2	Rc(PT)1/4	17	17.6	33.5	14.0	30.0	28.5
KBS3-R3	Rc(PT)3/8	19	25.2	38.5	17.0	34.5	33.8
KBS4-R4	Rc(PT)1/2	24	27.0	39.0	20.0	35.0	57.1






Series **KB**




Nipple: KBN

<u>_</u>	

Part No.	D	L	А	Weight (g)
KBN1	16.8	35.0	14.0	2.9
KBN2	21.0	35.0	15.0	4.6
KBN3	28.6	39.0	16.5	7.2
KBN4	30.4	41.5	17.0	10.2




Elbow different diameter female connector module: KBD




Different diameter module: KBR

Part No.	D	L A		Weight (g)
KBR2-1	21.0	21.5	8.0	2.8
KBR3-2	28.6	25.0	10.0	4.3
KBR4-3	30.4	30.5	14.0	8.8





	Part No.	H (Hex.)	D	L1	L2	А	Weight (g)
	KBP1	8	16.8	29.5	11.5	19.0	5.6
	KBP2	10	21.0	23.0		12.5	6.8
	KBP3	14	28.6	25.5	5.0	14.0	13.4
	KBP4	19	30.4	27.0		15.0	24.0



Cap: KBC



	Part No.	H (Hex.)	D	L1	L2	А	Weight (g)	øD
r ²	KBC1	14	13.6	30.0	13.0	26.5	23.4	
	KBC2	17	17.6	32.5	13.0	28.5	37.0	
	KBC3	19	25.2	35.5	14.0	31.5	46.7	
	KBC4	24	27.0	34.0	15.0	29.5	74.4	ſ <u></u> ₽₽₽
								Bracket mounting thread M6 X 1 X 8ℓ



Bracket: KBX



Part No.	А	Applicable model	Weight (g)
KBX6	7	KBP, KBC	27.5
KBX12	13	KBE1-04	26.1
KBX14	15	KBE1-06, KBE2-06	25.4
KBX16	17	KBE2-08, KBE3-08	24.4
KBX20	21	KBE2-10, KBE3-10	22.6
KBX22	23	KBE3-12, KBE4-12	21.6

* In case of KBX6, use the enclosed mounting screws designed for KBP (plug) and KBC (cap). Screw size: Cross recessed round head screw (M6 X 1 X 8/) Screw color: Black

