
## **Flow Sensor**



## For suction verification of very small workpieces

The flow sensor enables more reliable suction verification than a pressure sensor.



## Repeatability: ±2% F.S. Withstand pressure: 500 kPa

## Response speed: 5 ms or less Grease-free


Model		Range	Rated flow range [L/min]							
		nange	-3.0	-1.0	-0.5	0	0.1	0.5	1.0	3.0
(	lew 505-X502	0.1 L/min								
PFMV	505	0.5 L/min								
	510	1.0 L/min								
	530	3.0 L/min							i	
	505F	±0.5 L/min				i 	i 			
	510F	±1.0 L/min								
	530F	±3.0 L/min								





## **Compact and Lightweight**

The taper-shaped flow passage in front of the sensor chip enables stable sensing.



## Space-saving piping


The product is mountable in locations with limited space as piping space is not required.



## With a bend-resistant cable




## Mounting



 Single-side bracket mounting

Manifold mounting



 Both-side bracket mounting

## **Related Equipment** p. 12


**Compact Suction Filter** Filtration: 3 µm (Nominal) Applicable tubing (O.D./I.D.): ø6/ø4




IN: ø6 barb fitting OUT: M5

## **Applications**

- For suction verification of very small workpieces
- · Suction of small components can be verified.
- · Highly applicable to small nozzles.
- · Nozzle clogging and crushing can be detected.



• For leakage testing of 0.1 L/min or less · Pin holes in molded parts can be easily detected.



}SMC

# 3-Screen Display Digital Flow Monitor PFGV301 Series 13 Allows for the monitoring of remote lines

## Visualization of settings




## Easy screen switching

It is possible to change the settings	Main screen red value (Current sensor output voltage or flow value)	The sub screen can be switched by pressing the up/down buttons.
while checking the measured value. Sub screen/	Sub screen/	Set value (Threshold value)       Hysteresis value       Bottom value       Peak value         P       1       <
Left side Label (Display item)	Right side Set value (Threshold value)	

## Simple 3-step setting

When the S button is pressed and the set value  $(P_1)$  is being displayed, the set value (threshold value) can be set. When the S button is pressed and the hysteresis  $(H_1)$  is being displayed, the hysteresis value can be set.



SMC

With a snap shot function for set value reading

## **NPN/PNP** switch function

The number of stock items can be reduced.

Voltage output

Current output



Switchable

Fixed



## Input range selection (for Pressure/Flow rate)

Display Voltage input 1 V The displayed value to the sensor input can be set as required. (Voltage input: 1 to 5 V) Pressure switch/Flow switch can be displayed.

5 V

A is displayed for 1 V. B is displayed for 5 V. The range can be set as required.

### Pressure Sensor for General Fluids/PSE570

1   		Α	В
	<b>PSE570</b>	0	1000
	<b>PSE573</b>	-100	100
	PSE574	0	500
V	Set A and B	to the valu	les show

in the table above.

6 mm shorter

## **Convenient functions**

1 to 5 V

0 to 10 V

4 to 20 mA

Copy function
The set values of
the monitor can

also available.

the monitor can be copied.



### Security code

The key locking function keeps unauthorized persons from tampering with the settings.

### External input function

The accumulated value, peak value, and bottom value can be reset remotely.

## Functions

- Output operation
- Simple setting mode
- Display color
- Delay time setting
- Digital filter setting
- FUNC output switching function
- Selectable analog output function

\*1 During normal operation \*2 In power saving mode

- External input function
- Auto-shift function
- Forced output function
- Peak/Bottom value display
- Setting of a security code
- Key-lock function
- Reset to the default settings
- Display with zero cut-off setting
- Auto-preset function
- Selection of the display on the sub screen
- Analog output free range function
- Error display function

25 mm

 $\square$ 

PFGV301

PFM300


Copy function

31 mm

• Selection of power saving mode

## Mounting

Bracket configuration allows for mounting in four orientations.



## Compact: Max. 6 mm shorter • Lightweight: Max. 5 g lighter (30 g $\rightarrow$ 25 g)

10 units

Copy destination Power saving function Power consumption is reduced by turning off the monitor. Current consumption\*1 Reduction rate\*2 25 mA or less Approx. 50% reduction

## Analog output of 0 to 10 V is (1000)-Display Voltage input 1 V **Compact & Lightweight**

## CONTENTS

## Flow Sensor *PFMV5 Series* 3-Screen Display Digital Flow Monitor *PFGV301 Series*

Flow Sensor PFMV5 Series	
How to Order	p. 6
Specifications	p. 7
Internal Circuits and Wiring Examples	p. 7
Recommended Pneumatic Circuits	p. 8
Recommended Fittings	p. 8
Wetted Parts Construction	р. 8
Detection Principle	p. 8
Analog Output (Non-linear output)	p. 9
Pressure Loss	p. 10
Dimensions	p. 11
Related Equipment Compact Suction Filter	p. 12
3-Screen Display Digital Flow Monitor PEGV301 Series	

P. 5



,,,,,,, _	-
How to Order	p. 13
Specifications	p. 14
Display Accuracy and Repeatability when Combined	
with PFMV5. (Calculation Example)	p. 15
Settable Range and Voltage Input Range	p. 16
Internal Circuits and Wiring Examples	p. 17
Dimensions	p. 18
Made to Order	p. 21
Safety Instructions	Back cover




**PFMV5** 


## **PFMV** Series **Model Selection**

## Nozzle Diameter and Flow Rate Characteristics (Approximate values)

Use the following graphs as a reference to select sensor measuring range.




### Nozzle Diameter - Flow Rate Characteristics (Vacuum)




Selecting conditions:

Nozzle diameter: Ø0.3 P1: 0 [kPa] P2: -60 [kPa] The flow rate will be 0.7 to 0.8 [L/min] based on the graph.  $\rightarrow$  Select the PFMV510-1.






P2: Nozzle internal pressure



### Example (Positive pressure)


Selecting conditions:

- Nozzle diameter: ø0.3 P1: 0 [kPa] P2: 20 [kPa]
- The flow rate will be 0.7 to 0.8 [L/min] based on the graph.  $\rightarrow$  Select the PFMV510-1.



\* Since the calculated value may not meet the approximate value due to leakage and pressure loss in the piping system, please check the result by using actual equipment.


## Flow Sensor (E CA CAS Series RoHS



## **Option/Part Nos.**

If a single option or manifold mounting are required, order sensors with the part numbers below separately.

Part no. Stations		Note
ZS-36-A1	For 1 station (for single unit)	2 L-type brackets, 2 mounting screws M3 x 15L
ZS-36-A2	For 2 stations	2 L-type brackets, 2 mounting screws M3 x 25L
ZS-36-A3	For 3 stations	2 L-type brackets, 2 mounting screws M3 x 35L
ZS-36-A4	For 4 stations	2 L-type brackets, 2 mounting screws M3 x 45L
ZS-36-A5	For 5 stations	2 L-type brackets, 2 mounting screws M3 x 55L



•

## **PFMV5** Series

## **Specifications**

For flow switch precautions and specific product precautions, refer to the "Operation Manual" on the SMC website.


Model		PFMV505-X502	PFMV505	PFMV510	PFMV530	PFMV505F	PFMV510F	PFMV530F
Applicable fluid		Dry air, N <sub>2</sub>						
Applicable	e fluid	(JIS B 8392-1 1.1.2 to 1.6.2: 2003, ISO 8573-1 1.1.2 to 1.6.2)						
*1 Rated flow range (Flow rate range)		0 to 0.1 L/min	0 to 0.5 L/min	0 to 1 L/min	0 to 3 L/min	-0.5 to 0.5 L/min*2	-1 to 1 L/min* <sup>2</sup>	-3 to 3 L/min*2
Accuracy					±5% F.S.* <sup>3</sup>			
Repeatabil	lity				±2 F.S.*3			
Pressure o (0 kPa refe	characteristics erence <sup>*4</sup> )				F.S. (0 to 300 I F.S. (–70 to 0 I	,		
Temperatu (25°C refer	ure characteristics rence)				5 F.S. (15 to 35 5 F.S. (0 to 50°	,		
Rated pres	ssure range*5			_	70 kPa to 300 l	кРа		
Operating	pressure range*6			-1	00 kPa to 400 l	кРа		
Proof pres	sure	500 kPa						
Analog ou	tput (Non-linear output)	Voltage output: 1 to 5 V, Output impedance: Approx. 1 k $\Omega$						
Response	time	5 ms or less (90% response)						
Power sup	oply voltage	12 to 24 VDC $\pm$ 10% (With polarity protection)						
Current co	onsumption	16 mA or less						
	Enclosure	IP40						
	Fluid temperature	0 to 50°C (No freezing and condensation)						
	Operating temperature range	0 to 50°C (No freezing and condensation)						
	Stored temperature range	-10 to 60°C (No freezing and condensation)						
Environ-	Operating humidity range	35 to 85% R.H. (No condensation)						
ment	Stored humidity range	35 to 85% R.H. (No condensation)						
	Withstand voltage	1000 VAC for 1 minute between terminals and housing						
	Insulation resistance	50 M $\Omega$ or more (500 VDC measured via megohmmeter) between terminals and housing						
	Port size		M5	x 0.8 (Tightenii	ng torque: Appr	ox. 0.5 to 1.0 N	l∙m)	
	Wetted parts material		PPS, Si, A	u, Stainless ste	el 316, C3604	(Electroless nic	kel plating)	
Standards		CE/UKCA marking, UL (CSA)						
Lead wire		Vinyl cabtire cord, 3 cores ø2.6, 0.15 mm <sup>2</sup> , 2 m						
Weight		10 g (Excluding lead wire)						

\*1 The flow rate given in the specifications is the value under standard conditions.
\*2 Analog output indicates 3 V when the flow rate is 0. When the flow direction is from IN to OUT, the output is changed to 5 V, and when it's from OUT to IN, the output is changed to 1 V.
\*3 The unit % F.S. is based on the full scale of analog 4 V (1-5 V).
\*4 0 kPa indicates the atmospheric release.
\*5 Pressure range that satisfies the product specifications
\*6 Applicable pressure range

Applicable pressure range
 For wiring, refer to the "Operation Manual" on the SMC website.
 Products with tiny scratches, marks, or display color or brightness variations which do not affect the performance of the product are verified as conforming products.

## Internal Circuits and Wiring Examples

### -1 Analog voltage output



### Lead Wire Specifications

Conductor	Nominal cross section area	AWG26
Conductor	External diameter	0.58 mm
Insulator	External diameter	0.88 mm
Insulator	Colors	Brown, Blue, Black
Sheath	Material	Oil-resistant/Heat-resistant PVC
Finished ex	ternal diameter	2.6

Connection type


ZFC050-AU6X68

IN: ø6 barb fitting OUT: M5

IN/OUT: M5

Element (10 pcs.)

## **Recommended Pneumatic Circuits**



## Recommended Fittings


### **One-touch Fitting/KQ2 Series**

Туре	Tubing O.D. [mm]	Port size	Model
Male connector	Λ	M5 x 0.8	KQ2H04-M5A
Male elbow	4	0.0 X CIVI	KQ2L04-M5A

### **Miniature Fitting/M Series**

Туре	Tubing O.D. [mm]	Port size	Model
Barb fitting for nylon tube	4	M5 x 0.8	M-5AN-4
Barb mung for hyfori tube	6	O.U X CIVI	M-5AN-6

## Wetted Parts Construction



### **Component Parts**

Compact Suction Filter p. 12

Part no.

ZFC050-M5X68

ZFC-EL013-A

**ZFC050-AU6X68** 

ZFC050-M5X68

No.	Description	Material				
1	Fitting for piping	C3604 (Electroless nickel plating)				
2	Mesh holding screw					
3	Mesh	Stainless steel 316				
4	Body	PPS				
5	Print circuit board	GE4F				
6	Sensor chip	Si, Au				
_	concor omp	el, / la				


## **Detection Principle**

This MEMS sensor chip consists of upstream temperature measuring sensor (Ru) and downstream temperature measuring sensor (Rd), which are placed symmetrically from the center of a platinum thin film coated heater (Rh) mounted on a membrane, and an ambient temperature sensor (Ra) for measuring gas temperature.

The principle is shown as the diagram on the right. (a) When the gas is static, the temperature distribution of heated gas centered around Rh is uniform, and Ru and Rd have the same resistance. (b) When the gas flows from the left side, it upsets the balance of the temperature distribution of heated gas, and the resistance of Rd becomes greater than that of Ru.

The difference in resistance between Ru and Rd is proportional to the flow velocity, so measurement and analysis of the resistance can show the flow direction and velocity of the gas.

Ra is used to compensate the gas and/or ambient temperature.



# **PFGV301**


**PFMV5** 


(b) The gas flows from the	left side.

## **PFMV5** Series


## Analog Output (Non-linear output)

## PFMV505-1-X502







### PFMV530-1




### PFMV530F-1








# PFMV510-1



### PFMV510F-1




\* Use these graphs as a reference for calculating the flow rate value.


\* Due to slight differences between individual products, the values may not match the values shown in the graphs. Confirm with the actual product before use.




## Pressure Loss (Reference Data)

## PFMV505(F)-1(-X502)











## **PFMV5** Series


Dimensions













The dimensions show the PFMV5□□-1. The PFMV5□□F-1 has the same dimensions.

## *ZFC050* Related Equipment

### **Compact Suction Filter**



### Example of mounting to the flow sensor PFMV series (For suction verification)



### Specifications

Filtration degree	3 μm (Nominal)
Fluid	Air
Operating pressure range	–100 to 600 kPa
Ambient temperature	0 to 60°C (No freezing)
Applicable tubing material	Soft nylon, Polyurethane
Applicable tubing O.D./I.D.	ø6/ø4

## Replacement element part no....ZFC-EL013-A


## **▲**Caution

- 1. To screw in OUT side port (M5 male thread), tighten by hand before giving it an additional 1/4 turn with a tightening tool.
- 2. When replacing the element, remove the IN side body using the hexagon surface on the IN side, then replace the element. After replacing the element, tighten the IN side body with the tightening torque 0.5 to 0.7 N·m.
- 3. As a rule, replace the element when the pressure drops by 20  $\,\rm kPa.$
- 4. The response time of the single flow sensor is 5 msec. However, take great care since the response may be delayed depending on the element clogged conditions.

**SMC** 


**PFMV5** 

# 3-Screen Display Digital Flow Monitor **PFGV301 Series** RoHS



SMC

ZS-46-D



## 3-Screen Display Digital Flow Monitor **PFGV301** Series

## **Specifications**

For flow switch precautions and specific product precautions, refer to the "Operation Manual" on the SMC website.

	Model				P	FGV301 serie	es				
Applicable flow	sensor model		PFMV505-X502	PFMV505	PFMV510	PFMV530	PFMV505F	PFMV510F	PFMV530F		
	Rated voltage r	ange	1.00 to 5.00 V								
Voltage	Set voltage ran	ge				0.80 to 5.20 V					
	Smallest settab	le increment	0.01 V								
	Rated flow rang	ge <sup>*1</sup>	0 to 0.1 L/min	0 to 0.5 L/min	0 to 1 L/min	0 to 3 L/min	–0.5 to 0.5 L/min	–1 to 1 L/min	–3 to 3 L/min		
Flow	Set point range	•	–0.005 to 0.105 L/min	–0.025 to 0.525 L/min	–0.05 to 1.05 L/min	–0.15 to 3.15 L/min	–0.525 to 0.525 L/min	–1.05 to 1.05 L/min	-3.15 to 3.15 L/min		
	Smallest settab	le increment	0.001	L/min	0.01	L/min	0.001 L/min	0.01	L/min		
	Power supply v	oltage	12 to 24 VDC ±10% or less								
Electrical											
	Protection		Polarity protection								
	Display accura	су	±0.5% F.S. ± Min. display unit (Ambient temperature at 25°C)								
Accuracy*2	Analog output	accuracy	±0.5% F.S. (Ambient temperature at 25°C)								
Accuracy	Repeatability			±0.1% F.	S. ± Min. displa	y unit, Analog	output: 0.3% F.	S. or less			
	Temperature cha	racteristics		±0.5% F	S. (Ambient te	emperature: 0 to	o 50°C, 25°C st	andard)			
	Output type				Select from NPN	or PNP open	collector output	t			
	Output mode		Select	t from Hysteres	is, Window com	nparator, Error	output, or Switc	h output OFF n	nodes.		
	Switch operation	on			Select from	Normal or Reve	ersed output.				
	Max. load curre	ent				80 mA					
	Max. applied vo	oltage				0 V (NPN outpu					
Switch output	Internal voltage	•	NPN output:	1 V or less (at lo	bad current of 8	0 mA), PNP ou	tput: 1.5 V or le	ss (at load curr	ent of 80 mA		
	Response time	*3				3 ms or less					
	Delay time*3		Select from 0, 0.05 to 0.10 s (increments of 0.01 s), 0.1 to 1.0 s (increments of 0.1 s), 1 to 10 s (increments of 1 s), 20 s, 30 s, 40 s, 50 s, or 60 s.								
	Hysteresis*4		Variable from 0								
	Protection		Short circuit protection								
	Output type		Voltage output: 1 to 5 V (0 to 10 V can be selected only when the power supply voltage is 24 VDC)*6, Current output: 4 to 20 mA								
Analog output*5		Voltage output		-	Outp	ut impedance:	1 kΩ				
	Impedance	Current output	Max. load impe	dance: 300 $\Omega$ (a	t power supply	voltage of 12 VD	DC), 600 Ω (at po	ower supply volt	age of 24 VDC		
	Response time	*2				50 ms or less					
	Peak/Bottom	Input type		Input voltag	ge: 0.4 V or less	(Reed or Solid	d state) for 30 m	is or longer			
External input*7	value reset	Input mode	Peak/Bottom value reset								
	Auto-shift	Input type		Input volta	ge: 0.4 V or les	s (Reed or Soli	d state) for 5 m	s or longer			
	input	Input mode									
	Input type			Vc	ltage input: 1 to	5 VDC (Input i	mpedance: 1 M	Ω)			
Sensor input	Connection me	thod				onnector (e-CO	/				
	Protection					protection (Up	,				
	Display mode					ntaneous flow d					
	Unit <sup>*8</sup>		L/min, cfm (ft <sup>3</sup> /h)								
		Voltage				0.80 to 5.20 V					
	Display range	Flow	–0.005 to 0.105 L/min	–0.025 to 0.525 L/min	–0.05 to 1.05 L/min	–0.15 to 3.15 L/min	–0.525 to 0.525 L/min	–1.05 to 1.05 L/min	-3.15 to 3.15 L/min		
Display	Min. display	Voltage		0.01 V							
	unit	Flow	0.001 L/min 0.01 L/min 0.001 L/min 0.01 L/min								
	Display type	-				LCD					
	Number of disp	olays	3-screen display (Main screen, Sub screen)								
	Display color		1) Main screen: Red/Green, 2) Sub screen: Orange								
	Number of disp	olay digits	1) Main screen: 5 digits (7 segments), 2) Sub screen: 9 digits (7 segments)								
	Indicator LED		LED ON when switch output is ON. OUT1/2: Orange								
Digital filter*9			Select from 0, 0.05 to 0.10 s (increments of 0.01 s), 0.1 to 1.0 s (increments of 0.1 s), 1 to 10 s (increments of 1 s), 20 s, or 30 s.								
	Enclosure		IP40								
Environmental	Withstand volta	<u> </u>	1000 VAC for 1 min between terminals and housing								
	Insulation resis	stance	50 M $\Omega$ or more (500 VDC measured via megohmmeter) between terminals and housing								
resistance	Operating temper	rature range	Operating: 0 to 50°C, Stored: -10 to 60°C (No condensation or freezing)								
resistance				Operating/Stored: 35 to 85% RH (No condensation or freezing)							
resistance	Operating hum	idity range		Operatin	g/Stored: 35 to	85% RH (No c	ondensation or	treezing)			
	Operating hum	idity range		Operatin	7	85% RH (No c E/UKCA markir		freezing)			
resistance Standards Weight	Operating hum Body	idity range		· · ·	C	E/UKCA markir					

\*1 Rated flow range of the applicable flow sensor. The flow rate stated in the specifications is for under normal conditions (20°C, 101.3 kPa (absolute pressure), 65% R.H.).
\*2 The accuracy is with respect to the voltage display. When the flow rate

\*5 Setting is only possible for models with analog output.
\*6 When selecting 0 to 10 V, refer to the analog output graph for the allowable load current. Setting is only possible for models with external input. \*7

display function is selected, the repeatability and display accuracy should be exactly like the graph on page 15.

\*3 Value without digital filter (at 0 ms)

\*4 If the flow fluctuates around the set value, be sure to keep a sufficient margin. Otherwise, chattering will occur.

\*8 Setting is only possible for models with the unit selection function. \*9 The response time indicates when the set value is 90% in relation to the step input.

\* Products with tiny scratches, marks, or display color or brightness variations which do not affect the performance of the product are verified as conforming products.




**PFGV301** 

**PFMV5** 

## **PFGV301** Series

## Display Accuracy and Repeatability when Combined with PFMV5. (Calculation Example)



When the flow rate display function for the PFGV301 series is selected, calculate the repeatability from the analog output characteristics graph (page 9).

### Example) For PFMV530-1 (0 to 0.3 L/min)

- ① When the actual flow rate is 0.3 L/min, the PFMV530-1 outputs approximately 2.5 V of analog voltage (Arrow ① in the graph on the left).
- (2) The PFMV5 series has a repeatability of  $\pm 2\%$  F.S. ( $\pm 80$  mV) (Arrow (2) in the graph on the left).
- ③ When this accuracy is converted to a flow rate, it becomes approximately ±3% F.S. (±0.09 L/min), and this width becomes the repeatability when the flow rate is displayed (arrow ③, and the width of △ Q, in the graph on the left).

The flow rate display accuracy can be also calculated from the PFMV5 series accuracy ( $\pm$ 5% F.S.).

## Settable Range and Voltage Input Range

The settable rate range is the range that can be set in the switch.

The inputtable range is the range that satisfies the switch specifications (accuracy, linearity, etc.).

It is possible to set a value outside of the inputtable range if it is within the settable range, however, the specification is not guaranteed.

Item	Input vol	tage
	0 0.8 V	5.10 V 5.20 V
Voltage input range		
Display voltage range		ННН
Set voltage range		

The settable rate range is the flow range that can be set in the switch.

The rated flow range is the flow rate range that satisfies the switch specifications (accuracy, linearity, etc.).

It is possible to set a value outside of the rated flow range if it is within the settable range, however, the specification is not guaranteed.

Sensor		Flow rate range									
Sensor	–3 L	/min –1 L	/min _0.5 L/r	min 0	0.1 L	_/min 0.5 l	_/min	1 L/m	nin	3 L/r	nin
PFMV505-X502				0 –0.005 L/min –0.005 L/min		0.1 L/mi 0.105 L 0.105 L	/min				
PFMV505				0 –0.025 L/min –0.025 L/min		     	0.5 L/min 0.525 L/min 0.525 L/min				
PFMV510				0  0.05 L/min 0.05 L/min		, ,	, ,	1	L/min 1.05 L/min 1.05 L/min		
PFMV530				0   -0.15 L/min -0.15 L/min							3 L/min 3.15 L/min 3.15 L/min
PFMV505F			–0.5 L/min –0.525 L/min –0.525 L/min				0.5 L/min 0.525 L/min 0.525 L/min				
PFMV510F		–1 L/min –1.05 L/min –1.05 L/min						1	L/min 1.05 L/min 1.05 L/min		
PFMV530F	-3 L/min -3.15 L/min -3.15 L/min										3 L/min 3.15 L/min 3.15 L/min

The values shown on the graph are the displayed flow rate range and set flow rate range when PFMV5 series and PFGV301 series are connected.

Rated flow range

ĺ


**PFMV5** 


**PFGV301** 

Displayable flow range Settable range


## **PFGV301** Series

## Internal Circuits and Wiring Examples






## -RT: NPN (2 outputs) + Analog voltage output -SV: NPN (2 outputs) + Analog current output




## -RT: NPN (2 outputs) + External input -SV: NPN (2 outputs) + External input




### -XY -RT -SV


## PNP (2 outputs) + Copy function



## -RT: PNP (2 outputs) + Analog voltage output -SV: PNP (2 outputs) + Analog current output




## -RT: PNP (2 outputs) + External input -SV: PNP (2 outputs) + External input



## 3-Screen Display Digital Flow Monitor **PFGV301** Series


## Dimensions




## **PFGV301** Series


## **Dimensions**

Panel mount adapter (Part no.: ZS-46-B)




### Panel mount adapter + Front protection cover (Part no.: ZS-46-D)






## Power supply/output connection lead wire (Part no.: ZS-46-5L)



## **Cable Specifications**

Conducto	or cross section	0.15 mm <sup>2</sup> (AWG26)	
Inculator	Outside diameter	1.0 mm	
Insulator	Color	Brown, Blue, Black, White, Gray (5-core)	
Sheath	Finished outside diameter	ø3.5	
19		SM SM	


## Sensor connector (Part no.: ZS-28-CA)




## 3-Screen Display Digital Flow Monitor **PFGV301** Series

## Dimensions


## Panel fitting dimensions




Multiple (2 pcs. or more) secure mounting <Horizontal>



Panel mount example <Horizontal>




<Vertical>



Panel mount example <Vertical>

**SMC** 



**PFMV5** 

**PFGV301** 

## **PFGV301** Series **Made to Order**



Please contact SMC for detailed dimensions, specifications, and delivery times.


## **1** Conversion Cable for the PFMV30□ Lead Wire with Connector

The conversion cable allows for connection between the existing PFMV30 lead wire with connector and the PFGV301.

### $\textbf{PFMV30}\square \rightarrow \textbf{PFGV301} + \textbf{Conversion Cable Correspondence Table}$

Existing flow monitor model	Output specification	①Flow monitor part no.	② Conversion cable part no.
PFMV300-000-00	NPN 2 outputs + 1–5 V outputs	PFGV301-RT-D-DDD	
PFMV301-000-00	NPN 2 outputs + 4–20 mA output	PFGV301-SV-D-DDD	
PFMV302-000-00	NPN 2 outputs + auto-shift input	PFGV301-XY-🗆-🗆🗆	ZS-28-A-X538
PFMV303-000-00	PNP 2 outputs + 1–5 V outputs	PFGV301-RT-D-DDD	Z3-20-A-A330
PFMV304-000-00	PNP 2 outputs + 4–20 mA output	PFGV301-SV-D-DDD	
PFMV305-000-00	PNP 2 outputs + auto-shift input	PFGV301-XY-□-□□□□	

## ZS-28-A-X538



To PFGV301

To the existing PFMV30 wiring

## ▲ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)\*1), and other safety regulations.

**Danger**: Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

Warning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

Caution: Caution indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

## **A** Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
  - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
  - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
  - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

### 4. Our products cannot be used beyond their specifications. Our products are not developed, designed, and manufactured to be used under the following conditions or environments. Use under such conditions or environments is not covered.

- 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
- 2. Use for nuclear power, railways, aviation, space equipment, ships, vehicles, military application, equipment affecting human life, body, and property, fuel equipment, entertainment equipment, emergency shut-off circuits, press clutches, brake circuits, safety equipment, etc., and use for applications that do not conform to standard specifications such as catalogs and operation manuals.
- 3. Use for interlock circuits, except for use with double interlock such as installing a mechanical protection function in case of failure. Please periodically inspect the product to confirm that the product is operating properly.

\*1) ISO 4414: Pneumatic fluid power - General rules and safety requirements for systems and their components ISO 4413: Hydraulic fluid power - General rules and safety requirements for systems and their components IEC 60204-1: Safety of machinery - Electrical equipment of machines - Part 1: General requirements ISO 10218-1: Robots and robotic devices - Safety requirements for industrial robots - Part 1: Robots etc.

## 

We develop, design, and manufacture our products to be used for automatic control equipment, and provide them for peaceful use in manufacturing industries.

### Use in non-manufacturing industries is not covered.

Products we manufacture and sell cannot be used for the purpose of transactions or certification specified in the Measurement Act. The new Measurement Act prohibits use of any unit other than SI units in Japan.

## Limited warranty and Disclaimer/ **Compliance Requirements**

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

### Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.\*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.

\*2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

### **Compliance Requirements**

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

### **Revision History**

Edition B \* A flow rate display function has been added to the voltage monitor for the PFMV3. NS

Edition C \* Not available

- Edition D \* The PFMV3 has been changed to the PFGV3.
  - The PFMV505-X502 has been added.

Safety Instructions Be sure to read the "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" before use.

## **SMC** Corporation