Vacuum Pad/Bellows Type


2.5-stage Ø20, Ø32, Ø50 5.5-stage Ø20, Ø25, Ø32, Ø40, Ø50

For the adsorption transfer of workpieces with flexible soft film packaging

Thin film skirt and special shaped ribs

Thin film skirt Adapts to changes in soft packaging shape Vacuum leakage reduced by improved sealing effect Prevent the skirt from becoming caught

New Added: 2.5-stage bellows type



The pad and attachment are made of materials compliant with FDA (U.S. Food and Drug Administration) regulations as well as Food Sanitation Act standards.

Blue colored pad

Easy to distinguish the vacuum pad by color during contamination inspection


ZP3P-JT Series








Unstable workpieces such as bagged liquid or powder can be transferred.



Bellows Type

2.5 -stage


Prevents the suction of foreign matter




Stainless steel mesh at suction port*1

- Prevents the intrusion of foreign matter into piping
- Easy to check for clogging and easy to clean
- Reduced suction filter element replacement frequency
- *1 The mesh will not fall off because it is integrally molded into the attachment.

Reduced deflection during transfer before adsorption




Expanded hole size



- Expanded hole size to ensure suction flow rate
- Compatible with vacuum blower pumps
- G3/8 and G1/2 standardized for the direct mounting/male thread type
 Min. opening hole size of the adapter: Ø11.5 (Pad diameter: Ø32 or Ø50)









Multi-stage stroke


- Adaptable to changes in workpiece height and angle
- Reduced impact on the contents







Application examples


Workpieces of varying heights can be adsorbed by the stroke.





Variations





CONTENTS

Vacuum Pad/Bellows Type ZP3P-JT Series





2.5-Stage/Bellows Type

How to Order	p. 5
Specifications	p. 5
Dimensions/Models	p. 6
Construction	p. 8

Mounting Bracket Assembly Specific Product Precautions

5.5-Stage/Bellows Type

How to Order	p. 9
Specifications	p. 9
Dimensions/Models	p. 10
Construction	p. 12




Vacuum Pad

2.5-Stage/Bellows Type

ZP3P-JT Series





Pad diameter

20	ø20
32	ø32
50	ø50

2 Attachment

W	With attachment
WM	With mesh attachment

With adapter

3 Connection thread/4 Vacuum inlet

	3 Conne	ction threa	d	4	Vacuum	inlet	Pad diam	eter [mm]
Type	Thread	Symbol	Size	Thread	Symbol	Size	ø20	ø32, ø50
		AG01	G1/8				•	•
	Male	AG02	G1/4		Nil	*1	•	•
Direct	thread	AG03	G3/8	_	IVII		•	•
mounting		AG04	G1/2				_	•
	Female	BG01	01 G1/8		Nil	*1	•	_
	thread	BG02 G1/4			INII		_	•
				Female	B01	Rc1/8		
		A16	M16 x 1	thread	BN01	NPT1/8		
Plate	Male	Alo	IVITOXI	One-touch fitting*2 08		ø8		_
mounting	thread			Female	B02	Rc1/4		
		A20	M20 x 1	thread	BN02	NPT1/4		
		A20	IVIZU X I	One-touch fitting*2	10	ø10	_	

- *1 Use the connection thread.
- *2 Built-in One-touch fitting type

Pad, adapter assembly, and mounting nuts are included but do not come assembled.


Specifications

Operating ter	mperature range	−30 to 90°C*1
	Material	Silicone rubber*2, *3
Pad	Color	Blue
	Hardness (Shore A: ±5°)	40
	Material	Synthetic resin*2, *4/Stainless steel*5
	Color	White
	Mesh	Mesh: 60/Opening: 280 μm

- *1 -5 to 60 [°C] for the vacuum inlet with One-touch fitting
- *2 Compliant with FDA (U.S. Food and Drug Administration) regulation 21CFR§177.
- *3 Compliant with the standards for "Rubber apparatus (excluding baby drinking apparatus) and containers/packaging" (D3) (Partial revision: Ministry of Health, Labour, and Welfare Notification No. 595, 2012) in Section 3 "Apparatus and Containers/Packaging" of the Food Sanitation Act, Article 18 "Specifications and Standards for Food and Food Additives, etc." (Ministry of Health and Welfare Notification No. 370, 1959)
- *4 Compliant with the standards for "Synthetic resin apparatus and containers/packaging" (D2) in Section 3 "Apparatus and Containers/Packaging" of the Food Sanitation Act, Article 18 "Specifications and Standards for Food and Food Additives, etc." (Ministry of Health and Welfare Notification No. 370, 1959)
- *5 Stainless steel included only for mesh attachment



Pad unit




ZP3P - 20 JT2SF - W

		ı	Mode	ı							
	Pad dia.	Form	Number of bellows stages	Material	2 Attachment	A	В	С	D	(st)*1	Weight [g]
	20					20	17.7	16	15.2	2.5	2.8
ZP3P	32	JT	2	SF	W WM	32	24.6	25	20.6	4	8.3
	50					50	28.7		22.2	6.5	13.8

^{*1 (}st) indicates achieved vacuum pressure: Reference at -85 [kPa]

With adapter Direct mounting type (Male thread)




*1 Same dimension as the pad unit

ZP3P-T20JT2SF-W-AG01

			N	lodel										Min.	
	Vacuum inlet direction		Form	Number of bellows stages	Material	2 Attachment	Connection thread	E	F	G	Н	J	Weight [g]	opening hole size of the adapter	
							AG01	21.7	5.5	G1/8	18	17	6.5	ø5	
		20					AG02	22.7	6.5	G1/4	23	21	9.4	ø6.2	
							AG03	23.7	7.5	G3/8	29	27	15.9	00.2	
		32					AG01		5.5	G1/8		27	21.9	ø5.7	
							AG02	30.6	6.5	G1/4	29		21.6	ø8	
ZP3P	Т	32	JT	2	SF	WM	AG03		7.5	G3/8			20.9	ø11.5	
						*****	AG04	31.6	9	G1/2	32	30	27.8	011.5	
							AG01		5.5	G1/8			27.4	ø5.7	
		50					AG02	34.7	6.5	G1/4	29	27	27.1	ø8	
		50					AG03		7.5	G3/8			26.4	~11 E	
							AG04	35.7	9	G1/2	32	30	33.3	ø11.5	

With adapter Direct mounting type (Female thread)



*1 Same dimension as the pad unit


ZP3P-T 20 JT2SF-W-BG01 2 3 Cont

3 Connection thread (Female thread)


| BG01 | G1/8 |
| BG02 | G1/4 |

			N	1odel										Min.	
	Vacuum inlet direction	Pad dia.	Form	Number of bellows stages	Material	2 Attachment	Connection thread	K	L	M	N	P	Weight [g]	opening hole size of the adapter	
		20					BG01	28.7	18	G1/8	7.4	17	9.2	ø5	
ZP3P	Т	32	JT	2	SF	W WM	BC00	38.6	20	C1/4	11	27	31.1	~0	
		50				VV 1V1	BG02	42.7	29	G1/4	!!	21	36.7	- ø8	

With adapter Plate mounting type (Male/Female thread)




*1 Same dimension as the pad unit



				Mode	1													Min.
	Vacuum inlet direction	Pad dia.	Form	Number of bellows stages	Material	2 Attachment	3 Connection thread	Vacuum inlet	Q	R	S	T	U	V	w	X	Weight [g]	opening hole size of the adapter
		20					A16	B01	21.7	22	M16 x 1	1Ω	Rc1/8	17	5	19	24	ø5
		20					AIO	BN01	21.7		IVIIOXI	10	NPT1/8	17	3	19	23.8	
ZP3P	_	32	JT	2	SF	w		B02	30.6				Rc1/4				54.3	
ZFJF	•	32	01	_	31	WM	A20	BN02	30.0	26	M20 x 1		NPT1/4	27	6	0.4	54.1	ø8
		50					AZU	B02	34.7	20	IVIZU X I	29	Rc1/4	21	0	24	59.8	٥٥
		50						BN02	34.7				NPT1/4				59.7	

With adapter Plate mounting type (Male thread/One-touch fitting)



ZP3P-T20JT2SF-W-A16-08

	Model																Min.		
	Vacuum inlet direction	Pad dia.	Form	Number of bellows stages	Material	2 Attachment	3 Connection thread	4 Vacuum inlet	Ø	R	s	Т	U	٧	W	X	Y	101	opening hole size of the adapter
		20					A16	08	21.7	22	M16 x 1	18	8	17	5	19	48.6	24.8	ø5
ZP3P	Т	32	JT	2	SF	W W	A20	10	30.6	26	M20 x 1	29	10	27	6	24	62	56.7	~7.5
		50					AZU	10	34.7	20	IVIZU X I	29	10	27	0	24	66.1	62	ø7.5


*1 Same dimension as the pad unit

7

Vacuum Pad *ZP3P-JT Series* 2.5-Stage/Bellows Type

Construction

Direct mounting type (Male thread) ZP3P-T□JT2SF-□-A□



Direct mounting type (Female thread) ZP3P-T□JT2SF-□-B□




Plate mounting (Male/Female thread) ZP3P-T□JT2SF-□-A□-B□





Plate mounting (Male thread/One-touch fitting) ZP3P-T□JT2SF-□-A□-□



Component Parts

No.	Description	Material (Surface treatment)
1	Bellows pad	Silicone rubber
2	Attachment	Synthetic resin
2	Mesh attachment	Synthetic resin/Stainless steel
3	Adapter	Aluminum alloy (Anodized)
4	O-ring	Silicone rubber
5	Mounting nut	Steel (Trivalent zinc chromated)
6	Seal	NBR
7	Cassette	_

Replacement Parts

Pad Unit (Without attachment)

Part number	Applicable pad dia.
ZP3P-20JT2SF	ø20
ZP3P-32JT2SF	ø32
ZP3P-50JT2SF	ø50

Attachment Unit

Part number	Applicable pad dia.
ZP3PW-20JT2	ø20
ZP3PW-32JT2	ø32
ZP3PW-50JT2	ø50

Mesh Attachment Unit


Part number	Applicable pad dia.
ZP3PWM-20JT2	ø20
ZP3PWM-32JT2	ø32
ZP3PWM-50JT2	ø50



Vacuum Pad

5.5-Stage/Bellows Type

ZP3P-JT Series



1 Pad diameter

20	ø20
25	ø25
32	ø32
40	ø40
50	ø50

With adapter

2 Connection thread/3 Vacuum inlet

	2 Conne	ction threa	d	€	Vacuum	inlet	Pad diam	eter [mm]
Type	Thread	Symbol	Size	Thread	Symbol	Size	ø20, ø25	ø32 to ø50
	Male	AG01	_		Nil	*1	•	•
Direct	ng Female BG01 G1/8		_	INII		_	•	
mounting			Nil	*1	•	_		
	thread	BG02	G1/4	_	INII		_	•
				Female	B01	Rc1/8		
		A16	M16 x 1	thread	BN01	NPT1/8		
Plate	Male	AIO	IVITOXI	One-touch fitting*2	08	ø8		_
mounting	thread			Female	B02	Rc1/4		
		A20	M20 x 1	thread	BN02	NPT1/4		
		AZU	IVIZU X I	One-touch fitting*2	10	ø10	_	

- *1 Use the connection thread.
- *2 Built-in One-touch fitting type

Pad, adapter assembly, and mounting nuts are included but do not come assembled.


Specifications

Operating ter	mperature range	–30 to 90°C* ¹
	Material	Silicone rubber*2, *3
Pad	Color	Blue
	Hardness (Shore A: ±5°)	40
Guide	Material	Synthetic resin*2, *4
attachment	Color	White

- *1~-5 to 60 [°C] for the vacuum inlet with One-touch fitting
- *2 Compliant with FDA (U.S. Food and Drug Administration) regulation 21CFR§177.
- *3 Compliant with the standards for "Rubber apparatus (excluding baby drinking apparatus) and containers/packaging" (D3) (Partial revision: Ministry of Health, Labour, and Welfare Notification No. 595, 2012) in Section 3 "Apparatus and Containers/Packaging" of the Food Sanitation Act, Article 18 "Specifications and Standards for Food and Food Additives, etc." (Ministry of Health and Welfare Notification No. 370, 1959)
- *4 Compliant with the standards for "Synthetic resin apparatus and containers/packaging" (D2) in Section 3 "Apparatus and Containers/Packaging" of the Food Sanitation Act, Article 18 "Specifications and Standards for Food and Food Additives, etc." (Ministry of Health and Welfare Notification No. 370, 1959)



Pad unit




ZP3P - 20 JT5SF - WG

		1	Mode	ı							
	Pad dia.		Number of bellows stages		Attachment	A	В	С	D	(st)*1	Weight [g]
	20					20	31.2	16	21.2	10	4.6
	25					25 35	10	23	12	6.3	
ZP3P	32	JT	5	SF	WG	32	45		29	16	14.8
	40					40	51.5	25	31.5	20	20.3
	50					50	59		33	26	26.9

^{*1 (}st) indicates achieved vacuum pressure: Reference at -85 [kPa]

With adapter Direct mounting type (Male thread)



*1 Same dimension as the pad unit

ZP3P-T20JT5SF-AG01

ZP3P-T 20 JT5SF-BG01


2 Connection thread (Female thread)

G1/8

G1/4

			Mod	el									Min.
	Vacuum inlet direction	Pad dia.	F	Number of bellows stages	Maradal	Connection thread	E	F	G	Н	J	Weight [g]	opening hole size of the adapter
		20				AG01	35.2	5.5	G1/8	18	17	8.3	ø5
		25		Г 5		AG01	39	5.5	G 1/6	10	17	10.1	00
		32				AG01 51	5.5	G1/8			28.4	ø5.7	
ZP3P	т		JT		SF	AG02	G02	6.5	G1/4			28.2	ø8
ZP3P	•	40	וט		ЭГ	AG01	5.5	G1/8	00	27	33.9	ø5.7	
		40				AG02	57.5	6.5	G1/4	29	21	33.7	ø8
		50				AG01	01 05	5.5	G1/8			40.5	ø5.7
		50				AG02	65	6.5	G1/4			40.2	ø8

With adapter Direct mounting type (Female thread)




			Mode	el									Min.
	Vacuum inlet direction		Form	Number of bellows stages	Material	Connection thread	K 42.2	L	М	N	P	Weight [g]	opening hole size of the adapter
ZP3P		20	JT			BG01	42.2	10	C1/0	7.4	17	11	αE
		25					46	18	G1/8	7.4	17	12.8	ø5
	Т	32		5	SF		59					37.7	
		40					65.5	29	G1/4	11	27	43.2	ø8
		50				73					49.8		

BG01


BG02

^{*1} Same dimension as the pad unit

With adapter Plate mounting type (Male/Female thread)




*1 Same dimension as the pad unit



			Мо	del													Min.
	Vacuum inlet direction	Pad dia.	Form	Number of bellows stages	Material	2 Connection thread	Vacuum inlet	Q	R	S	Т	U	٧	w	X	Weight [g]	opening hole size of the adapter
		20					B01	35.2				Rc1/8				25.8	
		20				A16	BN01	33.2	22	M16 x 1	18	NPT1/8	17	5	19	25.7	ø5
		25				710	B01 BN01	39	22	MITOXI	10	Rc1/8		3		27.5	
		25						00				NPT1/8				27.4	
ZP3P	т	32 J	JT	5	SF		B02	51				Rc1/4				60.8	
ZFJF	•	32	01	3	31		BN02	31				NPT1/4				60.6	
		40				A20	B02	57.5	26	M20 x 1	29	Rc1/4	27	6	24	66.3	ø8
		40				A20	BN02	37.3	20	IVIZUXI	29	NPT1/4	21	0	24	66.1] 00
		50				_	B02	65				Rc1/4				72.9	
		50					BN02	00				NPT1/4				72.7	

With adapter Plate mounting type (Male thread/One-touch fitting)



 $\ast 1$ Same dimension as the pad unit

ZP3P-T	20 J	T5SF - A1	- 丁	ıum inlet
	Conne	ction thread 🙎	(One	-touch fitting)
		fale thread)	08	ø8
	A16	M16 x 1	10	ø10
•	A20	M20 x 1		

				Мо	del														Min.
		Vacuum inlet direction	Pad dia.	Form	Number of bellows stages	Material	2 Connection thread	Vacuum inlet	Q	R	S	Т	U	٧	W	X	Y	101	opening hole size of the adapter
	20 25	20				A16	08	35.2	00	M16 x 1	10	8	17	5	10	62.1	26.6	~ F	
					AIO	00	39	22	12 WITO X T	18	0	'	5	19	65.9	28.4	ø5		
ZF	ZP3P	т	32		5	SF			51								82.4	63.2	
21 31		40	-			A20	A20 10	57.5	26	M20 x 1	29	10	27	6	24	88.9	68.4	ø7.5	
			40 50						65								96.4	75.1	1

Vacuum Pad **ZP3P-JT** Series 5.5-Stage/Bellows Type

Construction

Direct mounting type (Male thread) ZP3P-T□JT5SF-A□





Plate mounting type (Male/Female thread) ZP3P-T□JT5SF-A□-B□



Component Parts

No.	Description Material (Surface treatment)						
1	Bellows pad	Silicone rubber					
2	Synthetic resin						
3	Adapter	Aluminum alloy (Anodized)					
4	O-ring	Silicone rubber					
5	Mounting nut	Steel (Trivalent zinc chromated)					
6	Seal	NBR					
7	Cassette	_					

Direct mounting type (Female thread) ZP3P-T□JT5SF-B□





Plate mounting type (Male thread/One-touch fitting) ZP3P-T□JT5SF-A□-□



Replacement Parts

Pad Unit (Without guide attachment)


, , , , , , , , , , , , , , , , , , , ,						
Part number	Applicable pad dia.					
ZP3P-20JT5SF	ø20					
ZP3P-25JT5SF	ø25					
ZP3P-32JT5SF	ø32					
ZP3P-40JT5SF	ø40					
ZP3P-50JT5SF	ø50					

Guide Attachment Unit

dalac Attabililicit offit							
Part number	Applicable pad dia.						
ZP3PWG-20JT5	ø20						
ZP3PWG-25JT5	ø25						
ZP3PWG-32JT5	ø32						
ZP3PWG-40JT5	ø40						
ZP3PWG-50JT5	ø50						

Vacuum Pad ZP3P-JT Series Mounting Bracket Assembly


■ Adapter Assembly: Direct Mounting Type



		Туре	Size	Cumbal	Pad diameter symbol						
	thread		Size	Symbol	20	25	32	40	50		
-	thre	Male thread	G1/8	AG01	ZP3PA-T1	JT-AG01		ZP3PA-T2JT-AG01			
Adapter	tion		G1/4	AG02	ZP3PA-T1	JT-AG02*1	ZP3PA-T2JT-AG02				
Ad	Connection		G3/8	AG03	ZP3PA-T1	JT-AG03*1	7	ZP3PA-T2JT-AG03*	1		
•	Con		G1/2	AG04	-	_	7	ZP3PA-T2JT-AG04*	1		
ľ	8	Female	G1/8	BG01	ZP3PA-T1	JT-BG01		_			
		thread	G1/4	BG02	_			ZP3PA-T2JT-BG02			

^{*1 2.5-}stage bellows only

■ Adapter Assembly: Plate Mounting Type



		Tuna	Size	Symbol		Tyme	Cina Cumbal	1 Pad diameter symbol						
ad	thread	Туре	Size	Symbol	_	Туре	Size	Symbol	20	25	32	40	50	
1				A16	inle	Female thread	Rc1/8	B01	ZP3PA-T1	JT-A16-B01	<u> </u>			
1	tion				A16 acnum	remale illieau	NPT1/8	BN01	ZP3PA-T1JT-A16-BN01		_			
1	connection th	Male				One-touch fitting	ø8	08	ZP3PA-T1	ZP3PA-T1JT-A16-08		_		
(5) US	thread			8	Female thread	Rc1/4	B02	_	_	ZP3P	A-T2JT-A2	0-B02	
	Q				A20	A20	A20	A20	Fell	remale infeau	NPT1/4	BN02	_	
						One-touch fitting	ø10	10	_		ZP3P	A-T2JT-A	20-10	
	B Mounting nut (Single unit) (Sales unit: 10 pcs.)			M16 x 1			KQ08-P01A		_					
				M20 x 1			_	_	KQ10-P01A					



ZP3P-JT Series Vacuum Pad/Specific Product Precautions

Be sure to read this before handling the products. Refer to the back cover for safety instructions. For vacuum equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website.

Operating Precautions

⚠ Caution

1. When mounting the product, tighten with the tightening torque shown in the table below.

If excessive or insufficient tightening torque is applied, sealing failure or loose screws may result.


Direct mounting (Male thread)	

Adapter

Connection thread size	Proper tightening torque [N·m]	
G1/8	3 to 5	
G1/4	8 to 12	
G3/8	15 to 20	
G1/2	20 to 25	
	thread size G1/8 G1/4 G3/8	

Direct mounting type (Female thread)	
Adapter	

Product part number	Connection thread size	Proper tightening torque [N·m]
ZP3P-T□JT□-□-BG01	G1/8	3 to 5
ZP3P-T□JT□-□-BG02	G1/4	8 to 12



Product part number	Connection thread size	Proper tightening torque [N·m]	
ZP3P-T□JT□-□-A16-□	M16 x 1	7 to 9	ı
ZP3P-T□JT□-□-A20-□	M20 x 1	14 to 17	1

Depending on the achieved vacuum pressure, the theoretical lifting force may exceed the strength of the vacuum pad, deforming or breaking the pad.

The safety factor should be 16 times or more of the theoretical lifting force for horizontal lifting, and it should be 25 times or more for vertical lifting.

[Calculation of theoretical lifting force]

 $W = P \times S \times 0.1 \times \frac{1}{t}$

W: Lifting force [N]

P: Vacuum pressure [kPa]

S: Pad area [cm²]

t: Safety factor Horizontal lifting: 16 or more Vertical lifting: 25 or more

3. When a bagged workpiece is lifted, the skirt changes its shape according to the changing shape of the workpiece.

As the vacuum pad skirt changes its shape, the actual lifting force may be below the theoretical lifting force. Before use, please conduct testing with the customer's actual equipment.

4. Mount the attachment for use.

Without the attachment, the vacuum pad will be easily deformed, resulting in adsorption failure.

5. When the vacuum pad is pressed onto the workpiece, make sure it stays within the stroke range.

When the maximum stroke is exceeded, the guide attachment may contact the adapter, leading to malfunction.

6. When the attachment is inserted into the vacuum pad, the attachment may damage or break the skirt if it is pulled with excessive force as the skirt is very thin.

Vacuum pad damage or breakage may lead to adsorption failure.

7. When the achieved vacuum pressure is low (approx. -20 [kPa]), the vacuum pad does not completely operate its stroke.

When a 5.5-stage bellows is used, and vacuum pressure is approx. –20 [kPa], the guide function cannot be used effectively because the guide attachment cannot be pulled up into the adapter.

8. Use the product within the operating temperature range.

The heat resistant temperature of the attachment (made of synthetic resin) is $90^{\circ}\text{C}.$

Operate within the specified operating temperature range (-30 to 90° C).

For temperatures outside of the operating temperature range, contact your local SMC representative.

9. Do not interfere with the vacuum pad stroke with an external stopper.

The vacuum pad will become deformed, resulting in adsorption failure or breakage. In some cases, the workpiece will separate from the pad and fall.

- 10. Vacuum pads are consumable. Please replace them when cracks, wear, or deformation is confirmed during periodic maintenance.
- 11. Before use, please check the transfer conditions with the customer's actual equipment.

Products are confirmed as transferable under SMC's specific testing conditions in the table below, but these are not guaranteed values. The transfer ability varies depending on the workpiece material, the friction between the pad and workpiece, moment, wind, vibration, etc. Testing with the customer's actual equipment is necessary.

· SMC's Specific Testing Conditions (Reference)

Civic	- eme a opecine reading conditions (reference)								
	Number	Workpiece		Adsorption conditions		Horizontal transfer conditions			
Pad diameter	of bellows stages	Material	Load [kg]	Ejector part number	Supply pressure [kPa]	Speed [mm/s]	Acceleration/ Deceleration [G]		
ø20		0.17				2			
ø25		Aluminum	0.27				3		
ø32	5.5 -stage	metalized	0.5	ZH15D	-85	1000	3		
ø40		film	0.7				4		
ø50			1.1				4		

- Adsorption is confirmed for 1 stroke, not for a back and forth or repeated operation.
- 12. When supplying vacuum release air, do so at a release flow rate of 110 L/min (ANR) or less. Failure to do so may result in damage to the vacuum pads.



⚠ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

Caution: Caution indicates a hazard with a low level of risk which, If not avoided, could result in minor or moderate injury.

Warning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

⚠ Danger: Danger if not avoided, will result in death or serious injury. **Danger** indicates a hazard with a high level of risk which, *1) ISO 4414: Pneumatic fluid power - General rules relating to systems.

ISO 4413: Hydraulic fluid power – General rules relating to systems.

IEC 60204-1: Safety of machinery - Electrical equipment of machines. (Part 1: General requirements)

ISO 10218-1: Manipulating industrial robots - Safety.

⚠Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
 - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
 - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

⚠ Caution

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary. If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/ **Compliance Requirements**

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.*2) Also, the product may have specified durability, running distance or
- replacement parts. Please consult your nearest sales branch. 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
 - 2) Vacuum pads are excluded from this 1 year warranty.

other damage incurred due to the failure of the product.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered.

Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

⚠ Caution

SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

Revision History

- Edition B * The 2.5-stage bellows type has been added.
 - * Plate mounting (One-touch fitting) has been added to the 5.5-stage bellows
 - * Number of pages has been increased from 12 to 16.

ΥV