Guide Table


Series MGF

Ø40, Ø63, Ø100

Low-profile compact cylinder utilizes a large concentric guiding sleeve to provide excellent eccentric load resistance.

■ Mounting height greatly reduced

Low-profile cylinder enables compact machine design.



■ Built-in non-rotating mechanism

Internal guide pin prevents rotation.

Non-rotating accuracy

Bore size (mm)	Non-rotating accuracy θ
40	± 0.08°
63	± 0.06°
100	± 0.05°

■ Series Variations

Model	Bore size	Sta	ndard s	stroke (mm)
Iviouei	(mm)	30	50	75	100
MGF 40	40	-+-	-+-	-+-	_+_
MGF 63	63	_+	_+	-+-	_+
MGF100	100	-+-	-+-	-+-	_+

■ Built-in T-slots

T-slots are provided on 3 faces of the body (except port face), allowing mounting for various brackets.

(Not suitable for mounting the cylinder itself.)

■ Auto switches can be mounted on 4 lateral faces of the body.

■ Large diameter guide (Eccentric load resistant)


A large diameter guide rod enables the cylinder to handle eccentric loads applied from any direction within a 360° angle.

Allowable moment


Bore size (mm)	Allowable moment (N·m)
40	10
63	40
100	110

^{*} Values are at a cylinder speed of 100 mm/s.

■ Can be mounted from two directions



■ Application examples



多SMC

MGJ

MGP

MGQ

MGG


MGC

MGF


MGZ

MGT

Model Selection




Allowable rotational torque



T (N·m)

Bore size	Stroke (mm)						
(mm)	30	50	75	100			
40	7	5	4	3			
63	22	16	12	10			
100	30	22	17	13			


Non-rotating accuracy



Bore size (mm)	Non-rotating accuracy θ
40	± 0.08°
63	± 0.06°
100	± 0.05°

Note) The value given for the non-rotating accuracy is applicable below the allowable rotational torque. If a greater rotational torque is applied, the non-rotating rod (page 415) bends, exceeding the value of the non-rotating accuracy.

Deflection angle of plate for eccentric load





Bore size (mm)	Deflection angle $ heta^\circ$			
40	$\pm~0.35^{\circ}$ or less			
63	+ 0.3° or less			
100	± 0.3 or less			




Operating Conditions

Allowable horizontal load










Allowable eccentric load

The maximum value of load which can be applied at an eccentric position at a distance of ℓ (mm) from the cylinder center.







How to read the graph

MGF

MGZ

MGT

D-□

-X□


Individual

¹⁾ When the load mass is 70 kg, eccentric distance is 60 mm, and the maximum speed is 150 mm/s \rightarrow Select MGF100 from Graph \odot .

²⁾ When MGF63 is operated with a load mass 30 kg and 100 mm eccentric distance → From Graph ⑥, the cylinder can be used at a maximum speed of 100 mm/s or less.

Guide Table Series MGF Ø40, Ø63, Ø100

How to Order



Applicable Auto Switch/Refer to pages 1719 to 1827 for further information on auto switches

(Example) M9NWZ

	nicable Auto Swi	1		ageee te		Load volta			tch model	Lead	wire l	enath	(m)					
Туре	Special function	Electrical entry	Indicator light	Wiring (Output))C	AC	Perpendicular	In-line	0.5 (Nil)	1	3	5 (Z)	Pre-wired connector	Applical	ble load		
				3-wire (NPN)		5 V 10 V		M9NV	M9N	•	•	•	0	0	IC			
				3-wire (PNP)		5 V, 12 V		M9PV	M9P	•	•	•	0	0	circuit			
switch				2-wire		12 V		M9BV	M9B	•	•	•	0	0	_			
Se	Dia anno atto ta dio attore			3-wire (NPN)	<u>/</u>	5 V, 12 V	V, 12 V	M9NWV	M9NW	•	•	•	0	0	IC	Б.		
tate	Diagnostic indication (2-color indication) Grommet	Grommet	Yes	3-wire (PNP)				M9PWV	M9PW	•		•	0	0	circuit	Relay, PLC		
				2-wire		12	12 V		M9BWV	M9BW	•	•	•	0	0	_	PLC	
Solid	Water resistant			3-wire (NPN)	5 V 10 V	5 V, 12 V		M9NAV	M9NA	0	0	•	0	0	ıc			
0)	(2-color indication)			3-wire (PNP)	1		5 V, 12 V	5 V, 12 V	5 V, 12 V		M9PAV	M9PA	0	0	•	0	0	circuit
	(2-color indication)			2-wire		12 V		M9BAV	M9BA	0	0	•	0	0	_			
ed tch	Reed switch	_ Y	Yes	3-wire (NPN equivalent)	_	5 V	_	_	Z 76	•	-	•	_	_	IC circuit	_		
N. Wil		Grommet		2-wire	24 \/	12 \/	100 V		Z 73	•	-	•	_	_	_	Relay,		
0,			No		24 V	IV 12 V	100 V or less	_	Z80	•	_	•	_	_	IC circuit	PLC		

* Lead wire length symbols: 0.5 m Nil (Example) M9NW (Example) M9NWM (Example) M9NWL 1 m M 3 m L

5 m Z

* ○: D-A9□/A9□V cannot be mounted.

* Solid state auto switches marked with "O" are produced upon receipt of order.

* For details about auto switches with pre-wired connector, refer to pages 1784 and 1785. * Auto switches are shipped together (not assembled).

 $[\]ast$ Since there are other applicable auto switches than listed, refer to page 419 for details.

Guide Table Series MGF



Specifications

Bore size (mm)	40 50 60						
Action	Double acting						
Fluid	Air						
Proof pressure	1.5 MPa						
Maximum operating pressure		1.0 MPa					
Minimum operating pressure	0.1 MPa						
Ambient and fluid temperature	−10 to 60°C						
Piston speed	20 to 200 mm/s						
Cushion	Rubber bumper on both ends						
Lubrication	Non-lube						
Stroke length tolerance	*1.0 mm						

Made to Order

Made to Order Specifications
(For details, refer to page 1847.)

Symbol	Specifications
—ХС79	Machining tapped hole, drilled hole and pin hole additionally

Standard Stroke

Model	Standard stroke (mm)	Intermediate stroke
MGF 40		As for the intermediate strokes (by the 5 stroke interval) other than the standard strokes at left are manufactured by means of installing
MGF 63		a spacer with the width of 5, 10, 15, 20, 25 mm. Example) In the case an MGF63-15 specification is required, a spacer of 15 mm is installed in the MGF63-30.The full
MGF100		length dimension when the cylinder is retracted is the same as that of 30 mm stroke.

Theoretical Output

								0	UT (N)		IN (N)	
										-	-	(N
Bore size	Rod size	Operating	Piston area			Op	erating	press	ure (M	Pa)		
(mm)	(mm) (mm) dir	direction	(mm ²)	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1.0
40	0.5	OUT	1256	251	376	502	628	753	879	1004	1130	1256
40	25	IN	765	153	229	306	382	459	535	612	688	765
60	00	OUT	3117	623	935	1246	1558	1870	2182	2493	2805	3117
63	36	IN	2099	419	629	839	1049	1259	1469	1679	1889	2099
100	-00	OUT	7853	1570	2356	3141	3926	4711	5497	6282	7067	7853
	36	IN	6835	1367	2050	2734	3417	4101	4784	5468	6151	6835

Note) Theoretical output (N) = Pressure (MPa) x Piston area (mm²)

MGJ

MGP

MGQ MGG

MGC

MGF

MGZ

MGT

Mass


					(kg)			
Model	Bore size	Standard stroke (mm)						
	(mm)	30	50	75	100			
MGF 40	40	2.1	2.6	3.2	3.8			
MGF 63	63	4.3	5.1	6.1	7.1			
MGF100	100	7.0	8.2	9.6	11.0			


D-□

-X□



Clean Series






Dimensions (m				
Α	В	GB		
58	48.5	36.5		
73	61.5	38		
78	66.5	38		
	A 58 73	A B 58 48.5 73 61.5		


Dimensions other than the above are the same as standard products.

Guide Table Series MGF

Construction



When the cylinder is extended



When the cylinder is retracted

Component Parts

No.	Description	Material	Note
1	Body	Aluminum alloy	Clear anodized
2	Tube	Aluminum alloy	Black hard anodized
3	Rod cover	Aluminum alloy	Black hard anodized
4	Piston	Aluminum alloy	Chromated
5	Piston rod	Carbon steel	Electroless nickel plated
6	Plate	Aluminum alloy	Anodized
7	End plate	Aluminum alloy	Anodized
8	Non-rotating rod	Stainless steel	Hard chrome plated
9	Bushing	Resin	
10	Bushing (For non-rotating rod)	Lead-bronze casted	
11	Bumper	Urethane	
12	Hexagon socket head cap screw A	Carbon steel	Nickel plated

Replacement Parts: Seal Kit

Bore size (mm)	Kit no.	Contents
40	MGF 40-PS	
63	MGF 63-PS	Items (9) to (23) from
100	MGF100-PS	the table above.

Component Parts

No.	Description	Material	Note
13	Hexagon socket head cap screw B	Carbon steel	Nickel plated
14	Hexagon socket head cap screw C	Carbon steel	Nickel plated
15	Magnet	_	
16	Plug	Carbon steel	
17	Element	Resin	
18	Retaining ring	Spring steel	
19	Rod seal	NBR	
20	Piston seal	NBR	
21	O-ring A	NBR	
22	O-ring B	NBR	
23	O-ring C	NBR	
24	Reinforcement ring	Carbon steel	Electroless nickel plated

MGJ

MGP

MGQ

MGG

MGC

MGF MGZ

MGT

D-□ -X□







^{*} Seal kit is not compatible with the clean series.
Seal kit includes (9 to (3). Order the seal kit based on each bore size.
* Since the seal kit does not include a grease pack, order it separately.
Grease pack part no.: GR-L-010 (10g)


Dimensions: Ø40


MGF40




When the cylinder is extended













MGF63





When the cylinder is extended











D-□ -X□

MGJ

MGP

MGQ

MGG

MGC


MGF

MGZ


MGT


Dimensions: Ø100


MGF100



When the cylinder is extended








Minimum Auto Switch Mounting Stroke

(mm)

				Applica	able auto switch	n model			
No. of auto switches mounted	D-M9□V	D-M9□WV D-M9□AVL	D-M9□ D-M9□W	D-M9□AL	D-Z7□ D-Z8□	D-Y69□ D-Y7PV	D-Y59□ D-Y7P	D-Y7□WV	D-Y7□W D-Y7BAL
1 pc.	5	10	15	20	10	5	10	15	20
2 pcs.	10	10	20	25	15	10	10	15	20

Auto Switch Proper Mounting Position (Detection at Stroke End)



Auto Sw	Auto Switch Proper Mounting Position					
Auto switch model	D-M9(D-M9(D-M9(D-M9(D-M9□ D-M9□V D-M9□W D-M9□WV D-M9□AL D-M9□AVL		80 Y69□ 7PV /Y7□WV -		
(mm)	Α	В	Α	В		
40	9	5	4	0		
63	19.5	5	14.5	0		
100	24.5	5	19.5	0		

Dimensions above denote the standard strokes.

Adjustment on A dimension is required for intermediate strokes.

Note) Adjust the auto switch after confirming the operating conditions in the actual setting.

Operating Range


			(mm)
A. da accidada con adal	Bore size (mm)		
Auto switch model	40	63	100
D-M9□/M9□V D-M9□W/M9□WV D-M9□AL/M9□AVL	6	6.5	6
D-Z7□/Z80	10	10	10
D-Y59□/Y69□ D-Y7P/Y7PV D-Y7□W/Y7□WV D-Y7BAL	6	6	6

* Since this is a guideline including hysteresis, not meant to be guaranteed. (Assuming approximately ±30% dispersion) There may be the case it will vary substantially depending on an ambient environment.

Auto Switch Mounting Bracket: Part No.

Auto switch model	Bore size (mm) Ø40, Ø63, Ø100
D-M9□/M9□V D-M9□W/M9□WV D-M9□AL/M9□AVL	BMG2-012

$D-M9\square(V)/M9\square W(V)/M9\square A(V)L$



Other than the applicable auto switches listed in "How to Order", the following auto switches can be mounted. For detailed specifications, refer to pages 1719 to 1827.

Auto switch type	Model	Electrical entry (Fetching direction)	Features
D-Y69A, Y69B, Y7PV Crammat (B		Grommet (Perpendicular)	_
Solid state	D-Y7NWV, Y7PWV, Y7BWV	Grommet (Perpendicular)	Diagnostic indication (2-color indication)
John State	D-Y59A, Y59B, Y7P	Crammat (In line)	_
	D-Y7NW, Y7PW, Y7BW	Grommet (In-line)	Diagnostic indication (2-color indication)

* For solid state auto switches, auto switches with a pre-wired connector are also available. Refer to pages 1784 and 1785 for details. * Normally closed (NC = b contact), solid state auto switch (D-F9G/F9H/Y7G/Y7H type) are also available. For details, refer to pages

1746 and 1748.

MGQ MGG

MGJ

MGP

MGC

MGF

MGZ

MGT







Series MGF Specific Product Precautions


Be sure to read before handling. Refer to front matters 42 and 43 for Safety Instructions and pages 3 to 11 for Actuator and Auto Switch Precautions.

Selection

⚠ Caution

- ① Operate loads within the range of the operating limits.
 - Select a model taking into consideration the allowable horizontal loads, rotational torque and eccentric loads that will apply. When used in excess of the applicable limit, eccentric loads applied to the tube guide will cause wear of the guide, increase the guide's deviation range, cause stress cracks and breaks on the mounting bolts, and decrease the life of the cylinder.
- ② Do not allow any dents, scratches, or other damage on the mounting faces of either the plate or end plate. The flatness of the mounting face may deteriorate, the guide's deviation range may increase and the sliding resistance may become greater.
- 3 Do not allow hands or fingers near the cylinder during its operation.

Your fingers may be caught between the body and the plate. If you need to come near the cylinder during its operation, install a cover on the cylinder.




④ Do not bring objects that are sensitive to magnetism near the cylinder.

There is a magnetic built into the cylinder. Do not bring magnetic disks, cards, or tapes near the cylinder. Data may be lost.

⑤ If the cylinder is operated vertically with heavy loads, measures must be taken to prevent rapid advancement of the piston rod when starting to operate in the downward direction.

If the cylinder is operated vertically with heavy loads at the same pressure for both upward and downward directions, the starting speed in the downward direction may be highter than the speed controlled with a speed controller. In such cases, use a dual pressure control circuit as an pneumatic circuit.



 Avoid use in environments where a cylinder will come in contact with coolants, cutting oil, water, adhesive matter, or dust, etc. Also avoid operation with compressed air that contains drain or foreign matter, etc.

Foreign matter or liquids on the cylinder's interior or exterior can wash out the lubricating grease, which can lead to deterioration and damage of bearing sliding parts and seal materials, causing a danger of malfunction.


When operating in locations with exposure to water and oil, or in dusty locations, provide protection such as a cover to prevent direct contact with the cylinder and operate with clean compressed air.

Mounting

⚠ Caution


① For mounting the cylinder, use screws that meet the appropriate length and tighten within the limits of the maximum tightening torque.

Mounting from upper side



Model	Bolt	Maximum tightening torque (N·m)	ℓ (mm)
MGF 40	M6 x 1	10	7.5
MGF 63	M8 x 1.25	25	9
MGF100	M10 x 1.5	51	9

Mounting from bottom side



Model	Bolt	Maximum tightening torque (N⋅m)	ℓ (mm)
MGF 40	M8 x 1.25	18	7.5
MGF 63	M10 x 1.5	36	9
MGF100	M12 x 1.75	65	9

When mounting a workpiece to the cylinder, do so only when the piston is retracted. Also make sure that the rotational torque applied to the cylinder body does not exceed the allowable rotational torque (given on page 410).

(Otherwise, the excessive rotational torque will damage the non-rotating mechanism and lead to a malfunction.)

